

Instructions for Red Cedar Backed Benches

Please read instructions entirely before beginning assembly.

Tools Required for Assembly





- 7/16" Socket or Adjustable Wrench
- #2 Square head Drill Bit (included)
- Hammer for tapping bolts and screws

Parts List



- 1 Bench Top
- 1 Back Assembly
- 2 Leg Assemblies
- 2 Cross Braces

Hardware

- 4 3" x 1/4" Hex Bolts
- 4 2 1/2" x 1/4" Hex Lag Screws
- 4 1/4" Hex Nuts
- 8 1 1/4" Large Washers
- 4 1/4" Small Washers
- 2 2 1/2" Square Head Screws


- Hex Bolt 
- Hex Lag Screw 
- Square Head Screw 
- Large Washer 
- Small Washer 
- Nut 
- Predrilled Hole 

Leg Assembly 45° Brace



Step 1

Lay the bench top upside down on a clean flat surface. We recommend using the box that the product was shipped in. Place each leg assembly on the inner edge of the 2x2 top surface and fasten with a 3" Hex Bolt. (Placing a washer at the end of the bolt.)




Step 2

Use the 2 1/2" Lag Screws and small washers to attach the 45° Braces to the leg and bench. Use a hammer to lightly tap the 2 1/2" screws into the leg and bench bottom. (There is no pre-drilled hole and it is recommended that you DO NOT pre-drill the holes. You can offset the 45° braces so they are not in the middle of the boards.)

Step 3

Now turn the bench upright and position the back assembly so that the angled bottom edges fit on the leg assembly's bottom braces. (see right)



Step 4

Insert the Hex Bolts into the pre-drilled holes on each side of the bench supports and through the sides of the back assembly. Be sure to use a large washer on each end of the bolt and tighten a nut at the end to secure. To complete assembly, use the square head bit to drive the screws through the back assembly braces and into the leg assembly.

