



ASSEMBLY INSTRUCTIONS

RESIN GARDEN SHED

SKU: T-PS24-0671

Patiowell,
Store
Your
Patio Well

www.patiowell.com



Patiowell
Resin Garden House
Installation Tutorial
[https://www.patiowell.com/
pages/video-T-PS24-0671](https://www.patiowell.com/pages/video-T-PS24-0671)


✉ saleservice@patiowell.com

SITE PREPARATION

Level the ground surface.



Recommendation: Construct a wooden or concrete base as a foundation.



BEFORE STARTING ASSEMBLY


Remove all of the pieces from the 2 packages and spread them out on the ground. Before installation, please check the type and quantity of parts first.

It is recommended to use a clean work surface to spread the parts out and for pre-assembly steps. Review all instructions before you begin, continue to refer to instructions during assembly.

Be sure to follow all steps thoroughly.

Please prepare these components in advance at the beginning of each stage.

REQUIRED TOOLS



CAUTION


Some parts have steel edges. Please be careful when handling components. Always wear work gloves, eye protection and long sleeves when assembling or performing any maintenance on your shed. Do not attempt assembly on days with strong winds or low temperatures.




Requires two people and takes 1-2 hours for Installation.
Recommended to wear gloves to avoid scratches.
Please read the manual carefully before installation.

**DO NOT RETURN YOUR UNIT
TO THE STORE**
Contact us first
saleservice@patiowell.com


FLOOR PARTS




A1 X2




A2 X2



A3 X2



A4 X2



A5 X1

WALL PARTS



B1 X2



BJ1 X4













DK-1 X1








DK-2 X1













WALL PARTS

			
	B1-2 X1	B1-4 X1	
B1-1 X3			
	B1-3 X1	4-B2 X9	
			
4-B3 X1		4-B4 X1	
			
4-B6 X1		B5 X6	



WINDOW PARTS

 W1 X1	 W2 X1	 W4 X1	 W5 X1
 W3 X1			









ROOF PARTS

 <p>4-E1 X6</p>		 <p>4-E2 X1</p>	
 <p>E3 X4</p>		 <p>4-E4 X2</p>	
 <p>F1 X2</p>		 <p>F2 X1</p>	
 <p>F4 X1</p>		 <p>DK-3 X1</p>	
 <p>F3 X1</p>	 <p>F5 X2</p>	 <p>C3 X2</p>	














ROOF PARTS

 <p>C1 X1</p>	 <p>C2 X1</p>
--	---



















DOOR PARTS

 <p>D1 X2</p>	 <p>D2 X2</p>	 <p>DB-2 X2</p>	 <p>DB-3 X1</p>
 <p>DB-4 X1</p>	 <p>DB-1 X4</p>		


ACCESSORIES

 <p>C4 X3</p>	 <p>A6 X2</p>	 <p>D1-3 X2</p>	 <p>D1-2 X1</p>
 <p>E5 X4</p>	 <p>E6 X2</p>	 <p>E7 X4</p>	 <p>E8 X2</p>
 <p>DB-5 X4</p>	 <p>DB-6 X1</p>	 <p>DB-7 X1</p>	 <p>M4 X8</p>
 <p>M5 X6</p>			

SCREW


 <p>22+2 pcs</p>  <p>S1 M5*10</p>	 <p>48+2 pcs</p>  <p>S2 M3.9*25</p>
 <p>72+2 pcs</p>  <p>S3 M3.9*30</p>	 <p>137+5 pcs</p>  <p>S4 M4-12</p>
 <p>8 pcs</p>  <p>S5 M4*10</p>	 <p>10+1 pcs</p>  <p>S7 M5*25</p>
 <p>6 pcs</p>  <p>S8 M5*45</p>	 <p>4 pcs</p>  <p>S9 M4*25</p>
 <p>16+1 pcs</p>  <p>S10 M4*30</p>	

CONTENTS




Floor Part Instruction

11-15
(page)




Wall Part Instruction

15-30
(page)



Roof Part Instruction


31-46
(page)




Door Part Instruction

46-50
(page)


STEP 1




STEP 2




STEP 3




STEP 4





STEP 5








STEP 6




STEP 7






Insert A1 at an angle.




STEP 8




Screw position



STEP 9




Put 4-B2, B5 into the floor corresponding grooves.




STEP 10



✓



✗




After placing BJ1, note the gap between BJ1 and 4-B2, B5.




STEP 11




✓



✗




After confirming the gap between BJ1 and 4-B2, B5, then use S3 to connect and fix.




S3
20 pcs


STEP 12






Confirm the gap between BJ1 and 4-B2.



Check the gap between the inside of two plates 4-B2.





After confirming the gap of the above accessories, fix BJ1 and 4-B2 by hand, and then connect and fix with S2.





S2
2 pcs

STEP 13

For details, see STEP 12.





Confirm the gap between BJ1 and B5.





S2
2 pcs

STEP 14

For details, see STEP 12.





Confirm the gap between BJ1 and 4-B2.





S2
2 pcs

STEP 15

For details, see STEP 12.





Confirm the gap between BJ1 and 4-B2.





S2
2 pcs

STEP 16

For details, see STEP 12.





Confirm the gap between BJ1 and B5.





S2
2 pcs

STEP 17

For details, see STEP 12.





Confirm the gap between BJ1 and 4-B2.





STEP 18

For details, see STEP 12.





Confirm the gap between BJ1 and 4-B2.





STEP 19

For details, see STEP 12.




Confirm the gap between BJ1 and B5.





 S2
2 pcs


STEP 20

For details, see STEP 12.




Confirm the gap between BJ1 and 4-B2.





 S2
2 pcs

STEP 21

For details, see STEP 12.




Confirm the gap between BJ1 and 4-B2.






S2
2 pcs


STEP 22

For details, see STEP 12.




Confirm the gap between BJ1 and B5.







S2
2 pcs

STEP 23

For details, see STEP 12.




Confirm the gap between BJ1 and 4-B3.






STEP 24

For details, see STEP 12.





Confirm the gap between BJ1 and 4-B4.




STEP 25

For details, see STEP 12.




Confirm the gap between BJ1 and B5.






S2
4 pcs


STEP 26

For details, see STEP 12.





Confirm the gap between BJ1 and 4-B6.






S2
4 pcs

STEP 27






Confirm the gap between BJ1 and B1.

STEP 28






S2
6 pcs


STEP 29




Confirm the gap between BJ1 and B1.

STEP 30





S2
6 pcs





STEP 31





STEP 32




STEP 33




STEP 34




Please install W1 and W2 first, confirm the card QQ (as shown in the figure), and then install the window.




Oblique placement




Flat forward thrust




Place W3 in the groove



Connect with S4



Place W5 in the appropriate position





Connect with S4





S4
8 pcs


STEP 35



STEP 36




STEP 37







For Front Door

S4
3 pcs


STEP 38



STEP 39







After confirming the correct position of C1 (refer to ✓ picture), connect and fix with S4.





S4
2 pcs

STEP 40




After confirming the correct position of C2 (refer to ✓ picture), connect and fix with S4.





S4
4 pcs


STEP 41





STEP 42





STEP 43





	
S5	M4
4 pcs	4 pcs

STEP 44






S4
4 pcs

STEP 45






S7
6 pcs

STEP 46





4-E2
Bend 4-E2.



STEP 47



Install E3.







Ensure that 4-E2 is centered before installing screw S4.




Hold down 4-E2 while installing screw S4.

S4
12 pcs


STEP 48




Check the gap between the inner sides of boards 4-E1 and 4-E2.



Hold down the upper roof panel while installing screw S4.





S4
4 pcs





STEP 49

For details, see STEP 48.





Hold down the upper roof panel while installing screw S4.








S4
4 pcs


STEP 50



STEP 51






Gently lift 4-E1, align 4-E4 with 4-E1, push forward, and buckle down into the wall panel



Adjust with a scraper.






STEP 52



S3
8 pcs

S4
8 pcs

STEP 53







Please check whether the buckle of E6 is fastened to the corresponding position. After confirmation, install S3 and S4.

S3
4 pcs

S4
4 pcs

STEP 54









Hold the top roof panel 4-E1 while installing the screws S4. Note that the screws S4 should also be installed in the same position on the other side of the roof panel.







S4
8 pcs

STEP 55






	
S3	S4
4 pcs	8 pcs




STEP 56




STEP 57





STEP 58




X2



STEP 59







X2






Please install S4 first and then install S3.

X4



			
S4	S3	S8	M5
8 pcs	8 pcs	2 pcs	2 pcs

STEP 60




Please align the A5 with the groove of the floor first. Confirm that the A5 is aligned with the center line of the floor, and then press A5 again.

STEP 61






S9
4 pcs




STEP 62




STEP 63




STEP 64



STEP 65




STEP 66






S4
10 pcs






STEP 67



STEP 68



STEP 69



CARE & SAFETY

- In case of fire, do not attempt to extinguish any burning polypropylene with water. Unsuitable for storage of flammable or corrosive substances.
- It is of utmost importance to assemble all of the parts according to the directions. Do not skip any step.
- Please consult your local authorities if any permits are required to erect shed.
- Periodically check shed to assure that it remains stable and that the site remains level.
- It is highly recommended to secure the shed to an immovable object or to the ground by drilling holes in the floor at the pre-marked locations and inserting proper screws into the ground (size: 1.9"-3", screws are not included).
- Wear safety-goggles and always follow the manufacturer's instructions when using power tools.
- Wash shed with garden hose or a mild detergent solution. Using a stiff brush or abrasive cleaner could damage shed.
- Hot items such as recently used grills, blowtorches, etc. must not be stored in the shed.
- Heavy articles should not be leaned against the walls, as this may cause distortion.
- Keep roof clean of snow and leaves. Heavy amounts of snow on roof can damage the shed making it unsafe to enter.
- Although wind direction varies, it is an important factor when taking into account where to place your shed. Therefore, it is recommended to reduce wind exposure of the shed in general, and the door side in particular.
- Keep doors closed and locked to prevent wind damage.
- Do not stand on the roof.