


Assembly Instructions

Dressing Table



MADE IN P.R.C.


Thank you for your purchase. All components are included in a single package. Please follow the instructions step by step for a quicker and smoother installation process. If you encounter any issues, please contact our customer service team and we will be pleased to assist you.

Before You Start


1. On the second page, check whether the accessories in the package are broken or missing parts (it is recommended to reserve space first, sort the parts with numbers in order, and sort the letters alphabetically)




2. This furniture requires 2 people to assembly. Make sure no parts are missing or damaged before assembly.



3. In order to ensure that the wooden boards and screws are not damaged, it is not recommended to use electric drills. If so, it is recommended to use low torque for installation.




4. Assemble the furniture on empty carton, carpet, or rug to prevent scratches or damage.




5. If you have any questions, please contact us (bring the part number), attach the email contact information or Amazon's customer contact method.
















6. The installation video is on the Amazon product page, and you can also scan the installation video QR code.


















Parts List















PARTS LIST

<p>①</p>  <p>1pc</p>	<p>②</p>  <p>1pc</p>	<p>③</p>  <p>1pc</p>
<p>④</p>  <p>1pc</p>	<p>⑤</p>  <p>1pc</p>	<p>⑥</p>  <p>1pc</p>
<p>⑦</p>  <p>1pc</p>	<p>⑧</p>  <p>1pc</p>	<p>⑨</p>  <p>2pcs</p>
<p>⑩</p>  <p>1pc</p>	<p>⑪</p>  <p>1pc</p>	<p>⑫</p>  <p>4pcs</p>
<p>⑬</p>  <p>4pcs</p>	<p>⑭</p>  <p>1pc</p>	<p>⑮</p>  <p>1pc</p>


PARTS LIST


<p>①⑥</p>  <p>1pc</p>	<p>①⑦</p>  <p>1pc</p>	<p>①⑧</p>  <p>1pc</p>
<p>①⑨</p>  <p>2pcs</p>	<p>②⑩</p>  <p>1pc</p>	<p>②⑪</p>  <p>1pc</p>
<p>②⑫</p>  <p>1pc</p>	<p>②⑬</p>  <p>1pc</p>	<p>②⑭</p>  <p>2pcs</p>
<p>②⑮</p>  <p>1pc</p>	<p>②⑯</p>  <p>3pcs</p>	<p>②⑰</p>  <p>3pcs</p>
<p>②⑱</p>  <p>1pc</p>	<p>②⑲</p>  <p>1pc</p>	<p>③⑰</p>  <p>1pc</p>


PARTS LIST


<p>31</p>  <p>1pc</p>	<p>32</p>  <p>1pc</p>	<p>33</p>  <p>1pc</p>
<p>34</p>  <p>1pc</p>	<p>35</p>  <p>6pcs</p>	<p>36</p>  <p>2pcs</p>
<p>37</p>  <p>3pcs</p>	<p>38</p>  <p>3pcs</p>	<p>39</p>  <p>3pcs</p>
<p>40</p>  <p>1pc</p>	<p>41</p>  <p>3pcs</p>	<p>42</p>  <p>2pcs</p>


Hardware List


(A)	X52+3
	
Ø15*9.5	


(B)	X52+3
	
Ø6.5*35	


(C)	X33+2
	
Ø8*30	


(D)	X9+1
	
Ø6*30	


(E)	X72+3
	
Ø3.5*12	


(F)	X2+1
	
Ø3*12	


(G)	X65+3
	
Ø4*35	


(H)	X4
	
45*12*1	


(I)	X26+2
	
Ø4*14	


(J)	X17+1
	
Ø6.3*50	


(K)	X4
	
120*38*17	


(L)	X1
	
109*99*38.5	


(M)	X3
	
CL	
L=300	


(M)	X3
	
DL	
L=300	


(M)	X3
	
CR	
L=300	

(M)	X3
	
DR	
L=300	









(N)	X1
	
145*55*45	

(O)	X2+1
	
Ø5*40	

(P)	X2+1
	
Ø6.3*70	





(Q)	X2set
	
Q-1 Q-2	

Hardware List




Cam Lock Fastening System


Insert the cam bolt into the hole first, then insert the cam lock and lock it.




Step 1




Note that the countersunk hole is on this surface.




Make sure the screw into the right holes.




G		x 8
	<small>Ø4*35</small>	


Step 2



Note: There are 8 countersunk holes on this surface.




Make sure the screw into the right holes.





Pay attention to the installation direction of the 24 board.

X2


G		x 16
	<small>Ø4*35</small>	


Step 3




G		x 4
	<small>Ø4*35</small>	




Step 4




G		x 4
	<small>Ø4*35</small>	


Step 5




Q	 Q-2	x 1
G	 Ø4*35	x 4
E	 Ø3.5*12	x 2

Step 6






B	 Ø6.5*35	x 3
---	---	-----

Step 7




Insert the cam bolt into the hole first, then insert the cam lock and lock it.





Ⓒ	 Ø8*30	x 2
Ⓐ	 Ø15*9.5	x 3

Step 8




Pay attention to the installation direction of Ⓐ-1 .





Ⓐ	 Ⓐ-1	x 1
Ⓔ	 Ø3.5*12	x 2

Step 9




Pay attention to the installation position of the C and D.



⊙	 Ø5*40	x 2
ⓐ	 Ø6.3*50	x 2
ⓓ	 Ø6*30	x 2
Ⓒ	 Ø8*30	x 2


Step 10





The Q-2 center hole on the 25 board is aligned with the Q-1 center protrusion on the 2 board, and then release vertically.

Step 11


Note the countersunk head on this surface.




Q	 Q-2	x 1
E	 Ø3.5*12	x 2




Step 12

Round Corner




Pay attention to the installation direction of Q-1 .




Q	 Q-1	x 1
E	 Ø3.5*12	x 2
B	 Ø6.5*35	x 2





Step 13




The Q-2 center hole on the 23 board is aligned with the Q-1 center protrusion on the 22 board, and then release vertically.



Insert the cam bolt into the hole first, then insert the cam lock and lock it.




Ⓒ	 Ø4*35	x 2
Ⓓ	 Ø6*30	x 2
Ⓒ	 Ø8*30	x 2
Ⓐ	 Ø15*9.5	x 2



Step 14





(M)	 CL 300	x 3
(E)	 Ø3.5*12	x 9


Step 15




(M)	 CR 300	x 3
(E)	 Ø3.5*12	x 9

Step 16




B		x 4
Ø6.5*35		

Step 17







Insert the cam bolt into the hole first, then insert the cam lock and lock it.




A		x 4
Ø15*9.5		

Step 18





B		x 4
Ø6.5*35		

Step 19






Insert the cam bolt into the hole first, then insert the cam lock and lock it.





A		x 4
Ø15*9.5		


Step 20




(J)	 Ø6.3*50	x 4
(C)	 Ø8*30	x 4

Step 21





(B)	 Ø6.5*35	x 8
-----	--	-----

Step 22



Note: Loosely install the screws tighten them all after assembly is complete.


X2

W	 (50/30/30)*45*2	x 4
I	 Ø4*14	x 8

Step 23




Pay attention to the installation direction of the 12 and 13 board.




Note: Loosely install the screws tighten them all after assembly is complete.


X2

I	 Ø4*14	x 8
---	--	-----


Step 24




Note: Loosely install the screws tighten them all after assembly is complete.



①		x 8
	<small>Ø4*14</small>	

Step 25





Insert the cam bolt into the hole first, then insert the cam lock and lock it.




③		x 8
	<small>Ø8*30</small>	
④		x 8
	<small>Ø15*9.5</small>	


Step 26



(P)		x 2
<small>Ø6.3*70</small>		

Step 27




(J)		x 2
<small>Ø6.3*50</small>		


WARNING

How To SEPARATE BALL BEARING SLIDE.


1) Pull toward arrow to open the slide until its stops and then flip it over.



2) Push plastic lever down and pull apart.




Cabinet Slide Rail



Drawer Slide Rail




Step 29




(R)		x 1
(E)		x 3



Step 30



(R)		x 1
(E)		x 3

Step 31





J	 Ø6.3*50	x 4
C	 Ø8*30	x 4

Step 32



Two people are needed to collaborate on this assembly step.




C		x 1
---	---	-----

Step 33




Two people are needed to collaborate on this assembly step.




T		x 4
---	---	-----

Step 34



	 Ø6.3*50	x 2
--	-------------	-----


Step 35



Pay attention to the installation direction of the 15 board.



Step 36

Round Corner





Two people are needed to collaborate on this assembly step.


Flip




Round Corner






Insert the cam bolt into the hole first, then insert the cam lock and lock it.






Proper orientation of CAM LOCK




(C)	 Ø8*30	x 4
(B)	 Ø6.5*35	x 4
(A)	 Ø15*9.5	x 4

Step 37





B	 <small>Ø6.5*35</small>	x 6
---	---	-----

Step 38






Insert the cam bolt into the hole first, then insert the cam lock and lock it.





A	 <small>Ø15*9.5</small>	x 6
---	---	-----


Step 39




G	 <small>Ø4*35</small>	x 7
D	 <small>Ø6*30</small>	x 2

Step 40







B	 <small>Ø6.5*35</small>	x 4
---	---	-----

Step 41



Pay attention to the installation position of the C、D、G and J.


Make sure the screw into the right holes.

ⓐ	 Ø6.3*50	x 3
ⓐ	 Ø4*35	x 3
ⓐ	 Ø6*30	x 3
ⓐ	 Ø8*30	x 2


Step 42





Two people are needed to collaborate on this assembly step.




Insert the cam bolt into the hole first, then insert the cam lock and lock it.







Proper orientation of CAM LOCK


C	 <small>Ø8*30</small>	x 4
A	 <small>Ø15*9.5</small>	x 4

Step 43




L	 109*99*38.5	x 1
I	 Ø4*14	x 2
H	 45*12*1	x 4
E	 Ø3.5*12	x 8

Step 44





(Y)		x1set
(N)	 145*55*45	x 1
(F)	 Ø3*12	x 2


Step 45




Insert the plastic buckle into the back plate slot , screw through the hole in the plastic buckle and lock it in place.

U	 Ø3*14	x 18
S		x 1

Step 46




G	 Ø4*35	x 4
---	--	-----



Step 47




Pay attention to the installation direction of the 40 board.




Step 48





B	 <small>Ø6.5*35</small>	x 4
---	---	-----

Step 49






Insert the cam bolt into the hole first, then insert the cam lock and lock it.




A	 <small>Ø15*9.5</small>	x 4
---	---	-----




Step 50




(K)	 120*38*17	x 1
(E)	 Ø3.5*12	x 2

Step 51




(M)	 DR 300	x 1
(M)	 DL 300	x 1
(E)	 Ø3.5*12	x 6


Step 52



X2



G	 Ø4*35	x 8
---	---	-----

Step 53




X2


Step 54




X2

Ⓑ		x 8
Ø6.5*35		


Step 55




Insert the cam bolt into the hole first, then insert the cam lock and lock it.





X2

Ⓐ		x 8
Ø15*9.5		


Step 56






X2

(K)	 120*38*17	x 2
(E)	 Ø3.5*12	x 4


Step 57




X2


(M)	 DR 300	x 2
(M)	 DL 300	x 2
(E)	 Ø3.5*12	x 12

Step 58






G	 Ø4*35	x 4
---	--	-----

Step 59




Step 60




G	 <small>Ø4*35</small>	x 1
---	---	-----


Step 61




Insert the cam bolt into the hole first, then insert the cam lock and lock it.



Step 62




Step 63






Place (35) boards according to customer requirements.

Step 64






Insert the cam bolt into the hole first, then insert the cam lock and lock it.




(B)	 Ø6.5*35	x 5
(A)	 Ø15*9.5	x 5



Step 65





(K)	 120*38*17	x 1
(E)	 Ø3.5*12	x 2

Step 66




(R)		x1set
(E)	 Ø3.5*12	x 6

Step 67




Push the iron plate with steel balls to the outermost position and then install the drawer.



Cabinet Slide

Drawer Slide

Cabinet Slide




Drawer Slide

Push the slide rails on both sides of the drawer into the grooves of the slide rails on the table top, keeping both sides pushed in simultaneously. Do not allow the drawer to tip to the left or right as it enters, if there is serious jamming during the pushing process, do not force it in.

V	 191*40(φ5)	x 12
---	----------------	------

Step 68




We have included a set of tipping restraint hardware for this unit. You must install this hardware to prevent accidents or injuries that can result from the unit falling. When properly installed, this restraint can provide protection against the unexpected tipping of the unit due to small tremors, bumps or climbing. We strongly recommend mounting this hardware to a wall stud and your unit.


NOTE: The tipping restraint hardware included is for wooden stud wall construction. It must be attached to a wall stud. Depending upon your wall construction different anchor hardware may be required. Please contact your local hardware store for assistance. Young children can be seriously injured by tipping furniture. You must install the tipping restraint hardware with the unit to prevent the unit from tipping, causing any accidents or damage. The tipping restraints are intended only as a deterrent and are not a substitute for proper adult supervision. The tipping restraints are not earthquake restraints. If you wish to add the extra security of earthquake restraints, they must be purchased and installed separately.




Install the tipping restraint hardware



- 1. make mark on the wall
- 2. drill two Ø8 holes on the wall
- 3. put two anchors in the holes



4. fix the device on the wall by the long screws



5. Push the cabinet close to the wall so that the two bases are close to each other, and then put on nylon tie to tighten it.

