



**EN\_IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY.**


**USING CAM LOCK AND QUICKFIT**




**EN\_QUICKFIT:** Tighten quickfit until shoulder is flush with panel. Do not overtighten or undertighten.



**EN\_CAM LOCK:** When fitting cam lock, ensure starting position is correct before you insert connecting quickfit.

















**EN\_Quickfit** head should be in the centre of the cam lock when the two panels are joined.  
Cam lock should be inserted before quickfit.























**EN\_Turn** cam lock clockwise to tighten.



PACKING DELALS

NO.	PARTS	QTY	SPARE
①		x1	
②		x1	
③		x1	
④		x2	
⑤		x1	
⑥		x4	
⑦		x1	
⑧		x1	
⑨		x5	
⑩		x5	

NO.	PARTS	QTY	SPARE
⑪		x5	
⑫		x5	
⑬		x5	
⑭		x5	




<p><b>A</b> x45 Ø6x35mm +3(spare)</p> 	<p><b>B</b> x45 Ø15x10mm +3(spare)</p> 	<p><b>C</b> x40 Ø6x30mm +3(spare)</p> 	<p><b>D</b> x25 Ø4x35mm +2(spare)</p> 	<p><b>E</b> x60 Ø3.5x12mm +3(spare)</p> 	<p><b>F</b> x10 Ø3x16mm +1(spare)</p>   <p>F-1 F-2</p>
<p><b>G</b> x2</p>   <p>G-1 G-2</p>	<p><b>H</b> x10</p>   <p>H-1 H-2</p>	<p><b>I</b> x2 Ø4x14mm</p>   <p>I-1 I-2</p>	<p><b>J</b> x4</p> 	<p><b>CL</b> x5 L350mm</p> 	<p><b>CR</b> x5 L350mm</p> 
<p><b>DL</b> x5 L350mm</p> 	<p><b>DR</b> x5 L350mm</p> 				




**x5**

A x25



02



x5


B x25



C x20



03





x5

E x30

DL x5

DR x5




x5

H x10



H-1




H-2



x5




CL x5

E x15





CR x5

E x15




A x14

J x4



B x7


C x7




B x7

C x7



10



11





A x6



B x6



C x6





F x10





F-1






F-2






G x2


I x2





First fix the anti-rewind screw in the reserved hole of the product.




Then, put the expansion bolt into the hole



then, use a ruler to measure the approximate height of the product on the wall, and then mark it with a pen.



Then use a tape drill to make holes in the wall that are suitable for the product screws.



WALL

