

























Bookcase









READ AND SAVE THIS INSTRUCTIONS FORE USE

# ASSEMBLY&INSTRUCTION MANUAL




<b>A</b>  X43+2	<b>B</b> M8X30  X34+2	<b>C</b>  X8set+1	<b>D</b> M3.5X12  X16+1	<b>E</b> M4X35  X8+1	<b>F</b>  X4+1	<b>G</b>  X4
<b>H</b>  X2	<b>I</b>  X4	<b>J</b>  X43+2	<b>K</b>  X2set			

<p>①</p>  <p>1070*249mm</p>	<p>②</p>  <p>1070*249mm</p>	<p>③</p>  <p>700*249mm</p>
<p>④</p>  <p>700*249mm</p>	<p>⑤</p>  <p>700*250mm</p>	<p>⑥</p> <p>one side</p>  <p>the other side</p> <p>700*250mm</p>
<p>⑦</p> <p>one side</p>  <p>the other side</p> <p>668*248mm</p>	<p>⑧</p> <p>one side</p>  <p>the other side</p> <p>668*248mm</p>	<p>⑨</p> <p>X2</p>  <p>400*228mm</p>
<p>⑩</p>  <p>298*226mm</p>	<p>⑪</p> <p>one side</p>  <p>the other side</p> <p>668*248mm</p>	<p>⑫</p>  <p>668*45mm</p>


<div> <div>⑬</div> <div>  </div> <div>X2</div> <div>662*180mm</div> </div>	<div> <div>⑭</div> <div>  </div> <div>X2</div> <div>200*150mm</div> </div>	<div> <div>⑮</div> <div>  </div> <div>X2</div> <div>200*150mm</div> </div>
<div> <div>⑯</div> <div>  </div> <div>X2</div> <div>619*150mm</div> </div>	<div> <div>⑰</div> <div>  </div> <div>X2</div> <div>628*198mm</div> </div>	<div> <div>⑱</div> <div>  </div> <div>X2</div> <div>678*330mm</div> </div>
<div> <div>⑲</div> <div>  </div> <div>678*410mm</div> </div>	<div> <div>⑳</div> <div>  </div> <div>654*339mm</div> </div>	

## CAM BOLT INSTALLATION AS BELOW:




## STEP1

X4





Push plastic lever down and pull apart.

## STEP2




A1	x8




## STEP3




A1	x4	A2	x4	B	x4	J	x4




## STEP4







A2	X4	B	X4	J	X4
					

## STEP5



A2	X4	B	X4	J	X4
					


## STEP6



A1 X16



## STEP7



A2 X4



B X4




J X4







## STEP8




## STEP9




## STEP10




## STEP11



## STEP12




## STEP13




## STEP14

# X2




## STEP15

# X2



## STEP 16









NOTE: You need to push inner rail steel ball to the front before installing the drawer!

F	X4	H	X2	I	X4

# STEP17

**NOTE:** The tipping restraint hardware included is for wooden stud wall construction. It must be attached to a wall stud. Depending upon your wall construction different anchor hardware may be required. Please contact your local hardware store for assistance. Young children can be seriously injured by tipping furniture. You must install the tipping restraint hardware with the unit to prevent the unit from tipping, causing any accidents or damage. The tipping restraints are intended only as a deterrent and are not a substitute for proper adult supervision. The tipping restraints are not earthquake restraints. If you wish to add the extra security of earthquake restraints, they must be purchased and installed separately.



# STEP18

