



CAUTION

- Inspect the wire insulation for any cuts, abrasions, or exposed copper that may have resulted during shipping. If there is a defect in the wire, do not attempt installation.
- Before starting installation of this fixture or removal of a previous fixture, disconnect the power by turning off the circuit breaker or by removing the fuse at the fuse box.

TOOLS REQUIRED






*PARTS SHOWN MAY DIFFER SLIGHTLY PER LIGHT FIXTURE


STEP 1

Screw the rods to the . Make sure to feed the branchwires of the through the during assembly. Remove or add rods to adjust the height. Secure the shade to the fixtur using the socket ring.



STEP 2

Use the mounting screws to attach themounting unitto the junction box



STEP 3

Make the electrical connection from the junction box .


Connect the ground wire to the mounting unit using the preinstalled green ground screw. Then, connect the positive, negative and ground wires with the supplied wire nuts. Secure with electrical tape


Connect Clear, Brown, Gold or Black Parallel Wire without tracer (round & smooth) or Black Fixture Wire to:

Black or Red Supply Wire or Insulated Wire (other than green) with copper conductor.

Connect Clear, Brown, Gold or Black *Parallel Wire with tracer (square & ridged) or White Fixture Wire to:

White Supply Wire or Insulated Wire (other than green) with silver conductor





STEP 4 Place the canopy over the mounting unit and secure the fixture with the cap nuts

