



Installation Instruction




Assembling

What you need

- Use the packaging carton as a working surface to prevent product damage during assembly
- Phillips head screwdriver



Weight Limitation




What' included

Code	Description	Qty
A	Cam Bolt M6X35MM	15
B	Cam Lock 15X10MM	15
C	Wooden Dowel M8X30MM	12
D	Screw M4X40MM	2
E	Screw M3.5X14MM	30
F	Shelf Holder	5
G	The screw M6X25MM	9
H	Shelf Holder	3
I	Cam Bolt M4X8MM	4
J	Metal shake handhandle	2
K	Hex key M4X55MM	1
L	MATS	11
M	The screw M6X35MM	4
N	Self-adhesive hole sticker	15
O	The metal plate	3
P	The screw M6X12MM	12

The Hardwares


A




B



C



D



E




F



G




H



I



J



K



L




M



N



O



P




IMPORTANT:

1. Do not tighten bolts / screws completely until all bolts / screws are lined up and inserted into holes.
2. Do not over tighten screws and bolts to avoid stripping
3. You can use a screwdriver. Power tools can also be used. (Be careful with power tools)


Included Accessories

Code	Description	Qty
1	Left panel	1
2	Left bottom plate	1
3	Vertical diaphragm	1
4	Diaphragm plate	1
5	Right panel	1
6	Right bottom plate	1
7	Left sliding door	1
8	Movable laminate	1
9	Right coaming panel	2
10	Solid wood feet	3
11	Metal support pipe	3
12	Metal joint pipe	2
13	Upper semicircular metal frame	1
14	Lower semicircular metal frame	1


The Accessoriess





Step 1




Step 2





Step 5

E	×12	O	×3
			



Step 6

C	×2
	




Step 7





K	×1

M	×4


P	×12



Note that the screw (M) should be locked to 100%





Pay attention to screw (P) do not lock lock to 90 percent




Step 8

G	×5


K	×1



Pay attention to screw (G) do not lock lock to 90 percent




Step 9





Note that in this step, all screws are 100% locked, and the hardware (P) and (G) of steps 7 and 8 are also 100% locked in this step


Step 10



Note the placement of hardware (F)



Step 11


C	×4	F	×1
			




Note that the No. ⑧ removable layer can be shared from side to side, and if the other side is required to place the No. ⑧ removable layer, the hardware (F) must be installed on the other side

Step 12


I	×4	J	×2
			



Step 13






Step 14




Note that when assembling the No. ⑦ arc sliding door, align the grooves of the No. ① and No. ② panels. If necessary, gently tap the No. ⑦ arc sliding door to make it fall into the grooves


Step 15

E	×6	H	×3
			









Step 16-1

E	×12
	



Step 16-2

How do I get the two doors to align flat by adjusting the hinges?




1. The screws can be loosened to adjust the uneven problem under the table top.

2. Adjust the screws shown in Fig. 2 and pull the door back and forth so that it can be opened smoothly.






3. Adjust the screws shown in Figure 3 to adjust the door left and right to the right position.

Step 17



Place the No. ⑨ plate neatly on the Velcro of the No. ⑬ metal semicircle and the No. ⑭ metal semicircle (Note: Please stretch the No. ⑨ plate completely and tighten along the magic so as not to have gaps that affect the appearance. If there are any noticeable gaps, tear them off and re-paste.)

Step 18



Two people work together to move the table.
Make sure you lift it off the ground.
Don't push and pull.