









Bistro Table



PART LIST

<div style="border: 1px solid black; padding: 2px; width: 20px; float: left; margin-right: 5px;">A</div> 	<div style="border: 1px solid black; padding: 2px; width: 20px; float: left; margin-right: 5px;">B</div> 
<p>Support Leg 4 PCS</p>	<p>Table Top 1 PC</p>


HARDWARE LIST




<div style="border: 1px solid black; padding: 2px; width: 20px; float: left; margin-right: 5px;">#1</div>  <p>(7.8*80mm)</p>	<div style="border: 1px solid black; padding: 2px; width: 20px; float: left; margin-right: 5px;">#2</div> 	<div style="border: 1px solid black; padding: 2px; width: 20px; float: left; margin-right: 5px;">#3</div> 	<div style="border: 1px solid black; padding: 2px; width: 20px; float: left; margin-right: 5px;">#4</div> 	<div style="border: 1px solid black; padding: 2px; width: 20px; float: left; margin-right: 5px;">#5</div> 
<p>"+" Bolt 2 PCS</p>	<p>Nut 8 PCS (Extra 1)</p>	<p>Washer 8 PCS (Extra 1)</p>	<p>Tube Cap 4 PCS</p>	<p>Wrench 4 PCS</p>

IMPORTANT NOTE: WE RECOMMEND AT LEAST TWO PEOPLE WORK TOGETHER TO ASSEMBLE UNIT.

Step 1. Lay table top (part B) upside down on a soft flat surface, such as carpet. Attach one support leg (part A) to another support leg (part A) using "+" bolts (part #1), nuts (part #2) and washers (part #3).


NOTE: Please do not fully tighten bolts until unit is fully assembled.







- | | | |
|----|---|-----|
| #1 |  | X 2 |
| #2 |  | X 4 |
| #3 |  | X 4 |

Step 2. Attach remaining support legs (part A) to assembled unit (parts A & B) using nuts (part #2), washers (part #3) and wrench (part #5). Add tube caps (part #4) to support legs (part A).

NOTE: Please full tighten all bolts at this time.



- | | | |
|----|---|-----|
| #2 |  | X 4 |
| #3 |  | X 4 |
| #4 |  | X 4 |
| #5 |  | X 1 |

Step 3. Carefully turn assembled unit upright.

