


## Installation Instruction

Please don't tighten the screws completely and go back later for a final tightening of all the screws after pieces are aligned with each other.




MADE IN CHINA







P3/21




P4/21







P6/21





P7/21







P9/21









P11/21





P12/21






Note: First, insert the thin edges of the fitting "H1" into the four corners of the rear panel, then tighten them firmly with the screws "H2".







P16/21

