
Assembly Instructions




Before Assembly

Tips Before Your Start:


- Remove all wrapping material, including staples & packing straps before you start to assemble.
- DO NOT tighten all screws and bolts until the assembly is completely assembled.
- Keep all hardware parts out of reach of children.

QUICKFIT



Tighten quickfit until shoulder is flush with panel. Do not overtighten or undertighten.


CAM LOCK




When fitting a cam lock, ensure the starting position is correct before inserting the connecting QUI CKFIT

Quickfit head should be in the centre of the cam lock when the two panels are joined.

Cam lock should be inserted before quickfit.






Turn cam lock clockwise to tighten.

Before Assembly

Tips Before Your Start


How to separate the drawer slider:






2. Pull out the inner slider for drawer box fixing

Drawer Front Alignment



If the drawer front panel is NOT level after being assembled, then...



Loosen the screws on the left and right hand side, then adj ust the drawer slide up or down, untill the drawer fronts are even/level, then tighten the screws.

Part List

No. A Quantity:20 Pcs Cam Lock Dowel 8*28mm



No. B Quantity:20 Pcs Cam Ø15



No. C Quantity:20 Pcs Sticker Ø20



No. D Quantity:6 Pcs Dowel 8*30mm



No. E Quantity:2 Pcs Handle 200*20mm



No. F Quantity:8 Pcs Screw M4*30mm



No. G Quantity:16 Pcs Screw M3.5*14mm



No. H Quantity:2 Sets Drawer Slider 10"



No. I Quantity:5 Pcs Foot Pad Ø20



No. J Quantity:2 Pcs Screw M6*35mm



No. K Quantity:2 Pcs Screw M6*55mm



No. L Quantity:2 Pcs Screw M6*35mm



No. M Quantity:16 Pcs Screw M6*40mm



No. N Quantity:1 Pcs Allen Key 4#




No. O Quantity:4 Pcs Screw M4*14mm




No. P Quantity:1 Sets Anti-falling Parts



Product structure





No. A Quantity: 8 Pcs 8*28 mm




No. J Quantity: 2 Pcs M6*35mm




STEP 2



The first screw hole should corresponded with the board location hole






No. H Quantity: 2 Sets 10"



No. G Quantity: 8 Pcs M3.5*14mm






No. B

Quantity: 4 Pcs

Ø15




STEP 4



No. A Quantity: 2 Pcs 8*28 mm






No. B Quantity: 2 Pcs Ø15




No. D Quantity: 1 Pcs 8*30mm

STEP 6



No. A Quantity: 2 Pcs 8*28 mm






No. B Quantity: 2 Pcs Ø15




No. D Quantity: 1 Pcs 8*30mm


STEP 8



No. K Quantity: 2 Pcs M6*55mm




STEP 10



No. B Quantity: 4 Pcs Ø15






No. M Quantity: 8 Pcs M6*40mm



No. N Quantity: 1 Pcs 4#


STEP 12



No. O Quantity: 4 Pcs M4*14mm



Page 10 of 16



No. D Quantity: 4 Pcs 8*30mm




No. M Quantity: 8 Pcs M6*40mm



No. N Quantity: 1 Pcs 4#


STEP 14




No. L Quantity: 2 Pcs M6*35mm



No. N Quantity: 1 Pcs 4#




STEP 16



No. I Quantity: 5 Pcs Ø20






×2


No. A Quantity: 8 Pcs 8*28 mm



STEP 18



No. F Quantity: 8 Pcs M4*30mm



No. B

Quantity: 8 Pcs


Ø15



STEP 20



The first screw hole should corresponded with the board location hole




×2

No. H Quantity: 2 Sets 10"



No. G Quantity: 8 Pcs M3.5*14mm





STEP 22

