


8x8 Cornershed



Let's get started...



Important information...

Safety	02
Base and positioning	03
Warranty	
Before you start	04
Care maintenance & Recycling	05

In more detail...

Parts List	06
Hardware chart	07
Detailed Technical Drawing	08
Assembly instructions	12-23

EN	For a copy of the instructions or a copy in another language please send an email or write to the address below.
F	Pour obtenir un exemplaire des instructions ou une copie dans une autre langue s'il vous plaît envoyez un e-mail ou écrire à l'adresse ci-dessous.
PL	Na kopii instrukcji lub kopii w innym języku prosimy o wysłanie maila lub pisać na adres podany poniżej.
RUS	Для получения копии инструкции или копия на другом языке, пожалуйста, отправьте по электронной почте или написать по указанному ниже адресу.
TR	Başka bir dilde talimatları veya bir kopyasını bir kopyası için bir e-posta gönderebilir veya aşağıdaki adrese yazınız.

These instructions are for your safety. Please read through them thoroughly before use .
PLEASE KEEP THIS BOOKLET FOR FUTURE REFERENCE

Check that you have noted all the following instructions



- ☒ We advise the use of non slip protective gloves throughout the assembly process.
- ☒ We advise the use of steel capped protective footwear throughout the assembly process
- ☒ We advise that you use a helper to hold the glass in position whilst you nail the beading in place
- ☒ We advise the use of protective headwear and safety goggles throughout the assembly process
- ☒ Where a ladder is in use another person must hold the ladder.
- ☒ Do not attempt to work in windy conditions
- ☒ We advise the use of a scaffold tower when fitting the roof , for felting or if you cannot reach from the ground.
- ☒ Do not allow children near the tools and work area
- ☒ Follow any safety precautions quoted by the manufacturer for any equipment you use
- ☒ Check all parts before assembly
- ☒ Only use child and animal safe wood preservative
- ☒ Do not use creosote
- ☒ Allow the wood preservative to fully dry before use
- ☒ Regularly check the building for wear and tear

Important!



EVERY PRECAUTION IS TAKEN TO ENSURE THAT YOUR BUILDING HAS NO ELEMENT INCORRECTLY PLACED OR POSSIBLY HAZARDOUS, HOWEVER PRIOR TO USE PLEASE CHECK ALL SURFACES FOR THE FOLLOWING:

- (1) RAISED GRAIN, SPLINTERS: Sand down timber to smooth finish
- (2) NAIL/SCREW/PIN HEADS PROUD: Tap home to be flush with surface of timber
- (3) DAMAGED SCREW HEADS RESULTING IN SHARP SPLINTERS OF METAL: Replace
- (4) SHARP ENDS OF NAILS/ SCREWS/ PINS PROTRUDING THROUGH THE PANEL: Remove and reposition.
- (5) ENSURE ALL PARTS ARE SECURED AGAINST REASONABLE FORCE: Remove and refit
- (6) ENSURE THERE ARE NO LOOSE PARTS: Remove and refit/discard



IMPORTANT ! For your safety please read carefully the safety warnings

Preparation of base...

We recommend that the base onto which your building will stand should be at least 75mm larger in each direction than the total floor size of the building.

Actual floor area of the building: 2248mm x 2248mm

Total height clearance: 2140mm

The chosen position in your garden for the siting of the building should be excavated to a depth of 75mm to allow a base of sand, on to which paving slabs can be evenly laid.

You may also use an adjustable timber base or a concrete base. Whatever base you decide upon IT MUST BE LEVEL AND FIRM.


Warranty...

Things to check before you start

- ☒ Ensure your base is ready– See page 3
- ☒ Check all parts as listed in the parts lists
- ☒ Read the instructions fully before starting work
- ☒ Follow all the health and safety guidelines



When you see the drill icon
Only ever drill through the first piece of framework which will be a pilot hole for the screw to attach the second piece of framework
The required drill bit size is shown with the icon.



You will need



• Hammer



• Spirit level




• Ladder



• 1mm, 3mm & 6mm drill bit



• Drill



• Tape measure or Ruler




• Sand paper



• Gloves



• Saw




• Pencil



• Goggles



• Chisel



• A helper for some tasks



• Screwdriver



• Sharp knife

The 5 golden rules of care

- (1) Ensure your base is level and firm
- (2) Ensure the building is not sitting directly on the ground using damp proof membrane or the optional timber base.
- (3) Ensure every piece of timber and surface, especially that which will be hidden upon assembly is treated with a top quality wood preservative at least twice (see note on pressure treated buildings in warranty section)
- (4) Garden buildings are not waterproof we recommend you seal between all the panels with a silicone based sealant .
- (5) Regularly check your roofing felt for weather damage and leaks

The 7 golden rules of maintenance

- (1) Re apply the timber treatment annually. (see note on pressure treated buildings in warranty section)
- (2) Visually check for weather damage
- (3) Check and replace if necessary any Silicone sealant if used on your building.
- (4) Check the roofing material for wear
- (5) The doors and windows may require periodical adjustment
- (6) Ensure your building is well ventilated especially during hot weather
- (7) During extremely hot periods humidify your building to prevent the timber from drying out .and shrinking

Recycling and disposal



packaging





























1. Pallet and timber widely recycled
2. Cardboard widely recycled
3. Plastic strapping subject to local regulations
4. Plastic sheeting subject to local regulations



Building

1. Timber widely recycled
2. Metal fixings widely recycled
3. Glass widely recycled
4. Roofing felt not currently recycled


Parts ListNot to scale

Double Doors (A1329) x1pair  1700mm 676mm each	Tee Hinge (TEE) x6 	Window Hinge (STH) x4 	Window Insert (WI3) x02  821mm 821mm	Casement set (CS-AL) x02 	Window Panel LH (WP117-LH) x01  2010mm 1190mm
Window Panel RH (WP117-RH) x01  2010mm 1190mm	Floor panels (FP-114) x01  1058mm 1190mm 2248mm	Plain Panel (PP25) x04  1930mm 1089mm	44s framework Square corner post (44s-1930) x01  44mm 44mm 1930mm	Angled door post (78R-2010-45) x02  2010mm 78mm 44mm	44D framework Door step (44D-1360) x01  25mm 44mm 1360mm
Gable Panel; (A1318) x01  1360mm 341mm	44s framework Truss block (44s-150) x02  44mm 44mm 150mm	Pad Bolt (PB) x01 	Cover strips (44C-1940) x04  12mm 44mm 1940mm	Door barrel bolt (DB) x02 	Cover strips (44C-680) x01  12mm 44mm 680mm
Cover strips (44C-710) x01  12mm 44mm 710mm	Cover strips (44C-1696) x03  12mm 44mm 1696mm	44s framework Truss (44s-2335) x01  44mm 44mm 2335mm	Front LH Roof panel From inside looking forward (RP103-LH-F) x01  809m 759m	Front RH Roof panel From inside looking forward (RP103-RH-F) x01  809m 759m	
Back LH Roof panel From inside looking forward (RP103-LH-B) x01  1546m 759m	Back RH Roof panel From inside looking forward (RP103-RH-B) x01  1546m 759m	LH Roof panel From inside looking forward (RP104-LH) x01  1293mm 1290mm	RH Roof panel From inside looking forward (RP104-RH) x01  1293mm 1290mm	Felt strips (FLTs-3.7m) x02 (FLTs-2.1m) x01 	

Profiled cover strip
(34C-1990 x02




Fascia
(70FC-1300) x02
(70FC-800) x02




Diamond
(DI) x01



Glazing
(GL355-355) x8




Beading
(8.5B-357) x32




Felt Nail
(13mm FN) x150




Panel Pin
(16mm PP) x64




Round head nail
(40mm RH) x55




Posi-drive screw
(25mm) x110




Posi-drive screw
(40mm) x18



Posi-drive screw
(60mm) x62




Posi-drive screw
(80mm) x06




Hardware Chart
Scale 1:1


Detailed Technical drawing 1:20




**Window
Internal view**



**Doors
Internal view**



In more detail.....




Assembly

GB-IE Position the hinges so the framework on the back forms a diamond.
Attach the "TEE" hinges to the doors keeping them over the door framework


01





Doors
(A1329)x01 pair



Tee hinge
(TEE)x06




Screw
(25mm)x24



GB-IE Try the window in position in the panel to check that you have it the correct way around.
The hinges fit the top of the window.


02





Window insert
(WI3) x02



Hinge
(STH)x04



Screw
(25mm)x08




GB-IE Position the window insert in the aperture and screw the inner screw holes that are just visible first.
Open the window and insert the remaining screws.

03




STEP 2
x02



Window panels
(WP117) x1 lh 1 rh



Screw
(25mm)x20



GB-IE Casement stay and pins must fit together loosely.
Fix the casement stay to the window insert first.
Then mark and fix the pins .


04




Step 3
x02



Casement set
(CS-AL) x01



Screw
(25mm)x12




GB-IE Stand both floor panels on edge, drill one floor panel and screw them together.
Lay your floors in position on your base.





05



Floor
(FP114) x01 pair



Screw
(60mm)x04




GB-IE Attach the plain panel "PP25" to the post "44S-1930" so the post is flush with the framework and the face of the cladding. At the bottom the post is flush with the framework.


06






Plain panel
(PP25 x01)



Corner post
(44S-1930) x01




Screw
(60mm)x03




GB-IE Add two more plain panels "PP25". This will leave a 34mm step on both corners to the edge of the floor.


08



Plain panel
(PP25 x02)



Screw
(60mm)x06




GB-IE Place the panel from step 3 in the corner. Position & fix another "PP25" plain panel against the post as above so the post overhangs the floor and is not seen from inside the building.


07



Plain panel
(PP25 x01)



Screw
(60mm)x03




GB-IE Position and fix the two window panels, the panels will be flush with the corners. Drill 3 holes per window panel to fix the step 10 "78R-2010-45" angled posts


09



Window panel
(WP117) x LH & RH



Screw
(60mm)x06




14


15

GB-IE Place one Angled door post '78R-2010' at the edge of one window panel. The wider part of the post should be flush to the front of the window panel and the sawn edge should rest against the window panel. The post should rest on the floor, but will overhang the floor slightly. Drill/screw into position through the panel framework into the post using 3x 60 mm screws. Repeat at other side.




10




Angled door post
(78R-2010-45) x02



Screw
(60mm)x06




**SEE PAGE
10**



GB-IE Pre drill the door step "44D-1360" and the "A1318" before positioning
Also fix a truss block to the gable with 2 x 80mm screws
Fix the door step "44D-1360" on the floor between and flush with the posts from the previous step over-
hanging the front of the floor with 60mm screws.
It should be central to the floor and it may be necessary to adjust the position wall panels to line up
everything correctly. Fix the gable panel "GP05" level with the top of the posts with 60mm screws.

11




Door step
(44D-1360)x01







Gable Panel
(A13185)x01



Screws
(60mm)x07
(80mm)x2




Truss block
(44S-150)x01




GB-IE Screw all the panels to the floor with 2 60mm screws each.

12



Screws
(60mm)x12




GB-IE Fix both doors leaving an even gap top and bottom with 1 x 25mm screw at first to the angled posts
at each of the hinges
Adjust the door if necessary and fit the remaining screws
Primary door opening first Secondary door to be bolted on the inside


13



Doors
(A1329)x01 pair




Screw
(25mm)x18




GB-IE Fix the main part of the pad bolt "PB" so it is over the framework on the back of the opening door.
Fix the other part to the door that will be bolted from the inside


14



Pad bolt
(PB) x01



Screw
(25mm)x06




16

17


GB-IE Mark a cover strip either side of the pad bolt, cut, over lap the other door and only screw it to the door that opens first (primary door)

GB-IE Position the cover strips so they overlap the doors and the posts either side and screw to the posts with 5 x40mm screws each.




15




Cover strip
(44C-1726) x01




Screw
(25mm)x10





18



Cover strip
(44C-1696) x02




Screw
(40mm)x10




GB-IE Fix a bolt at the top and bottom of the secondary door, Extend the bolt and fix the keep to the adjoining framework.

GB-IE On the inside back corner fit a truss block 78mm down from the top with 2x 80 mm screws. Position the truss on this block and the one fitted in step 8 to the gable Pre drill the truss and fix with 2x80mm screws. The truss will sit 34mm below the top of the panels (for the roof frame work to sit on top).




16




Door barrel bolt
(DB)x02




Screw
(25mm)x12




19






Truss block
(44S-150)x01



Truss
(44S-2335)x01




Screw
(80mm) x04




GB-IE There are two cover strips for the top of the inside. The "44C-710" strip goes over the opening door. Position the strips so they overlap the doors and screw to the gable framework with 4 screws each.



17



Cover strip
(44C-680 & 710) x01



Screw
(40mm)x08



18

19

GB-IE When joining the roof panels "RP103" together ensure the chamfered corners are positioned correctly.

20



Front LH Roof panel
(RP103-LH-F) x01



Front RH Roof panel
(RP103-RH-F) x01




Back LH Roof panel
(RP103-LH-B) x01



Back RH Roof panel
(RP103-RH-B) x01




Screw



GB-IE Pre drill the roof panels only ready for fixing together when in position on the building.

21




Assembly step



Roof Panel
(RP104 RH)x01







Roof panel
(RP104-LH)x01




Front

GB-IE Place the roof panels into position without fixing at this stage as it may be necessary to make adjustments to get the best fit


22



Screw
(60mm)x11



Nail
(40mm) x16




GB-IE Carefully screw the panels together using the pre drilled holes and also use 3 screws to fix to the gable. Nail through the roof panels into the top of the walls.

21


20

GB- Position all the felt, starting from the back, without fixing first to ensure you have an even overlap and at least 50mm to fold over the roof edgings and trim later .
Once you are happy with the positioning nail on top of the felt near the edge approximately 75mm apart.
Fold down the excess over the roof edgings fix as above and trim off the excess felt level with the bottom of the roof edging.

23




Felt strips
(FLTs-3.7m) x02
(FLTs-2.1m) x01







Felt Nail
(13mm) x150



Reverse view




Reverse view




GB-IE Fit cover strips at each corner with 4 nails each


24



Cover strip
(44C-1190) x04




Cover strip
(34C-1990) x02



Nail
(40mm) x24



34C-1990



GB-IE Fix the fascias to the window panel first and then the gable with 3 nails each.
Fix the diamond over the fascia join with 3 nails


25




Fascia
(70FC-1300) x02
(70FC-800) x02



Diamond
(D1) x01




Nail
(40mm) x15




GB-IE Remove the protective film from both sides of the glazing material before fitting.
Nail the beading at approximately 100mm spacing
Danger of cutting We advise you that a helper should hold the glass in position whilst you nail the beading. Wear gloves, suitable clothing and shoes,




26




Beading
(8.5B-377)X32



Glazing
((GL-355-355)) x08



Panel pin
(PP 16mm) x64



Glass
Danger of cutting

22

23