



1. Remove the two 75" bars. These will be the left and right siderails. Lay them flat on the floor.


Note: The bars should lay flat on the floor and look like L's facing each other as shown below



2. Take one of the cross bars with the 3 legs riveted on them. Take one and bolt it to the siderails as pictured. Repeat for all 3 cross arms



3. Install the black glides/feet as shown.



4. Bolt on the short cross bar with the gray glide



5. If you are using a headboard, find the headboard mounting brackets. They can be used as either left or right. Pick a set of the round holes that look like the right height for the headboard mounting holes. Loosely attach the brackets to the frame and see if you have selected the proper holes. Once you have selected the proper holes, tighten the brackets.

The brackets can be turned in or out, or one can be turned in and one out. Whatever configuration you need to securely attach the headboard. You can then mount the headboard using the hardware provided.

If you do not have a headboard, you should have black end caps on all 4 corners. When you put the foundation or box spring on the frame, center it over the frame.



6. If you do not have a headboard, you should have black end caps on all four corners. When you put the foundation or box spring on the frame, center it over the frame. This should leave you with a 5" overhang on the head and foot end on a Queen or King and 2 1/2" overhang on Full.