

## 2 Piece Nesting Coffee Table Set

### ASSEMBLY INSTRUCTIONS

#### **Before You Begin:**

Please identify all component parts and hardware pieces required before you begin. Carefully remove all of the components from the packaging and set aside for assembly. Assemble on a soft surface to prevent scratching during assembly.

#### **Caution:**

Tighten all components securely before use. Failure to do so may result in personal injury.

DO NOT use any sharp objects to open plastic wrapped components as damage to product or components may result.

#### **Warning:**

**CHOKING HAZARD** - Small Parts. Adult Assembly Required.

#### **DO NOT ALLOW CHILDREN TO CLIMB ON FURNITURE**

Serious or fatal injuries can occur from furniture tipping over. You must install Tipping Restraint Hardware (where included) to help prevent the unit from tipping and causing accidental injury, instability, death or damage. The tipping restraint is intended only as a safety measure, it is not a substitute for proper adult supervision.

To help prevent furniture from tipping over it must be permanently attached to the wall. Anti-Tip Safety Wall Straps suitable for the unit weight and wall materials (if not included) should be purchased and installed.

Online Assembly Instructions: <http://ftp.flashfurniture.com/AssemblyInstructions/NAN-JH-17145-GG.pdf>

Customer Service Email: [CustomerExperience@belnick.com](mailto:CustomerExperience@belnick.com) | Phone: 866-552-2810

NAN-JH-17145-GG

## **Have a Question/Concern?**

Quality products and first-class customer service are the cornerstone of long-lasting consumer relationships. We strive toward excellence in all we do and want you to be completely satisfied with your purchase.

**Please contact our exceptional Customer Experience Agents at the email address or phone number shown below to assist you with any product questions or issues before requesting a return.**

We look forward to serving you in a friendly, efficient manner to resolve any issues you may have.

**Customer Service Email: [CustomerExperience@belnick.com](mailto:CustomerExperience@belnick.com)**

**Customer Service Phone: 866-552-2810**


## **Our Warranty Statement**

This warranty covers manufacturing defects associated with your new product. The product is warranted from the original purchase date and to the original purchaser for normal usage, according to the below-referenced specifications and limitations.


- Non-moving metal parts are warranted for 5 years.
- Component parts including pneumatic cylinder, control mechanism, base and casters are warranted for 2 years.
- All other items are warranted for 1 year.

Normal usage means use in compliance with the restrictions and weight limits specified for the product. In the absence of product-specific restrictions and weight limits, normal usage means use for no more than forty hours per week by persons weighing 250 lbs. or less. Coverage terminates if the product is sold or otherwise transferred. Repairs made by parties other than Belnick also void this warranty.













This warranty will not cover: (1) labor, freight, or damage from misuse, abuse, negligence, alteration, assembly, installation, attachments, accident, vandalism, acts of nature or any other event beyond the control of Belnick; (2) tearing, scratching, scuffing, or blemishing of leather or fabric; (3) cosmetic damage that may result from normal usage; (4) damage attributable to use by persons exceeding specified weight limits or commercial use exceeding forty hours per week; or (5) rust or other damage caused by exposure to moisture. The user assumes all risk of injury resulting from use of this product. Liability for incidental or consequential damage is excluded. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.




**Larger Table**




**Nested Table**

|  |  |
|--|--|
| <p>①</p> <p>Drawer Pull</p>  <p>X 1</p>     | <p>②</p> <p>Dowel Pins</p>  <p>X6</p>     |
| <p>③</p>  <p>M4X14mmX10</p>                 | <p>④</p>  <p>M6X30mmX10</p>               |
| <p>⑤</p>  <p>M6X35mmX16</p>                 | <p>⑥</p>  <p>M4X35mmX8</p>                |
| <p>⑦</p>  <p>M4X18mmX2</p>                  | <p>⑧</p> <p>Floor Glides</p>  <p>X10</p>  |
| <p>⑨</p> <p>Drawer Glides</p>  <p>X1SET</p> | <p>⑩</p>  <p>Screw-In Pins</p> <p>X10</p> |
| <p>⑪</p>  <p>Cam Lock</p> <p>X10</p>        |  <p>Allen Wrench</p>                       |

## NESTED TABLE PARTS



## LARGE TABLE PARTS



## Larger Table Assembly


### Step 1

**STEP 1A:** Attach Left Leg (Part Q) and Right Leg (Part S) to Front and Rear Braces (Part P) using (4) M6x35mm Bolts (Part 5).

**STEP 1B:** Attach Middle Leg (Part R) to Front and Rear Braces (Part P) using (2) M6x30mm Bolts (Part 4).

**STEP 1C:** Attach Lower Braces (Part N) to Middle Leg (Part R) and Right Leg (Part S) using (4) M6x35mm Bolts (Part 5).


**STEP 1D:** Insert Floor Glides (Part 8) into Left Leg (Part Q), Middle Leg (Part R) and Right Leg (Part S).



④x2  
⑤x8  
⑧x6

### Step 2

**STEP 2:** Attach Table Top (Part O) to assembled frame using (6) M6x30mm Bolts (Part 4).




④x6

## Nested Table Assembly


### Step 1

**STEP 1A:** Insert (4) Screw-In Pins into Drawer Front Panel (Part L). Lay panel face down on a smooth, clean surface.


**NOTE:** Ensure grooves are facing inward and towards the bottom.



**STEP 1D:** Slide Drawer Bottom Panel (Part I) into the grooves of the left and right side panels and ensure it seats into grooves on front desk panel. Attach Drawer Back Panel (Part M) using (4) M4x35mm Bolts (Part 6)




**Screw-In Pin and Cam Lock Instructions**



① x1  
⑥ x4  
⑦ x2  
⑩ x4  
⑪ x4


### Step 2

**STEP 2A:** Insert (4) Dowel Pins (Part 2) into inner holes in the Left Panel (Part E) and Right Panel (Part F).




**STEP 2B:** Attach Drawer Glides (Part 9) to Left Panel (Part E) and Right Panel (Part F) using (4) M4x14mm Screws (Part 3)

③ x4




**STEP 2C:** Insert (2) Dowel Pins (Part 2) into inner holes in the Table Back Panel (Part G).



② x6  
③ x4  
⑨ x1 set

## Step 3


**STEP 3:** Attach Left Panel (Part E) and Right Panel (Part F) to Table Back Panel (Part G) using (4) M4x35mm Bolts Screws (Part6)



⑥x4

## Step 4

**STEP 4A:** Lay Table Top (Part A) face down on a clean, smooth surface. Insert (6) Screw-In Pins (Part 10) into table top. Insert (6) Cam Locks (Part 11) into Left Panel (x2), Right Panel (x2), and Table Back Panel (x2). Turn assembled drawer frame upside down and slide down over Screw-In Pins. Ensure Dowel Pins are seated in appropriate table top holes then tighten Cam Locks.



⑩x6


⑪x6

## Step 5

**STEP 5A:** Attach Rear Upper Brace (Part B) and Front Upper Brace (Part C) to Left Leg and Right Leg (Part D) using (4) M6x35mm Bolts (Part 5).

**STEP 5B:** Attach Rear Lower Brace and Front Lower Brace (Part H) to Left Leg and Right Leg (Part D) using (4) M6x35mm Bolts (Part 5).


**STEP 5C:** Insert Floor Glides (Part 8) into the left and right table legs.



⑤x8  
⑧x4

## Step 6

**STEP 6:** Turn assembled table frame upside down and place over drawer frame assembly. Attach assembled frame to drawer frame assembly using (2) M14x4mm Screws (Part 3) in the front and (2) M6x30mm Bolts (Part 4) in the back. Return table to the upright position.




③x2  
④x2



## Step 7

**STEP 7:** Pull Drawer Glides outwards and attach to Drawer Assembly using (4) M14x4mmScrews.



③x4

## Step 8

**STEP 8:** Place Nesting Table under Larger Table

