

Sofa with Drop-Down Table


ASSEMBLY & GENERAL USE GUIDE

Table of Contents


What's Inside the Box	2
Step 1: Connect the Power Headrest Cables	3
Step 2: Attach the Backrests to the Seat Base	4
Step 3: Connect the Power Cables	5
Step 4: Attach the Tray Tables	6
Step 5: Opening the Drop-Down Table	7
Using the Power Control Panel	8
Using the Reading Light	9
Using the USB/Power Panel	10
Troubleshooting Guide	
Seat Part List	
Warranty Info & Contact Information	

What's Inside the Box

- A. RAF BACKREST**
- B. MIDDLE BACKREST**
- C. LAF BACKREST**
- D. RAF RED BAG**
- E. MIDDLE RED BAG**
- F. LAF RED BAG**




STEP 1



Connect the Power Headrest Cables

Connect each Powered Headrest Female Cable to each Powered Headrest Male Cable.


STEP 2



Attach the Backrests to the Seat Base

Slide the Backrest Female Brackets onto the Backrest Male Brackets.
Push until you hear a click on both sides. This will indicate that each backrest is secured.

STEP 3




Connect the Power Cables

End Seats: Plug in the Power Adapter Cable to the Power Adapter. Connect the Power Adapter to the seat base.

Middle Seat: Plug in the Headrest Light Power Cable to seat base.

Plug in all four cables to a power source.


STEP 4



Attach the Tray Tables

Open the in-arm storages to find your Tray Tables. Place each Tray Table into an accessory mount.


STEP 5



Using the Fold-Down Table


Lift the headrest then pull down on the backrest to open the Fold-Down Table. Push the button on the USB/110V Panel to access it.

Using the Power Control Panel



- 1. AMBIENT LIGHT CONTROL**
Push to turn the ambient base lighting and the lighted cupholders on or off.
- 2. POWERED RECLINE**
Push to set the powered recline to your preferred position.
- 3. USB CHARGING PORT**
Plug in any USB-powered device to charge it.
- 4. POWERED HEADREST**
Push to adjust the powered headrest to your desired position.


Using the Reading Light



1. LEFT LIGHT POWER SWITCH
Push to turn the left reading light on or off.

2. RIGHT LIGHT POWER SWITCH
Push to turn the right reading light on or off.

Using the USB/Power Panel




1. 110V OUTLETS
Plug device in to power it.

2. USB CHARGING OUTLETS
Plug in USB-powered device to charge it.


Troubleshooting Guide

Q. Why aren't my chairs reclining?


A. The Power Adapters have become loose or disconnected.



Unplug and re-plug in the Power Adapter to a wall outlet.




The green light on the Power Adapter should be illuminated.




Unplug and re-plug in the Power Adapter to the Powered Recline Cable.

Q. Why isn't my chair's power headrest functioning?


A. The Powered Headrest Cables have become loose or disconnected.




Unplug and re-plug the Powered Headrest Cables to each other.



Unplug and re-plug in the Power Adapter to a wall outlet.



The green light on the Power Adapter should be illuminated.




Unplug and re-plug in the Power Adapter to the Powered Recline Cable.


Troubleshooting Guide

Q. Why won't the reading light on the drop-down table turn on?

A. The Reading Light Power Cable has become loose or disconnected.




Unplug and re-plug in the Power Adapter to a wall outlet.



Unplug and re-plug in the Reading Light Power Cable.

Q. Why won't my USB/110V Panel power any devices?

A. The USB/110V Panel Power Cable has become loose or disconnected.




Unplug and re-plug in the USB/110V Panel Power Cable to a wall outlet.


Troubleshooting Guide

Q. **How come the lights on my cupholder are not lighting up?**


A. **The Power Adapter has become loose or disconnected.**



Unplug and re-plug in the Power Adapter to a wall outlet.




The green light on the Power Adapter should be illuminated.




Unplug and re-plug in the Power Adapter to the Powered Recline Cable.

Q. **How do I remove the backrest from the seat base?**


A. **The Backrest Female Bracket has a locking tab.**




Pull up on the locking tab on the Backrest Female Bracket and firmly pull the backrest upward.



Recline Mechanism - Power	PT-CE5318H-2
Recliner Motor	PT-ML8-281A
Headrest Motor	PT-ML20-101





Recline Mechanism - Power	PT-CE5318H-2
Recliner Motor	PT-ML8-281A
Headrest Motor	PT-ML20-101

Warranty Information

We are proud of its high standards of quality and workmanship that go into our products. The customer is protected by the following Limited Warranty, which applies to seats under normal indoor residential use. This warranty does not apply to seats used for commercial, institutional, or other non-residential uses.

ONE YEAR LIMITED WARRANTY: **We** provide (1) one year comprehensive coverage for all components such as materials, foam and frame parts, and mechanisms including motorized parts from defective materials or workmanship.

MATERIAL: Normal fabric fading, shrinking, or stretching is not covered by this warranty. Similarly, the natural markings, stretching, and shrinking of leather is a proud mark of authenticity and therefore not covered by this warranty. Evidence of improper cleaning, abuse, or abnormal use of the materials will void this warranty.

FOAM AND FRAME PARTS: **We** warrant these components for (1) one year from the time of delivery, against manufacturing defects. Foam compression is natural, and therefore not covered by this warranty.

MECHANISMS: **We** warrant these components for (1) one year from the time of delivery, against manufacturing defects. After the warranty period, the customer is responsible for inspection, labor and transportation costs.

No warranties, express or implied, apply after the expiration of this Limited Warranty. The warranty period covers repair, substitution, and replacement. No returns or refunds are covered. A proof of purchase is required to service a claim; simply present the bill of sale to the dealer from whom the item was purchased, to request warranty service. **We are** not liable for incidental or consequential damages occurring outside the terms of this warranty, even if advance knowledge of such damages was possible.

Contact Information

We're here to help. For any missing or damaged parts or installation assistance please call us