



Assembly Instructions




Please visit our website for the most current instructions, assembly tips, report damage, or request parts.

General Assembly Guidelines


- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The three main types of hardware used to assemble this product are: wood dowels, screws and bolts.
- V. The provided glue is to secure wood dowels in place. When first inserting dowels, locate the appropriate hole for the dowel, place a small amount of glue in the hole and insert the dowel. Wipe away excess glue immediately.




In future assembly steps when dowels are necessary to attach assembly parts together, place a small amount of glue on the end of the dowel before attaching parts together. Wipe away excess glue immediately.



- VI. A Phillips head screwdriver is required for the assembly of this product.




- VII. Power tools should not be used to assemble this product.




- VIII. Drill may be needed for securing product to wall.


- IX. Concealed hinges are three-way adjustable.



Horizontal
by screw adjustment




In-and-Out
by loosening the hinge-arm
mounting screw or via cam
adjustment










Vertical
Via slots in the mounting
plate or via cam adjustment

Parts List



Hardware List



A		Ø8x30mm	Wooden dowel	60 pcs
B		Ø15x11mm	Cam lock	51 pcs
C		Ø6x32mm	Cam bolt	51 pcs
D		Ø8x20mm	Wooden dowel	4 pcs
E			Hinge	4 pcs
F		Ø3.5x14mm	Screw	24 pcs
G		16mm	Shelf support pin	8 pcs
H		Ø6x50	Bolt	8 pcs
J			Handle	2 pcs
K		Ø4x22mm	Handle Bolt	2 pcs
L		M4	Hex Key	1 pc
M			Plastic wedge	8 pcs
N		Ø3x17	Screw	8 pcs
P		Ø4x32	Screw	10 pcs
Q		M6x25mm	Bolt	8 pcs
R		Ø4x12mm	Screw	4 pcs
S			L shape bracket	2 pcs
T		Ø4x25	Screw	6 pcs
U		Ø30mm	Sticker	51 pcs
V			Glue tube	1 pc
W		F18V66L	Fireplace Insert	1 pc



**Philips head screwdriver required for assembly
(not included)**


*The hardware quantities listed above are required for proper assembly.
Some extra hardware may also have been included.*

Step 1




Insert wooden dowel (A) to part (14), using cam bolt (C) secure part (1) ,then using cam lock (B) secure part (14) into part (1) with Phillips head screwdriver as per diagram.

Step 2




Insert wooden dowel (A) to part (13), using cam bolt (C) secure parts (3,2) ,then using screw (P) secure part (13) into parts (2,3) with Phillips head screwdriver as per diagram.

Step 3




Insert wooden dowel (D) to parts (16,17), using cam bolt (C) secure parts (16,17) ,then using screw (T) secure parts (15,18) into parts (16,17) with Phillips head screwdriver as per diagram.

Step 4




Insert wooden dowel (A) to parts (5,25,27), using cam bolt (C) secure parts (5, 26,28) with Phillips head screwdriver as per diagram.

Step 5






Insert wooden dowel (A) into parts (7,8,9,10,11,12) , using cam bolt (C) secure parts (9,10) with Philips head screwdriver as per diagram.

Step 6




Insert wooden dowel (A) to parts (19,20,21,22,23,24), using cam bolt (C) secure parts (21,24) with Phillips head screwdriver as per diagram.

Step 7




Using cam lock (B) secure parts (19,20,22,23) to parts (21,24) with Philips head screwdriver as per diagram.

Step 8





Using bolt (H) secure part (4) to parts (7,8) with Philips head screwdriver as per diagram.

Step 9




Put part (30) into parts (7,8) as per diagram.

Step 10





Using cam lock (B) secure part (2) to parts (7,8) with Philips head screwdriver as per diagram.

Step 11




Using cam bolt (C) secure part (4) with Philips head screwdriver as per diagram.

Step 12




Using cam lock (B) secure part (19,20,21) to parts (4) with Philips head screwdriver as per diagram.

Step 13





Using bolt (H) secure part (6) to parts (11,12) with hex key (L) as per diagram.

Step 14




Insert part (30) into parts (11,12) as per diagram.

Step 15





Using cam lock (B) secure part (3) to parts (11,12) with Philips head screwdriver as per diagram.

Step 16





Using cam bolt (C) secure part (6) with Philips head screwdriver as per diagram.

Step 17





Using cam lock (B) secure parts (22,23,24) to part (6) with Philips head screwdriver as per diagram.

Step 18





Using cam lock (B) secure parts (25,27) to part (5) with Philips head screwdriver as per diagram.

Step 19





Using cam lock (B) secure parts (9,10) to parts (16,17,26,28) with Philips head screwdriver as per diagram.

Step 20




Using cam lock (B) secure parts (9,10) to part (5,25,27) with Philips head screwdriver as per diagram.

Step 21




Using cam lock (B) secure part (1) to parts (9,10) with Philips head screwdriver as per diagram.

Step 22




Using screw (P) secure part (32) with Philips head screwdriver as per diagram.

Step 23




Using bolt (Q) secure parts (8,9,10,11) with hex key (L) as per diagram.

Step 24




Place sticker (U) cover the holes as per diagram.

Step 25




Put fireplace insert as per diagram.

Step 26




Using screw (R) secure L shape bracket (S) to part (9,10) with Philips head screwdriver as per diagram.

Step 27




Using screw(N) secure plastic wedge (M) to part (30) with Philips head screwdriver as per diagram.

Step 28




Insert shelf support pin (G) into then put part (29) into parts (7,8,11,12) as per diagram.

Step 29




Using handle bolt (K) secure handle (J) to part (31), then using screw (F) secure hinge (E) to part (31) with Philips head screwdriver as per diagram.

Step 30




Using screw (F) secure hinge (E) to part (7) with Philips head screwdriver as per diagram.

Step 31



Using screw (F) secure hinge (E) to part (12) with Philips head screwdriver as per diagram.

Step 32



Final Assembly