


# ASSEMBLY INSTRUCTIONS

---




## TOOLS REQUIRED



Allen Wrench

(Included)




Socket Wrench

(Included)



2 - Persons  
Recommended

## ASSEMBLY RATING



EASY ————— DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.



## **CHECK BEFORE STARTING**

### **Are you missing anything?**

Double-check all parts, hardware and accessories listed on Page 6 are accounted for.

### **Check out our Quick Tips!**

We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!

### **Should we send any replacements?**

Are there any irregularities or flaws in the parts? We can send replacements!

### **Prep Time!**

Please review the assembly instructions and all diagrams prior to assembling. Arrange parts as recommended on Page 7 and group identical hardware together to make assembling easier.

# PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.



## Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.



## Suitable Location

Assembling near the area of the intended location is highly recommended.



## Sufficient Space

Make sure you have enough space to move around during the assembly.



## Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent scratches.



## Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

# ASSEMBLY AND CARE ADVICE



**FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.**



Position each part correctly and insert screws or bolts into their respective holes.




Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.



Use the appropriate hand tools or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.



Save the instructions and store any supplied tools for later maintenance.



After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

**IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.**

# CAM LOCK FASTENER ASSEMBLY INSTRUCTIONS

## Note :

Every cam lock bolt must have a cam lock connector in order to fasten the parts together.




cam bolt



cam lock




screwdriver



**1**

Screw the cam bolt into panel.




**2**

Insert the cam bolt into the bolt hole of joint panel.



**3**

Align the cam lock with its side opening (or arrow) pointing to cam bolt.




**4**

Turn the cam lock clockwise gently until it will not turn any more.

# SOFA TABLE




- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.




## PARTS

#1 1pc



Wooden top

#2 1pc



Cabinet door

#3 1pc



Left board

#4 1pc



Mid board

#5 1pc




Back board

#6 2pcs



Left-layer board

#7 1pc



Left-bottom board

#8 3pcs




Post

#9 2pcs




Right-layer board

#10 1pc




Right-bottom board

#11 1pc



Supporting batten-back

#12 1pc




Supporting batten-front

# SOFA TABLE



- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.




## HARDWARE

#A 10pcs



Bolt 1/4" X 1-5/8"

#B 1pc



Rod 1/4"x28"

#C 1pc



Washer

#D 1pc



Nut M6

#E 28pcs



Ø6x30

#F 16pcs




Cam Bolt M6x40

#G 16pcs



Cam Lock Ø14.5x11

#H 4pcs



Cam Bolt M6x24

#I 4pcs




Cam Lock Ø12x10.5

#J 6pcs




Adjustable Foot  
M6 x 16

#K 1pc



Socket Wrench  
M6

#L 1pc




Allen Wrench M4

#M 18pcs



Screw M4

#N 3pcs




Pipe hinges

# ASSEMBLY INSTRUCTIONS

## Exploded View

1




2


- Part #3 x 1pc
- Part #4 x 1pc
- Part #6 x 2pcs
- Hardware #E x 12pcs
- Hardware #F x 8pcs
- Hardware #G x 8pcs

1) Secure and attach cam bolts (#F) and dowels (#E) to left and mid boards (#3,4).


2-3



3) Insert dowels (#E) to left and mid boards (#3,4).




2-1



SCREWDRIVER (NOT PROVIDED)

2-2




2) Align layer boards (#6) to the left and mid boards (#3,4), then secure by using cam locks (#G).



# ASSEMBLY INSTRUCTIONS

## 3

- Part **#1** x 1pc
- Part **#7** x 1pc
- Hardware **#E** x 4pcs
- Hardware **#F** x 8pcs
- Hardware **#H** x 4pcs




1) Secure cam bolts (#F,H) onto bottom board (#7).




2) Secure cam bolts (#F,H) and dowels (#E) onto top (#1).

## 4

- Part **#3** x 1pc
- Part **#4** x 1pc
- Part **#5** x 1pc
- Part **#7** x 1pc
- Hardware **#G** x 4pcs
- Hardware **#I** x 2pcs



Align bottom board (#7) to built product, then secure cam bolts (#H) by using smaller cam locks (#I) and cam bolts (#F) by using larger cam locks (#G).






# ASSEMBLY INSTRUCTIONS

Align built product to top (#1), then secure cam bolts (#H) by using smaller cam locks (#I) and cam bolts (#F) by using larger cam locks (#G).


## 5

- Part #1 x 1pc
- Part #3 x 1pc
- Part #4 x 1pc
- Part #5 x 1pc
- Hardware #G x 4pcs
- Hardware #I x 2pcs




## 6

- Part #2 x 1pc
- Part #3 x 1pc
- Hardware #M x 18pcs
- Hardware #N x 3pcs




Align hinges (#N) to the built product and door (#2), then secure by using screws (#M).




# ASSEMBLY INSTRUCTIONS

## 7

- Part #1 x 1pc
- Part #8 x 3pcs
- Part #9 x 2pcs
- Hardware #B x 1pc
- Hardware #E x 12pcs





Secure rod (#B) to built product, then insert dowels (#E) to posts (#8) as you stack it with the layer boards (#9).



## 8

- Part #8 x 1pc
- Part #10 x 1pc
- Hardware #C x 1pc
- Hardware #D x 1pc




Align bottom board (#10) to the built product, then secure by using hex nut (#D) with washer (#C) onto rod.


# ASSEMBLY INSTRUCTIONS

## 9


- Part #7 x 1pc
- Part #10 x 1pc
- Part #11 x 1pc
- Part #12 x 1pc
- Hardware #A x 10pcs
- Hardware #J x 6pcs



Align supports (#11,12) to built product, then secure by using bolts (#A). Attach adjustable feet (#J) to supports (#11,12), then adjust feet according to ground level.



## 10



### ASSEMBLY COMPLETED



Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.



#### Keep this handy!

Please retain this instruction manual and any order-related information for future reference.