






Installation & Assembly




EN_IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY.


USING CAM LOCK AND QUICKFIT




EN_QUICKFIT: Tighten quickfit until shoulder is flush with panel. Do not overtighten or undertighten.



EN_CAM LOCK: When fitting cam lock, ensure starting position is correct before you insert connecting quickfit.


















EN_Quickfit head should be in the centre of the cam lock when the two panels are joined.
Cam lock should be inserted before quickfit.






EN_Turn cam lock clockwise to tighten.

PACKING DELALS

NO.	PARTS	QTY	SPARE
①		x1	
②		x1	
③		x1	
④		x1	
⑤		x1	
⑥		x1	
⑦		x3	
⑧		x1	
⑨		x2	
⑩		x2	




NO.	PARTS	QTY	SPARE
⑪		x2	
⑫		x2	
⑬		x2	
⑭		x2	
	 Hardware Kit	x1	





A x8
 Ø6x35mm

1 x1






B x8
 Ø15x10mm


C x8
 Ø6x30mm

2 x1


6 x1




Pay attention to the width of the groove when installing # 3 and # 5



$a < b$



7 x3




D x4
Ø4x35mm





G x2



8 x1




13 x2



C x8
Ø6x30mm

D x8
Ø4x35mm





A x8
Ø6x35mm

B x8
Ø15x10mm

E x4
Ø3x12mm




F x2

11 x2



9 x2

10 x2




x2

E x12
Ø3x12mm

F x6


12 x2





x2

H x4
Ø6x80mm


I x4






C x8
Ø6x30mm



E x16
Ø3x12mm







If the ground is uneven, we can rotate the adjusting foot of the # 13 board to keep it level with the ground

