
Instruction manual



CONTENTS

Safety and care advice	1
Components	2
Assembly instructions	6
Door alignment	22
Copyright	23

⚠ SAFETY AND CARE ADVICE ⚠

PLEASE READ THESE INSTRUCTIONS CAREFULLY AND KEEP FOR FUTURE REFERENCE

- Warning: This unit weighs approximately 84kgs. Please lift with care.
- Check you have all the components and tools listed on pages 2, 3 and 4.
- Remove all Ottings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to lay out the parts before starting.
- Do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its • Inal position (in the same room) as possible.

 Assemble on a soft level surface to avoid damaging the unit or your □oor (use opened out unit carton).



- We do not recommend the use of power drill/drivers for inserting screws, as this could damage the unit. Only use hand screwdrivers.
- **Safety note:** If there is any chance of this unit being pulled over by children etc. it is recommended that the unit is secured to a wall using suitable fixings.
- Dispose of all packaging carefully and responsibly.


CARE AND MAINTENANCE

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- •This product should not be discarded with household waste. Take to your local authority waste disposal center.

Note If required the next page can be cut out and used as reference throughout the assembly. Keep this page with these instructions for future reference.

COMPONENTS

Please check you have all the panels listed below:



	*	
1	Top Panel	x1
2	Left Side Panel	x1
3	Right Side Panel	x1
4	Horizontal Panel	x1
5	Middle layer board	x2
6	Leg	x4
7	Horizontal panel	x1
8	Bottom Panel	x1
9	Back panel	x2
10	Support bar	x1

11 Divider panel	x 1
12 Left door	x 1
13 Right door	x 1
14 Drawer bottom panel	x2
15 Drawer bottom bar	x2
16 Drawer face panel	x2
17 Drawer left side panel	x2
18 Drawer right side panel	x2
19 Drawer back panel	x2



COMPONENTS

Please check you have all the fittings listed below:

Α



Metal Dowel x 47

G



Handle x 4

В



Lock (Ø15x12mm) x 33

Н



Screw(Ø3x12mm) x 12

C



Lock (Ø15x9.5mm) x 14

I



Pad x 1

D



Wooden Dowel(Ø8x30mm) x 32

J



Back Support x 8

Ε



Screw(Ø4x35mm) x 19

K



L lock wall x 2

F



Screw(Ø3.5x12mm) x 16

L



Big Bend Hinge x 6



COMPONENTS

М



Rail bracket x 2

N



Clothes rail x 1

0



Wall plug x 2

P



Screw(Ø6x11mm) x 12



Drawer runner x 2

R





Screw(Ø3x14mm) x 8

S



Support hardware x 1

ı



Screw (Ø6x12mm) x 4

U



Screw (Ø6x35mm) x 3

V



Allen wrench x 1

W



Screw(Ø3.5x14mm) x 12

X



TOOLS NEEDED

(We don't provide)




Phillips Screwdriver x 1



DRAWER RUNNER INSTRUCTION


△ IMPORTANT - Please read carefully - 1 Pair of drawer runners includes 4 pieces.


Part Q includes CR\DR\DL\CL.





Fittings (not to scale)


No.	Description	Qty	
CR	Outer Drawer Runner - Right	2	
CL	Outer Drawer Runner - Left	2	
DR	Inner Drawer Runner - Right	2	R
DL	Inner Drawer Runner - Left	2	




















Step 10







11





Step 14


















Step 21











Step 26







Congratulations! Now you have finished assembling the product.


DOOR ALIGNMENT




Customer Attention:

To align doors and control gap in between doors, product doors may need adjusting during and after assembly.

This can be done by adjusting appropriate screws. See below illustration.







Vertical Door Adjustment:

Loosen both screws on all hinges and lift the door to the desired height.


This allows an even space at the top and bottom between the door and frame.





Lateral Door Adjustment:

If door is hinge bound, (rubbing on frame as you close or open door) loosening screw shown and move the door in approriate direction. (In or out)





Horizontal Door Adjustment:

Rotate screw clockwise or anticlockwise. This will produce an even gap between doors and frame.