

# TOP TIPS - TOP TIPS

Read before you start assembly

## Locating the Dowel Rods

To keep the bed from rattling all the dowel holes have been slightly mis-drilled by a couple of mm. When you push parts together the dowels will straighten and pull together to ensure a tight fit. Whenever you locate a dowel on the hole NEVER push it all the way in, leave it so it is loose and can be aligned with the second locating hole.

Push them all the way in and they will not line up.



## GLUE SACHET INCLUDED

We have included a sachet of glue.  
THIS IS NOT TO BE USED with the dowel rods.

Open the sachet and empty into a plastic container. Whenever you connect a confirmat bolt (D) or a connector bolt (B) into a barrel bolt (c) dip the end of the bolt in the wood glue and screw in as normal. This will act as a lock tight and prevent the bolt from working loose.



## Clean out the Pre-drilled Holes

You have brought a solid pine product. During the drilling process there may be sawdust still in the holes.

BEFORE you start assembly clear these holes with one of the bolts. Push the bolt through each hole, this will dislodge any sawdust or debris that could interfere with fixing the bed.



## Applying a Finish to the Beds

The bed can be used in a natural form. However if you are applying a stain or finish we advise that you build the bed first. When you are happy with your purchase then put a sheet under the product and apply your stain/paint to the manufacturers recommendations.

NOTE: we are unable to accept the return, under any circumstance once a finish has been applied. By painting the bed you have deemed to accept the quality.



## Corner Posts -

Make sure the WHITE Mark is facing upwards and at the top when laid on the floor



# Fixing List

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than required. These are universal instruction so some fixings have different QTY's depending on size, ie single or double sizes.



## Fixing A1

Small sachet of glue for bolts B & C (NOT dowels)

Number Required

1



## Fixing A2

70mm wooden rail or base slat spacer

Number Required

1



## Fixing J

35mm gold bracket  
Used to hold centre rails

Single Size Model requires

0

Double Size Model requires

2



## Fixing A

40mm by 10mm Wooden Dowel  
Used to connect parts

Number Required

68  
0



## Fixing K

Allen Key  
To connect bolts

Number Required

1



## Fixing B

14mm Barrel bolt/Nut  
Used to connect with bolt C

Single Size Model requires

8

Double Size Model requires

16



## Fixing L

Small silver 15mm screw

Single Size Model requires

0

Double Size Model requires

4



## Fixing C

90mm Connector bolt  
Used to connect with bolt B

Single Size Model requires

8

Double Size Model requires

16



## Fixing Q

Black screw

Number Required

6



## Fixing D

90mm Confirmat Bolt  
Used to connect headboards

Single Size Model requires

14

Double Size Model requires

8



## Fixing E

30mm silver Screw  
Used to attach base slats and part 5

Number required

24

# Parts Identifier



## Description

Part Q1 Quattro Corner Post ( HB Left)

Part Q2 Quattro Corner Post (HB Right)

Part Q3 Quattro Corner Post (FB Left)

Part Q4 Quattro Corner Post (FB Right)

Part 1 - LONG Side Rail

Part 16- LONG Centre Rail (Not single size)

Fixing Kit and Instructions

Part 25- Siderail Support Legs

Part 26- Centre Leg (Not Single Size)

Part 9- (4G) Shaker headboard Insert

Part 13- Double Blue headboard facia


Part 4K- Quattro side top side rail facia (4k)

Part 4H- Quattro Top Headboard (4H)

Part 12- Long Shaker Inserts

## Consult Box Contents list for QTY

# How to identify your parts and fixings




## BLUE MARKING/FIXINGS

### \*\*SINGLE BEDS ONLY\*\*

The part will have a blue marker pen marking on the end.

Hole / Bolt configuration:

TWO large dowel holes - Place for large dowel  
One small centre hole - Place for large 90mm connector bolt D




## BLUE MARKING/FIXINGS

### \*\* DOUBLE/KING BEDS ONLY\*\*

The part will have a blue marker pen marking on the end.

Hole / Bolt configuration:

TWO large dowel holes - Place for large dowel  
One small centre hole - Place for large 90mm connector bolt C  
Facing access hole - Place for barrel bolt B bolt




## BLACK MARKING/FIXINGS

### \*\*SINGLE BEDS ONLY\*\*

The part will have a blue marker pen marking on the end.

Hole / Bolt configuration:

TWO large dowel holes - Place for large dowel  
One small centre hole - Place for large 90mm connector bolt D




## BLACK MARKING/FIXINGS

### \*\* DOUBLE /KINGSIZE ONLY\*\*

The part will have a blue marker pen marking on the end.

Hole / Bolt configuration:

TWO large dowel holes - Place for large dowel  
One small centre hole - Place for large 90mm connector bolt C  
Facing access hole - Place for barrel bolt B bolt



## SIDE RAIL MARKING/FIXINGS

The part will have a blue marker pen marking on the end.

Hole / Bolt configuration:

TWO large dowel holes - Place for large dowel  
One small centre hole - Place for large 90mm connector bolt C  
Facing access hole - Place for barrel bolt B

## First Build the Head Board Insert



Place dowel rods in all the headboard inserts as described, **DO NOT PUSH ALL THE WAY IN**. Now locate the **PART 9** facias and push in to create the headboard. The dowels will straighten as they align.

### NOTE\*\* Locating the Dowel Rods

To keep the bed from rattling all the dowel holes have been slightly mis-drilled by a couple of mm. When you push parts together the dowels will straighten and pull together to ensure a tight fit. Whenever you locate a dowel on the hole **NEVER** push it all the way in, leave it so it is loose and can be aligned with the second locating hole.

Push them all the way in and they will not line up.



### We need to build the headboard

You have four corners posts, each marked at the bottom. Find and locate Q1 to the left, Q2 to the right. The white chalk marking **MUST** be face the front at the top. Now locate the headboard facia and attach to the corner posts ( See Page 5 for fixings) **REMEMBER**, do Not push the dowel rods all the way in. **DO NOT** attach the top detail yet.



### Now we need to build the footboard.

Select and place corner posts Q3 (left) & Q4 (right). Again white chalk mark at the top facing you as lay them down as shown. Now footboard facia PART 13 (see page 5 for fixings). **DO NOT** attach the top detail yet.

## Attach the two side rails



Firstly ensure there is no sawdust or debris in the access holes. Using a bolt push through to clear. Now insert the dowel rods at all ends, do not push all the way in.

Make sure the **WHITE MARKINGS** on each headboard are facing inwards. Now start with the headboard and connect each side rail to each corner post

Place the barrel bolt within the round access hole on the side rail. Now dip bolt B into the glue and push through to connect to the barrel bolt. This side rail is designed not too move so the fixing is tight. Then locate the footboard, again ensure the **WHITE MARKINGS** are facing inwards and connect. (See page 5, FIG 5 for fixings)

## Attaching the top fineals.

### Front and Back Facias

You will have two parts 4H for the top head and foot boards. Attach these using confirmat bolts.

### Side Facias

You will find two part 4K, again attach using connector /barrel bolts. Once in place now go round and tighten all bolts.



## Attach the side rail support legs



It is important this leg is attached as it supports the side rail. Measure a half way point on the side rail. Place the support leg under the side rail from the outside. Using two black screws attach from the inside of the side rail. Note there is no access hole as the screws are self threading

The centre leg will hover slightly off the floor, when the bed is in use it will move down and support the bed. This is to protect the leg if the bed moves.



# Attach The Centre Rail

(Double/Kingsize Beds ONLY)



From the inside of the bed we need to attach metal brackets, one either end. These are fixed using the small screws (L), these are fixed to bottom headboard facia. Using a tape mark a centre line from each corner post, then measure and mark **55mm** from the top of the BLUE Facia(13). Now position the top of the bracket (J) just below this mark, attach with the small screw (L)

## Attach the centre rail support leg



The centre leg is located under the centre rail, in the centre. Simply measure to the centre of the bed and locate under the centre rail. Using two black screws attach from the side.



It is **IMPORTANT** that this is positioned correctly and remains in place while the bed is being used, failure to fix will weaken the bed. This part is manufactured using recycled timber as the component is out of sight. The centre leg will hover slightly off the floor, when the bed is in use it will move down and support the bed. This is to protect the leg if the bed moves.



## We Now need to attach the base slats.

You will have twelve extra wide base slats. Push the first slat tight with the footboard corner posts, then using the base slat spacer block evenly space out the remaining base slats. **DO NOT SCREW IN PLACE YET.**

Now push the slats flush to the left hand side rail and screw in (do not screw the right hand side yet). Now go to the right hand side and start with the slat near the centre. Push the side rail in so the slat is flush, then fix using the screw. This aligns the side rail. Now fix the remaining base slats.



**TIP:-**When you have attached the base slats you will have additional base slats screws. Out of the 12 slats screw 4 of them directly into the centre rail. Using the base slat screws simply drill through the top of the base slat into the centre rail. This will further strengthen the bed.