
LOVESEAT


A1	A	Left Arm Rest	1PC
A2	A	Right Arm Rest	1PC
В		Seat Back	1PC
С		Seat Base	1PC
D		M6 x 18 Socket Head Cap Screw	6PCS
Е		M6 x 40 Socket Head Cap Screw	2PCS
F	0	Washer	8PCS
G		Allen Key	1PC



Н	Back Cushion	2PCS	
J	Seat Cushion	1PC	


Attach right arm rest (A2) to seat base (C) using M6 x 18 socket head cap screw (D) and washer (F) as shown. Do this in two places.

Loose attach all connections at the beginning, adjust alignments then fully tighten all joints




LOVESEAT

2 Attach left arm rest (A1) to seat base (C) using M6 x 18 socket head cap screw (D) and washer (F) as shown. Do this in two places.



Attach seat back (B) to left and right arm rest (A1&A2) using M6 x 40 socket head cap screw (E) and washer (F) as shown. Do this in four places. Connect seat back (B) with seat base (C) using M6 x 18 socket head cap screw (D) and washer (F).



COFFEE TABLE




PART LIST	FIGURE	QUANTITY	DESCRIPTION
Α		1 PC	TABLE TOP
В		4 PCS	LEG
С		1 PC	LEG CONNECTOR
D		12 PCS	BOLT (M6*28)
E	0	12 PCS	FLAT WASHER
F		1 PC	ALLEN WRENCH

COFFEE TABLE

STEP 1


A. PLACE TABLE TOP (A) UPSIDE DOWN ON A FLAT, PROTECTED SURFACE.

B. ATTACH LEGS (B) TO TABLE TOP (A) WITH FLAT WASHER (E) AND BOLT (D) USING ALLEN WRENCH (F). DO NOT TIGHTEN COMPLETELY.



STEP 2

A. ATTACH LEG CONNECTOR (C) TO LEG (B) WITH FLAT WASHER (E) AND BOLT (D) USING ALLEN WRENCH (F). DO NOT TIGHTEN COMPLETELY.



STEP 3

A. ROTATE TABLE TO UPRIGHT POSITION SO THAT IT STANDS STABLE ON THE FLOOR.

B. TIGHTEN ALL BOLTS SECURELY USING ALLEN WRENCH (F).

TIGHTEN LEG CONNECTOR (C) FIRST, THAN TIGHTEN LEG (B) TO TABLE TOP (A).

C. KEEP ALLEN WRENCH (F) TO TIGHTEN ALL BOLTS PERIODICALLY AS NEEDED.

