
MODEL: IG10600148-1212



OWNER'S MANUAL


The Horizon 12'x12' Hard Top Gazebo W/ Solar LED light

TABLE OF CONTENTS	QUESTIONS?		
ASSEMBLY GUIDE 02 USING YOUR PRODUCT 04	E-mail: support@modernshade.org		
October 13, 2024	Toll Free: 1-888-666-3070		
	Mon-Fri : 9:0017:00 PST.		

ASSEMBLY GUIDE


PARTS LIST

A1 Post 1	A2 Post 2	B Foot Base	C Foot Cover	D4 Cross Beam 1	D5 Cross Beam 2
(2 pieces)	(2 pieces)	(4 pieces)	(4 pieces)	(4 pieces)	(4 pieces)
P0010000301	P0010000401	P0030000201	P0020000201	P0040001301	P0040001401
E1 Roof Rib 1 (4 pieces)	E2 Roof Rib 2 (4 pieces)	F1 Middle Cross Beam (4 pieces)	G1 Support Bracket 1 (4 pieces)	G2 Support Bracket 2 (4 pieces)	H3 Mosquito Net Rod (8 pieces)
				0 0	
P0070000201	P0070000301	P0080000101	P0050000101	P0050000201	P0100000401
J1 Top Beam 1 (8 pieces)	J5 Top Beam 2 (4 pieces)	K5 Roof Support 1 (4 pieces)	K9 Roof Support 2 (4 pieces)	K12 Roof Support 3 (4 pieces)	K13 Roof Support 4 (4 pieces)
P0090000101	P0090000501	P0090001001	P0090001401	P0090001701	P0090001801
L1 Connector 1 (4 pieces)	L2 Connector 2 (4 pieces)	L3 Connector 3 (4 pieces)	L4 Connector 4 (4 pieces)	L5 Connector 5 (4 pieces)	L6 Connector 6 (8 pieces)
		200			
P0060000201	P0110000201	P0110000401	P0060000301	P0060000401	P0060000501
Connector 7 (16 pieces)	L8 Connector 8 (1 piece)	L9 Connector 9 (4 pieces)	M1 Roof Rib Cover 1 (4 pieces)	M2 Roof Rib Cover 2 (4 pieces)	M3 Roof Rib Cover 3 (1 piece)
0	0 0				
P0060000601	P0060001101	P0110000501	P0120000101	P0120000301	P0120000401
N1 Roof Plate 1 (4 pieces)	N2 Roof Plate 2 (4 pieces)	N3 Roof Plate 3 (4 pieces)	N4 Roof Plate 4 (4 pieces)	N5 Roof Plate 5 (4 pieces)	N6 Roof Plate 6 (4 pieces)
P0130000101	P0130000201	P0130000301	P0130000401	P0130000501	P0130000601





HARDWARE



IMPORTANT:

This instruction manual contains important information necessary for the proper assembly and safe use of the product.

Read and follow all warnings and instructions before assembling and using the product.

Follow all warnings and instructions when using the product.

Keep this manual for future reference.

Installer/Assembler: leave these instructions with the consumer.

SAFETY ALERT KEY

A DANGER

Indicates a hazardous situation that, if not avoided, will result in death or serious injury.

A CAUTION

Indicates a hazardous situation that, if not avoided, could result in minor or moderate injury.

A WARNING

Indicates a hazardous situation that, if not avoided, could result in death or serious injury.

NOTICE

Indicates information considered important, but not hazard-related (e.g.messages related to property damage).


ASSEMBLY INSTRUCTIONS

Please carefully unpack each of the components and hardware.
 check the components against the parts list and make sure there are no missing parts. lay pieces on cardboard or a soft mat to help protect the pieces from scratches.


A CAUTION

Watch for sharp edges when handling the pieces, wear gloves to avoid injury.

STEP 01 Slide Foot Cover C onto Post 1 A1 . Attach Foot Base B using two (2) M6*20 Bolts [AA] and two (2) M6 Flat Washers [DD]. Repeat for the second Post 1 A1 . Slide Foot Cover C onto Post 2 A2 . Attach Foot Base B using two (2) M6*20 Bolts [AA] and two (2) M6 Flat Washers [DD]. Repeat for the second Post 2 A2 .




STEP 03 Connect the assembly from Step 2 to Post 1 A1 and Post 2 A2 using four (4) M6*20 Bolts [AA] and four (4) M6 Flat Washers [DD]. Repeat to create a second set of legs.




- •For ease of assembly, it is recommended to have 3 or more people and allow enough time to completely finish the assembly. assembly can take 6-8 hours. a step-ladder is required for assembly (not included).
- •Follow step by step instructions, and follow all safety warnings provided with your tools.
- •DO NOT tighten screws until all the screws and washers are properly installed.
 tighten screws securely, do not over tighten.
- •Gazebo should not be used in inclement weather and high winds.


STEP 02 Slide Cross Beam 1 D4 and Cross Beam 2 D5 onto the ends of one (1) Connector 1 L1. Secure with a Connector 2 L2 using five (5) M6*20 Bolts [AA] and five (5) M6 Flat Washers [DD]. Repeat to create four (4) assemblies.




<u>STEP 04</u> Connect the sets of legs from Step 3 together using the remaining assemblies from Step 2 using eight (8) M6*20 Bolts [**AA**] and eight (8) M6 Flat Washers [**DD**].



STEP 05 In each corner, connect one Connector 3 L3 using two (2) M6*20 Bolts [AA] and two (2) M6 Flat Washers [DD]. Then, connect one Connector 5 L5 on top of each corner using three (3) M6*20 Bolts [AA] and three (3) M6 Flat Washers [DD].




STEP 06 On each post, attach one (1) Support Bracket 1 G1 on the left and one (1) Support Bracket 2 G2 on the right using two (2) M6*20 Bolts [AA] and two (2) M6 Flat Washers [DD] on the lower holes and two (2) M6*45 Bolts [BB] and two (2) M6 Flat Washers [DD] in the upper holes.




STEP 07 Attach two (2) Mosquito Net Rods 3 H3 on each side of the gazebo using two (2) M6*20 Bolts [AA] and two (2) M6 Flat Washers [DD] each.

STEP 08 At each corner, attach one (1) Roof Rib E1 using four (4) M6*20 Bolts [AA] and four (4) M6 Flat Washers [DD].



STEP 09 Slide one (1) Roof Rib 2 E2 into the top of each Roof Rib 1 E1. Connect all Roof Rib 2 E2 together using the Connector 8 L8, four (4) M6*20 Bolts [AA] and four (4) M6 Flat Washers [DD].




STEP 11 Attach one Connector 6 L6 to the middle of Middle Cross Beam 4 F1. Then, attach a second Connector 6 L6 to the end of Middle Cross Beam 4 F1 without the tab. Attach one Connector 4 L4 on the bottom side.

Use one (1) M6*20 Bolt [AA] and one (1) M6 Flat Washer [DD] in each hole.


Repeat to make four (4) assemblies.


STEP 10 Add one (1) Roof Support 1 K5 between each set of Roof Rib 2 E2 using one (1) M6*20 Bolts [AA] and one (1) M6 Flat Washers [DD].

[AA] x 8




STEP 12 Attach each Middle Cross Beam 4 F1 to each side of the gazebo using three (3) M6*20 Bolts [AA] and three (3) M6 Flat Washers [DD].







STEP 13 On each Roof Rib E1, attach one (1) Connector 7 L7 to the bottom end, one (1) Connector 7 L7 in the center, and one (1) Connector 7 L7 to the end of the upper arm using one (1) M6*20 Bolt [AA] and one (1) M6 Flat Washer [DD] in each hole.

STEP 14 Connect one (1) Top Beam 2 J5 to each side at the top of the gazebo. Use two (2) M6*20 Bolts [AA] and two (2) M6 Flat Washers [DD] in each.






STEP 15 Connect two (2) Top Beam 1 J1 to each side of the gazebo halfway down each Middle Cross Beam 1 F1. Use four (4) M6*20 Bolts [AA] and four (4) M6 Flat Washers [DD] per side.




STEP 16 Attach one Roof Support 2 K9 to the Connector 7 L7 on the upper arms of Roof Rib 2 E2 using two (2) M6*20 Bolts [AA] and two (2) M6 Flat Washers [DD] in each.

<u>STEP 17</u> Install Roof Support 3 K12 and Roof Support 4 K13 on each side of the camper using two (2) M6*20 Bolts [AA] and two (2) M6 Flat Washers [DD] each.




STEP 18 Cover the connections between Roof Support 3 K12 and Roof Support 4 K13 with a Connector 9 L9 using two (2) M6*20 Bolts [AA] and two (2) M6 Flat Washers [DD] in each.

[**AA**] x 8 [**DD**] x 8




STEP 19 From left to right, attach Roof Plates in this order: N12, N8, then N13. Use one (1) M6*20 Bolt [AA] and one (1) M6 Flat Washer [DD] per hole. Repeat on each side of the gazebo to build the top of the roof.




STEP 20 Cover the seams at the corners using Roof Rib Cover 2 M2. Secure with two (2) M6*45 Bolts [BB], two (2) M6 Flat Washers [DD], and two (2) Sealant Washers [EE] each.


Secure it by clipping it into place, then attach the Hook P from underneath.




STEP 22 From left to right, attach the Roof Plates in this order: N6, N4, N2, N1, N3, N5, then N7. Use four (4) Plastic Clips [GG] in the top holes and M6*20 Bolts [AA] with M6 Flat Washers [DD] in all of the other holes. Repeat three times to finish the roof all the way around.




STEP 23 Cover the seams at the corners using Roof Rib Cover 1 M1. Secure with two (2) M6*45 Bolts [BB], two (2) M6 Flat Washers [DD], and two (2) Sealant Washers [EE] each.




STEP 24 Insert two (2) M4*20 Bolts [CC] into each Post. Tighten ¾ of the bolt, leaving some exposed. Attach one (1) Light at to each set of bolts.



STEP 25 Attach all fifty-six (56) Rings [LL] to the mosquito net around the gazebo on the rings.




STEP 26 Position the gazebo where you want it, then slide the Foot Cover C up. Insert the Concrete Anchors [FF] into the Foot Base B, and tighten completely. Then, slide the Foot Cover C down over the Foot Base B.




Outdoor Structure anchoring guide for anchoring gazebo to wood or concrete: If step 26, on page 11 in the assembly instructions is not properly completed, this will void the warranty.



WARNING! If your gazebo is not properly anchored, damage could occur. It is highly recommended for maximum safety that you mount and secure to wood or concrete footers. This is far better and safer than using ground stakes. The following are some examples of how to mount the structure to wood or concrete surfaces. Refer to local building codes or consider consulting a licensed contractor for assistance in the anchoring of this product.





If digging for foundation, please double check for possibility of any underground utilities such as gas, telephone, cable or sprinkler lines. Refer to your local building and city codes, ordinances, neighborhood covenants, or height restrictions regarding this type of structure for guidance on acceptable installation requirements.

A CAUTION

DO NOT climb or walk on roof for any reason.

- •Our components are intended for privacy, decorative and ornamental use only.
- •Product is NOT INTENDED for the following:
- •A safety barrier to prevent unsupervised access to pools, hot tubs, spas or ponds.
- •As load bearing support for a building, structure, heavy objects or swings.
- •Used in structures that trap wind, rain or snow that would create extra load on the product.
- Accumulated snow must be removed from roof.
- •DO NOT climb or walk on roof for any reason.

LIMITED WARRANTY

We warrants this product against defects in materials and workmanship for a period of one (1) year from the original date of purchase. To the extent any such defects occur, our products will send the appropriate replacement part(s) at no charge.

This warranty does not cover:

- •Inspection costs or labor for replacement of any defective parts);
- Incidental or consequential damages;
- •Cosmetic defects which DO NOT affect performance;
- Normal wear and tear:
- •Damage due to vandalism; acts of nature, including but not limited to wind, storms, hail, floods;
- •Improper assembly, installation, or use;
- •Discoloration or fading of the finish as a result of exposure to chemicals, spills, pool or salt water
- Corrosion/ rust.

Your product has been designed for safety and quality.

Any modifications made to the original product could compromise its structural integrity or function, and could lead to product failure or personal injury. As such, modifying this product voids any and all warranties.

This product is warranted for RESIDENTIAL USE ONLY, and is not for commercial, contract or other non-residential purposes. Products disclaims all other representations and warranties of any kind, express or implied.

The warranty applies to the original purchaser and is non-transferable. It does not apply to purchases of display models, or when the product is sold on clearance or "as is".

We makes no warranty whatsoever in respect to accessories or parts not supplied with it. This warranty shall apply only within the boundaries of the United States of America and Canada. This warranty gives the original purchaser specific rights, and the original purchaser may also have other rights, which vary from state to state.