




Multifunctional storage

## Assembly Instructions



# Parts List











X5

## ASSEMBLY MATERIAL

**Notice:**





1. Follow the Installation instructions. Please confirm all accessories are preset before installation.
2. Do not fully tighten the screws during initial assembly. Fully tighten screws only once all pieces which are correctly assembled
3. If you encounter any problems during installation, refer to two solutions: Follow the installation video tutorial on the Amazon product page or contact our customer service.





Item no.	Reference Image	Qty.	Item no.	Reference Image	Qty.
<b>A</b>		X61	<b>E</b>		X1
<b>B</b>		X61	<b>F</b>		X1
<b>C</b>	 8 x 30MM	X36	<b>G</b>		X5
<b>D</b>	 6 x 30MM	X15	<b>H</b>	 300MM	X5

## ASSEMBLY MATERIAL











**Notice:**

1. Follow the Installation instructions. Please confirm all accessories are preset before installation.
2. Do not fully tighten the screws during initial assembly. Fully tighten screws only once all pieces which are correctly assembled
3. If you encounter any problems during installation, refer to two solutions: Follow the installation video tutorial on the Amazon product page or contact our customer service.






Item no.	Reference Image	Qty.
<b>I</b>	 $\phi$ 3.5 x 12MM	X25
<b>J</b>	 M3.5 x 12MM	X52
<b>K</b>	 M6 x 12MM	X4
<b>L</b>	 M6 x 25MM	X4







Item no.	Reference Image	Qty.
<b>M</b>	 M3.5X35	X23
<b>N</b>		X8
<b>O</b>		X2
<b>P</b>		X1

## ASSEMBLY MATERIAL


Item no.	Reference Image	Oty.	Item no.	Reference Image	Oty.
①		X1	⑥		X2
②		X1	⑦		X1
③		X1	⑧		X1
④		X1	⑨		X1
⑤		X1	⑩		X1

## ASSEMBLY MATERIAL


Item no.	Reference Image	Qty.
<b>11</b>		X1
<b>12</b>		X5
<b>13</b>		X5
<b>14</b>		X5
<b>15</b>		X5

Item no.	Reference Image	Qty.
<b>16</b>		X5
<b>17</b>		X2
<b>18</b>		X1
<b>19</b>		X1
<b>20</b>		X1
<b>21</b>		X1


# How to use the cam lock system




1.Screw cam bolt into panel




2.Push cam into panel - arrow feature on cam top points to panel edge



3.Align cam bolt(s) with cam(s) and insert all the way into cross-bored hole(s)







3.Rotate cam(s) clockwise 190°-230° to lock panels together



5.Panels should be tight against each other and connection should be rigid


**Insert the wood dowel [C] at least half way by tapping lightly with a rubber mallet ,IF NECESSARY.**




- Unit must be placed on a level surface or leveled with included hardware (when applicable).
- Do not sit or stand on or allow children to climb,sit or stand on the assembled product.
- For safety reasons,it is imperative that this unit be mounted to the wall.
- Do not use without installing the tip restraint.
- Unit can tip over causing severe injury or death.
- Do not exceed the recommended weight limits.
- Evenly distribute the weight on each level and always keep the heavier loads on the bottom.
- Before cutting,drilling or hammering into any wall or floor surface,verify the location of electrical, plumbing and gas lines.Cutting may cause serious injury.

# Ready to assemble the Multi-purpose lockers

Before installation, observe each structure of the Multi-purpose lockers. The Multi-purpose lockers consists of two main parts. You will assemble the chest first, and then install the five drawers. Finally, look at the finished look, and contrast list of part, imagine how to install it faster, hope this will help you.





We recommend using a power drill to assemble。





## Step 1



- Attach ①A & ①C to ④ as below shown
- Screw ①B to lock the ④ as below shown



## Step 2



-Attach ①A & ①C to ④ as below shown

-Screw ①B to lock the ④ as below shown




### Step 3

- Stick ① to ④ & ⑤, use ⑥ locked
  - Install the drawer slides ⑦ on the middle side panel ⑤.
- When building it make sure to take note of the drawer slides is the one with a flat end.




Make sure the 2 large pre-drilled hole are on the upside.






## Step 4




- Attach ① to ④ as below shown
  - Stick ① to ③ & ④, use ② locked
  - Install the drawer slides ③ on the right side panel ④.
- When building it make sure to take note of the drawer slides is the one with a flat end.



Tighten ① clockwise until all of their threads are engaged.



Make sure the 2 large pre-drilled hole are on the upside.




① should be screw to the small holes


## Step 5

-Attach (A) & (C) to (2) as below shown





-Screw (B) to lock the (11) as below shown



The two boards fit vertically, place (B) and match their holes with (A) then tighten (B) clockwise.



Tighten (A) clockwise until all of their threads are engaged.




## Step 6


-Attach ① & ③ to ⑤ & ② as below shown

-Stick ④ to ② & ⑤, use ⑥ locked







-Screw ⑦ to lock the ⑧ as below shown



The two boards fit vertically, place (B) and match their holes with (A) then tighten (B) clockwise.



Tighten (A) clockwise until all of their threads are engaged.




## Step 7


-Attach (A) & (C) to (3) as below shown

-Screw (B) to lock the (2) & (7) & (9) & (11) as below shown



-Stick (L) to (9) & (10), use (P) locked



The two boards fit vertically, place (B) and match their holes with (A) then tighten (B) clockwise.




Tighten (A) clockwise until all of their threads are engaged.




## Step 8

-Attach ① & ③ to ④ as below shown




-Screw ② to lock the ② & ⑨ & ⑪ as below shown



The two boards fit vertically, place (B) and match their holes with (A) then tighten (B) clockwise.



Tighten (A) clockwise until all of their threads are engaged.










## Step 9


-Stick (E1) to (8)&(E2),use (P) locked

-Stick (I) to (8)&(F1),use (P) locked

-Stick (K) to (8)&(F2),use (P) locked




# Step 10




# Step 11





- Attach (A) & (C) to (3) & (4) & (5) as below shown
- Screw (B) to lock the (3) & (4) & (5) as below shown



The two boards fit vertically, place (B) and match their holes with (A) then tighten (B) clockwise.






Tighten (A) clockwise until all of their threads are engaged.





## Step 12

-Screw ① to attach ⑬ to ① & ② & ③ & ④ & ⑤ as below shown







## Step 13

-Attach ①N to ③&⑤ as below shown




## Step 14


- Attach ① to ⑮ as below shown
- Attach ⑫ & ⑬ to ⑮ as below shown
- Screw ② to lock the ⑫ & ⑬ as blow show




Tighten (A) clockwise until all of their threads are engaged.




The two boards fit vertically, place (B) and match their holes with (A) then tighten (B) clockwise.



X5







The long groove on the panel is used to install the bottom plate. Please make sure all grooves of these boards are on the same side.



X5





## Step 15

- Screw ⑤ to attach ⑫ & ⑬ to ⑭ as below shown
- Screw ⑪ to attach ⑧ to ⑮ as below shown
- Attach ⑭ to ⑫ & ⑬ as below shown
- Attach ⑯ to ⑮ as below shown



## Step 16


-Install the drawer slides (H) on the drawer side panels (12) & (13) as below shown




-Repeat the previous step to install the remaining drawers






## Step 17



## Step 18



## Step 19



The furniture must permanently be fixed to the wall using the provided anti-tipping device to prevent it from tipping over.

- Mark the drill positions on the wall with a pencil.
- Drill a small hole on the marked positions.
- Insert a wall anchor into the drilled hole.
- Fix the anti-tipping strap to the wall using the provided screws.