


# Before You Start



- ✓ Read through each step carefully and follow the proper order
- ✓ Separate and count all your parts and hardware
- ✓ Give yourself enough room for the assembly process
- ✓ Have the following tools: Flat Head Screwdriver, #2 Phillips Head Screwdriver and Hammer
- ✓ Caution: If using a power drill or power screwdriver for screwing, please be aware of to slow down and stop when screw is tight. Failure to do so may result in stripping the screw. (Assembly speed can be increased by using electric screwdriver)

## Helpful Hints


### PEOPLE NEEDED FOR ASSEMBLY: 1-2

- Open your item in the area you plan to keep it to avoid excessive heavy lifting.
- Identify, sort and count the parts before attempting assembly.
- Compression dowels are lightly tapped in with a hammer.
- Slides are labeled with an **R** (right) and **L** (left) for proper placement.
- Make sure to always face the point on the top of the Cam Lock towards the outer edge.
- If there is a back panel in the package, please install it to make sure your unit is complete and sturdy.
- Please fix all the screws provided for the back panel which can enhance product stability. If it is difficult to fix it when tightening, it can be fixed with the help of a hammer and then tightened.
- Do NOT use harsh chemicals or abrasive cleaners on this item.
- Never push, pull, or drag your furniture.




# Board Identification


Not actual size




Ⓐ X1




Ⓑ X1




Ⓒ X1




Ⓓ X1




Ⓔ X2




Ⓕ X1




Ⓖ X1




Ⓕ X1



Ⓖ X1




Ⓖ X1




Ⓖ X1

# Board Identification


Not actual size




Ⓛ X1




Ⓜ X1




Ⓝ X2




Ⓞ X1




Ⓟ X1




Ⓠ X2




Ⓡ X1




Ⓢ X2




Ⓣ X1



Ⓤ X4



Ⓥ X4




Ⓦ X4


---

# Board Identification


Not actual size




ⓧX12




ⓎX12



ⓏX12




ⒶⒶX12




ⒷⒷX12


# Part List




CAM LOCK  
spare:5




CAM BOLT  
spare:4




CAM BOLT  
spare:1




WOODEN DOWEL  
spare:2




WOODEN DOWEL  
spare:3




SCREW  
spare:1




SCREW  
spare:2




SCREW  
spare:1




SCREW  
spare:3




SCREW  
spare:3




SCREW  
spare:1




HANDLE




SCREW  
spare:1




LEFT CABINET MEMBER




RIGHT CABINET MEMBER




LEFT DRAWER RUNNER




RIGHT DRAWER RUNNER



LAMP TUBE




LAMP CLIP  
spare:1




HEX KEY


# Part List




PLUG BOARD




CORNER BUMPER




BACKBOARD BUCKLE




CABLE COVER



HOLE STICKERS




ANTI-TIPPING HARDWARE



Duct Tape










# Board Identification

Not actual size







# STEP1





x 12


# STEP2




 Ø7X40mm	
2	X16


 Ø6.5X35mm	
3	X4

	
12	X4


 M4X12mm	
13	X8









x 12





x 4





# STEP3





# STEP4





 Ø15X9.5mm	
1	X20


 Ø3.5X14mm	
9	X24

 Ø4X40mm	
10	X4














14"  350mm	
14DL	X4

 Ø21mm	
22	X16

14"  350mm	
14DR	X4



# STEP5






14DR


14DL


x 4


# STEP6





 Ø15X9.5mm	
1	X20






 Ø3.5X14mm	
9	X24

 Ø4X40mm	
10	X4

14"  350mm	
14DL	X4

 Ø21mm	
22	X16

14"  350mm	
14DR	X4







14DR







14DL

x 4

# STEP 7








# STEP8












# STEP9







# STEP10
















USB Wire  
docking














# STEP11















# STEP12












# STEP13



# STEP14






# STEP15




14"  
LEFT CABINET MEMBER





FLIP OVER



14"  
RIGHT CABINET MEMBER



# STEP16



T

R


S

x 2

N


x 2


O








# STEP17






 Ø15X9.5mm	
1	X12

 Ø6.3X50mm	
6	X4





 4X65mm	
17	X1






# STEP18



# STEP19







## STEP20







The two men laid the cabinet flat on the floor,  
Insert the upper P plate first,  
And then the Q plate below,  
Finally put the Q in the middle.


# STEP21



# STEP22






drill two Ø6  
holes on the  
wall



put two anchors  
in the holes

# STEP23



# STEP24

