


Before You Start




- ✓ Read through each step carefully and follow the proper order
- ✓ Separate and count all your parts and hardware
- ✓ Give yourself enough room for the assembly process
- ✓ Have the following tools: Flat Head Screwdriver, #2 Phillips Head Screwdriver and Hammer
- ✓ Caution: If using a power drill or power screwdriver for screwing, please be aware of to slow down and stop when screw is tight. Failure to do so may result in stripping the screw. (Assembly speed can be increased by using electric screwdriver)

Helpful Hints


PEOPLE NEEDED FOR ASSEMBLY: 1-2

- Open your item in the area you plan to keep it to avoid excessive heavy lifting.
- Identify, sort and count the parts before attempting assembly.
- Compression dowels are lightly tapped in with a hammer.
- Slides are labeled with an **R** (right) and **L** (left) for proper placement.
- Make sure to always face the point on the top of the Cam Lock towards the outer edge.
- If there is a back panel in the package, please install it to make sure your unit is complete and sturdy.
- Please fix all the screws provided for the back panel which can enhance product stability. If it is difficult to fix it when tightening, it can be fixed with the help of a hammer and then tightened.
- Do NOT use harsh chemicals or abrasive cleaners on this item.
- Never push, pull, or drag your furniture.




Board Identification


Not actual size




Ⓐ X1




Ⓑ X1




Ⓒ X1




Ⓓ X1




Ⓔ X1




Ⓕ X1




Ⓖ X1




Ⓖ X1



Ⓙ X1




Ⓚ X1




Ⓛ X1

Board Identification


Not actual size




Ⓛ X3




Ⓜ X3




Ⓝ X1




Ⓞ X1




Ⓟ X1




Ⓠ X1




Ⓡ X2




Ⓢ X1




Ⓣ X2



Ⓤ X6




Ⓥ X6



Ⓦ X6

Board Identification


Not actual size



ⓧ X6




Ⓨ X6




Ⓩ X4


Part List




CAM LOCK
spare:3




CAM BOLT
spare:3




CAM BOLT
spare:1




WOODEN DOWEL
spare:3




SCREW
spare:1




SCREW
spare:2




SCREW
spare:1




SCREW
spare:1




SCREW
spare:2




SCREW
spare:2




LEFT CABINET MEMBER




RIGHT CABINET MEMBER




LEFT DRAWER RUNNER




RIGHT DRAWER RUNNER




LAMP TUBE




SCREW
spare:1




LAMP CLIP
spare:1



HEX KEY




PLUG BOARD




CORNER BUMPER


Part List




BACKBOARD BUCKLE




CABLE COVER



HOLE STICKERS




Acrylic plate








ANTI-TIPPING HARDWARE

Board Identification






Not actual size










STEP 1



STEP 2





STEP 3





x 4


STEP 4






 <p>Ø15X9.5mm</p>	
1	X6

 <p>Ø4X40mm</p>	
9	X6






 <p>Ø3X14mm</p>	
10	X60

 <p>14" 350mm</p>	
11DL	X6







 <p>14" 350mm</p>	
11DR	X6






STEP 5








STEP 6










STEP 7
















STEP8




STEP 9





STEP10





STEP 11





	
Ø7X40mm	
2	X14

	
Ø6X30mm	
4	X4








	
Ø6.3X8mm	
6	X18

	
14" 350mm	
11CL	X3










	
14" 350mm	
11CR	X3




STEP12





STEP 13





STEP14




 Ø15X9.5mm	
1	X16






 Ø6.3X50mm	
5	X2

 4X65mm	
15	X2





 Ø21mm	
20	X4









STEP 15




STEP 16







STEP 17







USB Wire docking




STEP 18



STEP 19






drill two Ø6 holes on the wall






put two anchors in the holes


STEP20



STEP21



Light outward



x 4

STEP 22

