


# Instructions

## ⚠ WARNING



- Check for electric, gas, & plumbing lines before drilling or consult a professional.
- Turn off your electricity at the circuit breaker or main fuse box before installation. Do not restore power to the line until the light has been fully installed.
- Do not use with bulbs exceeding the recommended wattage.
- Always switch off the electricity supply and allow bulbs to cool for 10 minutes before changing it.
- Do not look directly at lit bulb.



## ASSEMBLY

It is recommended to use two or more persons during the assembly process.

1. Connect the 8 Curved lamp bodies (D) with terminal pairs and tighten them with M4 screws for fixation
  2. Use 4 connecting rods (B) to connect with the spliced large circle
  3. Use 4 connecting rods (A) to connect and fix the junction box (E)
  4. Refer to the wiring diagram and connect the power cord using Wiring terminals (F). Pay attention to distinguishing positive and negative poles
  5. The iron chains (L) are fixed to the junction box (E). Choose the required length of the iron chain
  6. Fix the installation bracket (I) to the junction box (H)
  7. Use wiring caps to connect the power and ground wires Pay attention to the distinction between positive and negative poles
  8. Use Canopy Nut (K) to fix Canopy (J) to Junction box (H)
  9. Place Bushing (C) over the lamp holder and twist in the E12 bulb
  10. After installation is completed, turn on the power switch and test whether the lighting fixtures are on
- Due to the large size of the lamp body and the relatively complex installation, it is recommended to have a professional electrician complete it!

d1		x 3
d2		x 2

E12 Socket  
Max  
.40W Bulbs  
(not included)