

JY9985BS01/JY9985HS01




As this item contains many parts, please read the installation instruction carefully before installation . Please use tools properly and carefully. If you have any questions about the product and installation, please contact us.

hosoteservice@gmail.com

Our professional after-sales team will serve you online all day.

Before You Start



- ✓ Read through each step carefully and follow the proper order
- ✓ Separate and count all your parts and hardware
- ✓ Give yourself enough room for the assembly process
- ✓ Have the following tools: Flat Head Screwdriver, #2 Phillips Head Screwdriver and Hammer
- ✓ Caution: If using a power drill or power screwdriver for screwing, please be aware of to slow down and stop when screw is tight. Failure to do so may result in stripping the screw.

Helpful Hints



















PEOPLE NEEDED FOR ASSEMBLY: 1-2

- Open your item in the area you plan to keep it to avoid excessive heavy lifting.
- Identify, sort and count the parts before attempting assembly.
- Compression dowels are lightly tapped in with a hammer.
- Slides are labeled with an **R** (right) and **L** (left) for proper placement.
- Make sure to always face the point on the top of the Cam Lock towards the outer edge.
- Use all the nails provided for the back panel and spread them out equally.
- Back panel must be used to make sure your unit is sturdy.
- Do NOT use harsh chemicals or abrasive cleaners on this item.
- Never push, pull, or drag your furniture.





















Board Identification

Not actual size

①x1 	②x2 	③x2 
Left upper cabinet left panel	Left upper cabinet, left and right fixed laminate	Left upper cabinet left and right rear panels
④x1 	⑤x2 	⑥x1 
Left upper cabinet left middle riser	Left upper cabinet middle fixed laminate	Left upper cabinet middle rear panel
⑦x1 	⑧x1 	⑨x1 
Left upper cabinet right middle riser	Left upper cabinet top plate	Right upper cabinet left panel
⑩x1 	⑪x2 	⑫x1 
Right upper cabinet top plate	Right upper cabinet upper and middle fixed laminate	Right upper cabinet rear panel
⑬x1 	⑭x1 	⑮x1 
Right upper cabinet fixed laminate	Place the board in rows	Right upper cabinet right panel
⑯x1 	⑰x1 	⑱x1 
Push pull mirror plate	Left cabinet desktop board	Left cabinet lower left panel










Board Identification

Not actual size


<p>①9x1</p> 	<p>②0x1</p> 	<p>②1x1</p> 
Lower rear panel of left cabinet	Left cabinet grille	Left cabinet right panel
<p>②2x1</p> 	<p>②3x1</p> 	<p>②4x1</p> 
Lower bottom plate of left cabinet	Left cabinet lower rear connection strip	Right cabinet top plate
<p>②5x1</p> 	<p>②6x1</p> 	<p>②7x1</p> 
Right cabinet left panel	Right cabinet right panel	Rear panel of right cabinet
<p>②8x1</p> 	<p>②9x3</p> 	<p>③0x1</p> 
Right cabinet rear pull-down bar	Connecting bar under drawer	Front panel of left cabinet and drawer
<p>③1x1</p> 	<p>③2x2</p> 	<p>③3x2</p> 
Front panel of left cabinet and right drawer	Left side panel	Right side panel
<p>③4x2</p> 	<p>③5x2</p> 	<p>③6x2</p> 
Pull back plate	Remove the support bar	Bottom plate extraction

Board Identification
































Not actual size

37x3 	38x3 	39x3 
Front panel of right cabinet drawer	Left side panel	Right side panel
40x3 	41x3 	42x1 
Pull back plate	Bottom plate extraction	Cushion
43x2 	44x2 	45x1 
Stool side panels	Stool horizontal bar	Fixed layer board

Board Identification




Part List

 Ø6x35mm A x53(+3) Cam Bolt	 Ø15x10mm B x54(+3) Cam Lock	 Ø6x30mm C x58(+3) Dowel	 Ø4x35mm D x63 (+3) Flat Head Tapping Screw	 Ø3.5x12mm E x60(+3) Sliding Track Screw
 F x5 Couple	 Ø10mm G x4 Anti-collision sticker	 Ø15mm H x6 Foot nail	 Ø6x20mm I x2 Counter lock male screw	 Ø8x20mm J x2 Counter lock nut screw
 K x5 Handle	 Ø4x16mm L x10(+1) Handle screw	 Ø3x16mm M x30(+2) Back Buckle and screw	 N x1 The power plug	 Ø20mm O x35(+1) Hole sticker
 Ø6x30mm P x2 Plastic Expansion	 Q x1 Power supply socket	 Ø3.5x12mm R x2 Power socket screw	 S x2 Anti-Fall Strip	 Ø4x14mm T x2 Round head screw and shim
 U x2 Doorstep wheel	 V x2 Lower door wheel	 W x16(+1) Lower door screw	 X x1 Screw cover	 Y x1 Two-hole angle iron
 Z x4 Two-hole angle iron	 4x12mm Aa x8 Angle iron screws			
 L300mm CL x5 Sliding Track	 L300mm CR x5 Sliding Track	 L300mm DL x5 Sliding Track	 L300mm DR x5 Sliding Track	


Part List

Cam Lock Fastening System






Insert the cam bolt into the hole first, then insert the cam lock and lock it.





STEP 1





STEP 2









STEP 3



STEP 4
















 $\varnothing 15 \times 10 \text{ mm}$		 $\varnothing 6 \times 30 \text{ mm}$		 $\varnothing 15 \text{ mm}$	
B	x2	C	x2	H	x2









Proper orientation of CAM LOCK


STEP 5





STEP 6









Proper orientation of CAM LOCK




STEP 7









STEP 8






STEP 9



 Ø6x35mm		 Ø6x30mm		 Ø4x35mm	
A	x4	C	x2	D	x2









STEP 10







Proper orientation of CAM LOCK

STEP 11
















STEP 13



STEP 14







STEP 15












Proper orientation of CAM LOCK

STEP 16







STEP 17










Proper orientation of CAM LOCK






STEP 18



STEP 19







STEP 20





Proper orientation of CAM LOCK

STEP 21







STEP 23









STEP 25




STEP 26













STEP 29





STEP 30




STEP 31






STEP 32




STEP 33




STEP 34




(1)














(2)



(3)











STEP 35







Proper orientation of CAM LOCK


STEP 36




STEP 37




(1)




(2)









(3)




(4)




STEP 38





(1)













(2)










STEP 39








STEP 40



STEP 44



STEP 45



STEP 46

