

# Assembly Instructions

## Tools Needed For Assembly:

7/16" Wrench  
7/16" Socket  
Power Screwdriver  
#2 Square Drive Bit

## Parts List:

Table Top (1)  
Leg Columns (2)  
Table Feet (6)  
Leg Brace (1)

## Hardware:

1/4" Flange Nuts (16)  
2" Polybuster Screws (8)

- Step 1**      Unpack and identify all parts and pieces. Lay a piece of cardboard on your work table or floor to prevent scratching your table top.
- Step 2**      Set the leg columns upright with the predrilled holes toward the top. Attach the leg brace by inserting the hanger bolts on each end into a set of holes on each leg column. Fasten with four flange nuts and tighten securely with the 7/16" wrench or socket.
- Step 3**      Attach the table feet to the leg columns by inserting the bolts in the feet into the holes on the remaining three sides of the leg columns and put on the 1/4" flange nuts. Tighten securely with the 7/16" wrench or socket. **Note: The bottom of the feet need to be turned up when attaching to the leg column.**
- Step 4**      Put the table top upside down on the cardboard. Now place the other end of the leg columns into the 6" square frames on the bottom of the table top. Make sure the leg columns are seated squarely inside the frames. Fasten with the 2" screws by turning them through the predrilled holes in the poly frame. **Do not overtighten the screws or they will strip!**
- Step 5**      Set the table upright, pull up some chairs and enjoy!

