



## **Warnings and Cautions**

*Please retain this instruction for future usage and read carefully before assembly.*

*Make sure you have all the parts & hardware as item list shows.*

**3 adults or more** are recommended to install your Sunroom.

*Do not discard any of the packaging until you have checked that you have all the parts and pack of fittings.*

*Check all bolts for tightness before use, and periodically check and tighten bolts ensure your gazebo works properly.*

*Some parts might have sharp edges/corners/Please follow basic safety precautions to reduce the risk of hurts.*

**Avoid installing and settling the solarium in a corridor of heavy wind.**

*Some assembly parts contain sharp edges, you should wear protective gloves when handling these items.*

*For safety issues you must not leave the unit unattended if it is not completed, even if it is already anchored to the ground.*


*It is essential to place the gazebo on level ground and not less than **6 feet** from any obstruction such as fences, garages, overhanging branches, laundry lines, or electrical wires.*

*If you have questions or concerns.*

*Please contact us via email at **service@domioutdoorliving.com***

# Domi outdoor living


domi  
outdoor living



SKU:LGMF1617

Solarium Wall-Mounted  
Sunroom

**Assembly Manual**



164.44"


143.77"

84.13"

161.92"

139.76"

102.08"



**T**hank you for your purchase of  
*Domi outdoor living's Sunroom*

Read and follow this assembly and operation guide.

To reduce personal injury and damage to you Sunroom

We recommend a **three-person team** for assembly and disassembly.

Please **remove** snow accumulation at all times.

Please schedule enough time to complete the assembly of the sunroom.

It will takes approximately 7 hours to set up.

If you like our products, please tell other customers

If you have problem with our products, please tell us

*Please feel free to contact us.*

**DOMI OUTDOOR LIVING**

**domi**  
outdoor living


## Pre-assembly

### TOOLS THAT MAY BE REQUIRED (Not included in boxes)

\*NOTE: Tools / equipment are not shown to actual size and scale.



LEVEL




RUBBER Mallet




PHILLIPS SCREW



DRILL



ALLEN KEY



ALLEN KEY

### EQUIPMENT REQUIRED (Not included in boxes)

\*NOTE: Equipment are not shown to actual size and scale.



SAFETY HAT



GLOVES



SAFETY GOGGLES



STEPLADDER

### Matters needing attention



1. Three or more people are required for assembly.



2. Do not fully tighten screws prior to complete assembly.



### Regulation

**IMPORTANT:** A sunroom may entail to purchase a municipal permit or be subject to specific building codes. It is the consumer's responsibility to inform themselves of any restrictions.

#### Care and Cleaning:



For cleaning, use a domestic soap or detergent and wash with warm water using a sponge or fabric. Rinse with clean water.

1





**x12**

If the deck is hard wood and the depth of it is over 3 inch, you can use **5/16 in. x4 in. Structural Wood Screw** to mount the pergola.





2




If the ground is concreted and the depth of it is over 3 inch, you can use 1/4 inch expansion bolts to mount the pergola


3














Or you can make a concrete footing for pergola, **15×15×15 inches** is recommended. use expansion bolts to mount the pergola like (2) shows.



**IMPORTANT:**  
Anchor is not recommended









D<sub>2</sub> 8X




E<sub>1</sub> 4X




E<sub>2</sub> 2X




F 5X




G<sub>1</sub> 1X



G<sub>2</sub> 1X



G<sub>3</sub> 1X



G<sub>4</sub> 1X



H<sub>1</sub> 1X




H<sub>2</sub> 1X




H<sub>3</sub> 1X




H<sub>4</sub> 1X




I<sub>1</sub> 1X



I<sub>2</sub> 1X



I<sub>3</sub> 2X




I<sub>4</sub> 2X




J<sub>1</sub> 1X




J<sub>2</sub> 1X




J<sub>3</sub> 1X




J<sub>4</sub> 1X




K 2X




L1 1X




L2 1X




M1 1X




M2 1X




N1 2X




N2 2X




O1 2X




O2 2X




P 4X




Q 2X



R<sub>1</sub> 20X



R<sub>2</sub> 6X



S<sub>1</sub> 2X




S<sub>2</sub> 2X




S<sub>3</sub> 1X




S<sub>4</sub> 1X




S<sub>5</sub> 12X




T<sub>1</sub> 6X




T<sub>2</sub> 4X



U<sub>1</sub> 2X




U<sub>2</sub> 2X




U<sub>3</sub> 2X


V<sub>1</sub> 1X




V<sub>2</sub> 1X




V<sub>3</sub> 1X




V<sub>4</sub> 1X



V<sub>5</sub> 1X




V<sub>6</sub> 1X



V<sub>7</sub> 1X




V<sub>8</sub> 1X















V<sub>9</sub> 1X




V<sub>10</sub> 1X









Z<sub>5</sub> 1X




Z<sub>6</sub> 1X




Z<sub>7</sub> 8X




Z<sub>8</sub> 4X




Z<sub>9</sub> 1X




Z<sub>10</sub> 12X




Z<sub>11</sub> 4X




Z<sub>12</sub> 3X



Z<sub>13</sub> 1X



Z<sub>14</sub> 1X



Z<sub>15</sub> 1X

 1# 8 ST4. 8*13	 2# 19 M5*12	 3# 64 ST3. 5*13
 4# 276 M6*16	 5# 92 M6*28	 6# 8 M6*40
 7# 2 M6*12 (L20)	 8# 6 M6*15 (L30)	 9# 10 ST6*70
 10# 10	 11# 92 M6	 12# 2 M8*60
 13# 2 M8	 14# 2 M8	 15#


<p>16# 24</p>  <p>S3.5*19</p>	<p>17# 36</p>  <p>M5*48</p>	<p>18# 36</p>  <p>M5</p>
<p>19# 36</p>  <p>M5</p>	<p>20# 4</p>  <p>M4*50</p>	<p>21# 4</p>  <p>M4</p>
<p>22# 1</p>  <p>S8</p>	<p>23# 1</p>  <p>S13</p>	<p>24# 1</p>  <p>S4</p>
<p>25# 1</p>  <p>S6</p>	<p>26# 1</p>  <p>S3</p>	



A1 1X




A2 1X




N1 2X




4# 6X




S4 24# 1X






A3 1X



A4 1X




N2 2X




M6\*16


4# 8X




S4

24# 1X







A5 1X



A6 1X




W4 2X




M6\*16

4# 12X



S4

24# 1X






T2 4X






4# 4X





S4 24# 1X

⚠ The bracket #2 is used to fix the post against the wall. If you don't need that, please retain for future use. If you don't need this, please skip this step.



# Front Beam Assembly







B1 1X


W1 1X

1# 3X






R2 1X




M6\*16


4# 2X




S4

24# 1X





B2 1X





W2 1X

ST4.8\*13




1# 3X






R2 1X




M6\*16


4# 2X




S4

24# 1X







C 1X




4# 4X




24# 1X






D1 1X




M6\*16


4# 4X




S4

24# 1X






D2 2X



M6\*16

4#


8X



S4

24#

1X




8X

B1/B2


4#

D2



15# 1X

Use silicone sealant (part #15) to affix the gap between the two beams.





W3 1X

ST4. 8\*13




1# 2X




M5\*12

2# 1X





S4

24# 1X



# Side Beam Assembly






G1 1X




G2 1X



F 1X





M6\*16




S4

4# 10X

24# 1X






H1 1X

H2 1X



M6\*16






S4


4#

10X

24#

1X






O1 1X






O2 1X



M6\*16  
4# 4X



S4  
24# 1X






R2 2X






M6\*16

4# 4X




S4

24# 1X



# Side Beam Assembly





G3 1X




G4 1X



F 1X



M6\*16




S4



4#

10X

24#

1X








O1 1X




O2 1X



4# 4X



24# 1X






R2 2X




M6\*16

4# 4X



S4

24# 1X




G3

R2

4#

4#




G4

R2

4#

4#




R2


G3

G4

R2

# Rear Beam Assembly







I<sub>1</sub> 1X


I<sub>2</sub> 1X

F 1X

4# 12X

24# 1X






D1 1X





M6\*16


4# 4X




S4

24# 1X






D2 2X



M6\*16

4#


8X




S4


24#

1X







P 4X




4# 8X




S4 24# 1X






# Frame Assembly



M6\*16




S4

4#

6X

24#


1X






M6\*16

4# 10X




M6\*12 (L20)

7# 2X




M6\*15 (L30)

8# 6X





S4



24# 1X




S6

25# 1X





M6\*16



S4

Q


2X


4#

2X

24#

1X






M6\*40

6#


8X



S4


24#



1X




2X


# Two Central Beam Assembly






2X






D1 2X





M6\*16


4# 8X



S4

24# 1X






D2 4X



M6\*16

4#



16X




S4

24#


1X



2X



M6\*16




S4


4#

4X

24#

1X






J1 1X



J2 1X


K 1X

M5\*12 2# 8X


S4 24# 1X









T1 6X




M6\*16  
4# 14X




S4  
24# 1X






V1 1X



V3 1X




V5 1X



V7 1X




V9 1X







L1 1X





M6\*16  
4# 2X




S4  
24# 1X







⚠ The notch of #V8 & V10 is facing inward.





L2 1X




M6\*16  
4# 2X




S4  
24# 1X






Y1 1X




X 2X



M6\*28  
5# 2X



11# 2X





S4  
24# 1X




S13

23# 1X






Y<sub>2</sub> 6X



X 18X




5#

M6\*28



11#

18X




S4


24# 1X




S13

23# 1X






Y1 1X



X 3X




M6\*28

5# 3X



11# 3X




S4





24# 1X



S13





23# 1X






**silicone sealant application**


- (1) Apply 3 mm wide silicone sealant to the first row of roof panels as shown.
- (2) Install the second row of roof panels and fix the screws.




Repeat above procedures to assemble the third row of roof panels.




M1 1X




M2 1X




4# 6X




24# 1X







Z11 4X



R1 8X




**⚠ ATTENTION:** The orientation of Screen Panel #Z11.







E1 1X




E2 1X





**⚠ ATTENTION:** The orientation of Part #E1 & #E2 when assembling.




Z12 3X




R1 6X



**⚠ ATTENTION:** The orientation of Screen Panel #Z12.



Z4 1X




Z9 1X



M5\*12

2# 2X






Z3 1X



Z5 1X



Z6 1X







Z7 4X



ST3.5\*13



3# 32X





⚠ ATTENTION: The orientation of Part #R1.

R1 2X







S3 1X



S4 1X






17# 12X




18# 12X




19# 12X









S5 2X




St3.5\*19


16# 4X






Z15 1X








S5 2X



16# 4X







E1 1X



E2 1X




**⚠ ATTENTION:** The orientation of Part #E1 & E2 when assembling.



M6\*16

4#


28X



S4

24#

1X






Z<sub>1</sub> 1X



Z<sub>2</sub> 1X



Z<sub>3</sub> 2X






Z<sub>7</sub> 4X



ST3. 5\*13



3# 32X







⚠ ATTENTION: The orientation of Part #R1.



R1 4X





Z10 4X








S5 4X




ST3.5\*19


16# 8X

Z7




S1/S2






Z13 1X



Z14 1X







S5 4X




ST3.5\*19

16# 8X






Z8 4X



M4\*50  
20# 4X





M4  
21# 4X



S3  
26# 1X




S8  
22# 1X






E1 2X




⚠ ATTENTION: The orientation of Part #E1.




M6\*16


4#

16X







U<sub>1</sub> 2X




U<sub>3</sub> 2X




2X





U2

2X




12#

2X





13#

2X






14#

2X




⚠ The two support tubes can strengthen the weight capacity of the metal roof. In bad weather, especially snowstorm, they are essentially needed to prevent the roof from collapsing under heavy snow. In daily life, you can put them away.






ST6. 0\*70

9# 10X




10# 10X

⚠ Install this step if you need fix the canopy to the wall (you need to drill holes into the wall). Otherwise please skip this step.



M<sub>1</sub>/M<sub>2</sub>




A<sub>3</sub>/A<sub>4</sub>

T<sub>2</sub>

A<sub>3</sub>/A<sub>4</sub>

T<sub>2</sub>

10#



# Care and Cleaning

Wash frame part with mild soap and water, rinse thoroughly.

Do not use bleach, or other solvents on the frame parts.

Please check periodically that the sunroom is anchored properly to the floor or ground to enjoy its safe usage.

Please check periodically that all screws are tight to maintain the solidity of the structure.

Please remove any snow accumulation at all times.

# Warranty

## Frames

Frames constructions are warranted to be free from defects in material and workmanship for 1 year from item purchased. Damage to frame from negligence won't be covered by this warranty.

## Bolts & nuts

Bolts and nuts are warranted to be free from defects in material and workmanship for 1 year from item purchased. Damage from exposure to chemicals (including not only oils ,spills, fluids) won't be covered by this warranty.

## Warranty Limitation

This warranty is for the original purchase order only. (Order number required). This warranty is non-transferable. Domi outdoor living is responsible for the free replacement part including shipping charges for the 1 year warranty.

## Warranty Exclusion

This warranty does not cover products subject to negligence, abuse usage, inappropriate installation. Domi outdoor living reserves the right to explain warranty exclusions. When the replacement item is applied, the 1 year warranty automatically expires. Please feel free to contact us for applying warranty.



RESORT COMFORT IN YONR  
OWN BACKYARD

**Support:**



**Business cooperation contact email:**

[marketing@domioutdoorliving.com](mailto:marketing@domioutdoorliving.com)

**After-sales contact email:**

[service@domioutdoorliving.com](mailto:service@domioutdoorliving.com)

Please tell us your order ID when contact.

Attach photos of damaged part for instant reply.