


# DRESSER

Assembly Instructions - Please keep for future reference

N707P170347



## Dimensions

Width-59inch

Depth-15.7inch+11inch

Height-54inch

**Important – Please read these instructions fully before starting assembly**

Issue 1 - 05/05/24



# Safety and Care Advice

**Important – Please read these instructions fully before starting assembly**

- Check you have all the components and tools listed on the following pages.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.

- During assembly do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Parts of the assembly will be easier with 2 people.



power drill is set on a low torque setting.

- To reduce the likelihood of damaging your product please ensure that your

## Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

## Handy Hints

- Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts
- Regularly check and ensure That all bolts and fittings are tightend properly.

## WARNING

**In order to help prevent overturning – please follow these instructions**

To help prevent product toppling over please follow the below steps:-

Use the anti tip strap or wall fixing method provided (if applicable)  
Do not allow children to climb or hang on the furniture  
Do not open more than one drawer at a time  
Do not place heavy items in the top drawers  
Do not place heavy items on top of the furniture, unless the furniture has been designed for this purpose

Please note that only the anti tip strap is provided.




















You will need to provide wall plugs and screws applicable for your wall type




# Components - Fittings

Please check you have all the panels listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

<p><b>A</b></p>  <p>Cam Bolt x44</p>	<p><b>B</b></p>  <p>Cam Lock x44</p>	<p><b>C</b></p>  <p>3.5*14 Screw x48</p>	<p><b>D</b></p>  <p>6*40 Screw x21</p>
<p><b>E</b></p>  <p>6*20 Screw x2</p>	<p><b>F</b></p>  <p>Wooden sales x30</p>	<p><b>G</b></p>  <p>handle x5</p>	<p><b>H</b></p>  <p>4*18 Screw x10</p>
<p><b>I</b></p>  <p>Plate sales x8</p>	<p><b>J</b></p>  <p>Hinge x4</p>	<p><b>K</b></p>  <p>4*35 Screw x12</p>	<p><b>L</b></p>  <p>The power plug x1</p>
<p><b>M</b></p>  <p>Prevent falling accessories x1</p>	<p><b>CL</b></p>  <p>Runner300mm x3</p> <p><b>CR</b></p>  <p>Runner300mm x3</p>	<p><b>DL</b></p>  <p>Runner300mm x3</p> <p><b>DR</b></p>  <p>Runner300mm x3</p>	<p><b>6-point screwdriver</b></p>  <p>6-point screwdriver x1</p> <p><b>bolt driver</b></p>  <p>bolt driver x1</p>

Ruler - Use this ruler to help correctly identify the screws




**EN\_** It may be necessary to adjust the hinges so that the doors align. Use the instructions below as a guide.

**FR\_** Il est parfois nécessaire d'ajuster les charnières pour un meilleur alignement des portes. Servez-vous des instructions ci-dessous comme guide.

**ES\_** Puede que sea necesario ajustar los quicios de forma que se alineen las puertas. Use las instrucciones que aparecen debajo como guía.

**DE\_** Möglicherweise müssen Sie die Scharniere so einstellen, dass die Türen ausgerichtet sind. Verwenden Sie die nachstehenden Anweisungen als Leitfaden.

**IT\_** Potrebbe essere necessario regolare le cerniere in modo che le porte siano allineate. Per fare ciò attenersi alle istruzioni sottostanti.




**EN\_** To adjust the door vertically loosen the screw as shown and move up and down as needed.

**FR\_** Si vous souhaitez régler la porte **verticalement**, desserrez la vis comme indiqué et déplacez la porte de haut en bas selon les besoins.

**ES\_** Para ajustar la puerta **verticalmente** afloje el tornillo tal y como se muestra y muévelo hacia arriba o hacia abajo según sea necesario.

**DE\_** Um die Tür **vertikal** auszurichten, lösen Sie die Schraube wie abgebildet und bewegen Sie sie nach Bedarf nach oben oder nach unten.

**IT\_** Per allineare la porta **verticalmente** allentare la vite come mostrato e spostarla in alto o in basso secondo necessità.




**EN\_** To adjust the gap from the door to the main frame turn the screw clockwise or anti-clockwise as needed.

**FR\_** Si vous souhaitez ajuster l'**écart** entre la porte et le cadre principal, tournez la vis dans le sens des aiguilles d'une montre ou dans le sens inverse, si nécessaire.

**ES\_** Para ajustar el **espacio** desde la puerta al marco principal, gire el tornillo en sentido horario o antihorario, según se necesite.

**DE\_** Um den **Abstand** von der Tür zum Hauptrahmen auszurichten, drehen Sie die Schraube je nach Bedarf im oder gegen den Uhrzeigersinn.

**IT\_** Per regolare lo **spazio** tra la porta e il telaio principale, avvitare o svitare la vite secondo necessità.




**EN\_** To adjust the door laterally adjust the screw as shown by turning clockwise or anti-clockwise.

**FR\_** Si vous souhaitez ajuster la porte **latéralement**, ajustez la vis comme indiqué en tournant dans le sens des aiguilles d'une montre ou dans le sens inverse des aiguilles d'une montre.

**ES\_** Para ajustar la puerta **lateralmente** ajuste el tornillo tal y como se muestra girándolo en sentido horario y antihorario.

**DE\_** Um die Tür **seitlich** auszurichten, stellen Sie bitte die Schraube wie abgebildet durch Drehen im oder gegen den Uhrzeigersinn ein.

**IT\_** Per allineare la porta **lateralmente** regolare la vite come mostrato, avvitandola o svitandola.



**EN\_** Please fix other screws

**FR\_** Merci de serrer les autres vis.

**ES\_** Fije los demás tornillos

**DE\_** Befestigen Sie bitte die anderen Schrauben

**IT\_** Fissare le altre viti


# Using Camlocks

## Step 1

Connect the male camlock as directed in the assembly instructions using a screwdriver.

1


DO NOT OVER TIGHTEN.  
NE PAS SERRER EXCESSIVEMENT.



## Step 2

Push the male camlock into the entry hole.

2




## Step 3

Insert the female camlock as shown in the instruction.

Note: ensure that the arrow on the top of the camlock points towards the entry hole for the male camlock.

3




## Step 4

Turn the female camlock clockwise with a screwdriver.




You should feel a click when the camlock is locked in place.

The joint is now secure.

4





## Tools required

















Screwdrivers can be converted to Phillips and Slotted.















# Assembly Instructions



# Assembly Instructions










<p>①</p>  <p>706*390*15mm</p> <p>1</p>	<p>⑧</p>  <p>300*168*15mm</p> <p>3</p>
<p>②</p>  <p>354*232*15mm</p> <p>2</p>	<p>⑨</p>  <p>215*168*15mm</p> <p>3</p>
<p>③</p>  <p>mm</p> <p>1</p>	<p>⑩</p>  <p>295*225*3mm</p> <p>3</p>
<p>④</p>  <p>700*233*15mm</p> <p>2</p>	<p>⑪</p>  <p>716*244*3mm</p> <p>2</p>
<p>⑤</p>  <p>800*390*15mm</p> <p>1</p>	<p>⑫</p>  <p>716*280*3mm</p> <p>1</p>
<p>⑥</p>  <p>292*231*15mm</p> <p>3</p>	<p>⑬</p>  <p>706*373*15mm</p> <p>1</p>
<p>⑦</p>  <p>300*168*15mm</p> <p>3</p>	<p>⑭</p>  <p>706*390*15mm</p> <p>1</p>

# Assembly Instructions

<p>⑮</p> <p>736*100*15mm</p>  <p>1</p>	<p>⑳</p> <p>100*58*15mm</p>  <p>1</p>
<p>⑯</p> <p>736*358*15mm</p>  <p>1</p>	<p>㉑</p> <p>100*58*15mm</p>  <p>1</p>
<p>⑰</p> <p>358*84*15mm</p>  <p>3</p>	<p>㉒</p> <p>768*78*15mm</p>  <p>1</p>
<p>⑱</p> <p>373*10mm</p>  <p>3</p>	<p>㉓</p> <p>42.5*58*15mm</p>  <p>2</p>
<p>⑲</p> <p>800*390*15mm</p>  <p>1</p>	<p>㉔</p> <p>42.5*78*15mm</p>  <p>2</p>
<p>㉀</p> <p>800*390*40mm</p>  <p>1</p>	<p>㉕</p> <p>736*100*15mm</p>  <p>1</p>
<p>㉁</p> <p>800*58*15mm</p>  <p>1</p>	<p>㉖</p> <p>800*600*15mm</p>  <p>1</p>


# Assembly Instructions


## Step 1




# Assembly Instructions



## Step 2



CL  Runner 300mm x 3	CR  Runner 300mm x 3	C  3.5*14 Screw x12
---	---	--

## Step 3









D  6*40 Screw x8	F  Wooden sales x8
---	---



# Assembly Instructions



## Step 4






<p>B</p>  <p>Cam Lock x8</p>	<p>F</p>  <p>Wooden sales x8</p>
---	---

# Assembly Instructions

## Step 5




## Step 6



# Assembly Instructions

## Step 7





B



Cam Lock x12


# Assembly Instructions

## Step 8



# Assembly Instructions


## Step 9




<p>B</p>  <p>Cam Lock x6</p>	<p>F</p>  <p>Wooden sales x2</p>	<p>D</p>  <p>6*40 Screw x3</p>
---	---	---

# Assembly Instructions

## Step 10





D



6\*40 Screw x10

# Assembly Instructions

## Step 11





E







6\*20 Screw x2

# Assembly Instructions

## Step 12







<p>C</p>  <p>3.5*14 Screw x16</p>	<p>G</p>  <p>handle x2</p>	<p>H</p>  <p>4*18 Screw x4</p>	<p>J</p>  <p>Hinge x4</p>
--	---	---	--



# Assembly Instructions

## Step 13








<p>C</p>  <p>3.5*14 Screw x8</p>	<p>L</p>  <p>The power plug x1</p>	<p>M</p>  <p>Prevent falling accessories x1</p>
---	---	--


# Assembly Instructions

## Step 14

### WALL




After the cabinet assembly, please install the wall fixing device on the back of the cabinet to avoid accidents. Install at a location based on your needs.




# Assembly Instructions

## Step 15




WALL



# Assembly Instructions

## Step 16



<b>B</b>  Cam Lock x12	<b>C</b>  3.5*14 Screw x12	<b>G</b>  handle x3	<b>H</b>  4*18 Screw x6
<b>K</b>  4*35 Screw x12	<b>DL</b>  Runner300mm x3	<b>DR</b>  Runner300mm x3	

# Assembly Instructions

## Step 17

