


Mass: 56.4 kg



Follow and Tag Us: @shiregardenbuildings

Batch No: 6580

© Overlap 3x5 SD Value



**These instructions are for your safety. Please read through them thoroughly before use.
PLEASE KEEP THIS LEAFLET FOR FUTURE REFERENCE**

Let's get started...

Important information...



Safety	03
Preparation of base	04
Warranty	04
Care, maintenance & Recycling	05

In more detail...



Parts List	06
Fascia & Nail List	07
Detailed Technical Drawing	08-09
Hardware Chart	10
Before You Start	11
Assembly instructions	12-23

Like us, Follow us, Recommend us & Tag us



Shire Garden Buildings



@shiregardenbuildings



Shire Garden Buildings



customerservice@shiregb.co.uk



Brigstock Road Wisbech Cambridgeshire PE13 3JJ
Tel 01945 465 295

Safety

Check that you have noted all the following instructions:



- We advise the use of non slip protective gloves throughout the assembly process.
- We advise the use of steel capped protective footwear throughout the assembly process.
- We advise that you use a helper to hold the glass in position whilst you nail the beading in place.
- We advise the use of protective headwear and safety goggles throughout the assembly process.
- Where a ladder is in use another person must hold the ladder.
- Do not attempt to work in windy conditions.
- We advise the use of a scaffold tower when fitting the roof, for felting or if you cannot reach from the ground.
- Do not allow children near the tools and work area.
- Follow any safety precautions quoted by the manufacturer for any equipment you use.
- Check all parts before assembly.
- Only use child and animal safe wood preservative.
- Do not use creosote.
- Allow the wood preservative to fully dry before use.
- Regularly check the building for wear and tear.

Important!

EVERY PRECAUTION IS TAKEN TO ENSURE THAT YOUR BUILDING HAS NO ELEMENT INCORRECTLY PLACED OR POSSIBLY HAZARDOUS, HOWEVER PRIOR TO USE PLEASE CHECK ALL SURFACES FOR THE FOLLOWING:

- (1) RAISED GRAIN, SPLINTERS: Sand down timber to smooth finish
- (2) NAIL/SCREW/PIN HEADS PROUD: Tap home to be flush with surface of timber.
- (3) DAMAGED SCREW HEADS RESULTING IN SHARP SPLINTERS OF METAL: Replace.
- (4) SHARP ENDS OF NAILS/ SCREWS/ PINS PROTRUDING THROUGH THE PANEL: Remove and reposition.
- (5) ENSURE ALL PARTS ARE SECURED AGAINST REASONABLE FORCE: Remove and refit.
- (6) ENSURE THERE ARE NO LOOSE PARTS: Remove and refit/discard.



IMPORTANT ! For your safety please read carefully the safety warnings

Preparation of base...

We recommend that the base onto which your building will stand should be at least 75mm larger in each direction than the total floor size of the building.

- **Actual floor area of the building:** 990mm x 1618mm
- **Total height clearance:** 1834mm
- **Roof size:** 1146mm x 1645mm

The chosen position in your garden for your building should be excavated to a depth of 75mm to allow a base of sand, on to which paving slabs can be evenly laid. You may also use an adjustable timber base or a concrete base. Whatever base you decide upon IT MUST BE LEVEL AND FIRM.

Warranty...

10 Year anti rot warranty subject to the following:

- The building must be raised so it is not in contact with any water retaining base surface (for example grass).
- This can be achieved using a timber, concrete or slab base.
- When using a concrete or slab base use damp proofing strips under the bearers.
- The building must have been completely treated and sealed prior to assembly.
- The building must have been re-treated and re-sealed annually.

NOTE: Wood is a natural product, and therefore the following are excluded from the warranty:

- Colour change.
- Warping.
- Splitting.

The following are also excluded:

- Damage resulting from poor assembly.
- Poor treatment application.
- Poor care and maintenance.
- Changes to the design.
- Misuse.
- General wear and tear.

Building Photographs

It will be greatly appreciated if you could forward images of your completed building to -

sales@shiregb.co.uk.

Care, Maintenance and Recycling

The 5 golden rules of care:

- (1) Ensure your base is level and firm.
- (2) Ensure the building is not sitting directly on the ground using damp proof membrane or the optional timber base.
- (3) Ensure every piece of timber and surface, especially that is hidden upon assembly, is treated with a top quality wood preservative at least twice (before assembly). Turn the panels upside down whilst painting so the treatment runs into the seams.
- (4) Garden buildings are not waterproof, therefore you must seal between all the panels with a silicone based sealant.
- (5) Regularly check your roofing felt for weather damage and leaks.

The 6 golden rules of maintenance:

- (1) Visually check for weather damage.
- (2) Check and replace if necessary any Silicone sealant if used on your building.
- (3) Check the roofing material for wear.
- (4) The doors and windows may require periodical adjustment.
- (5) Ensure your building is well ventilated especially during hot weather.
- (6) During extremely hot periods humidify your building to prevent the timber from drying out.

Recycling and disposal:



packaging

1. Pallet and timber widely recycled.
2. Cardboard widely recycled.
3. Plastic strapping subject to local regulations.
4. Plastic sheeting subject to local regulations.




Building


1. Timber widely recycled.
2. Metal fixings widely recycled.
3. Glass widely recycled.
4. **Roofing felt not currently recycled.**

Stacked Parts List


FLOOR PANEL
(A5547)x01




PLAIN PANEL 809
(A5549)x04




PLAIN PANEL 922
(A5550)x01




GABLE
(A5551)x02




OSB 821x610
(A5553)x04




34x34x1642
(A5631)x02




34x34x1617
(A5632)x02




RUSTIC DOOR
(A5555)x01




34x34x922
(A5556)x01



FELT STRIP 1.7M
(A0499)x02




RUSTIC COVERSTRIP 12X48X1560
(A1378)x06




Fascia and Nail Bag Parts List

DOOR STOP 12X21X922
(A5557)x01




A 3D perspective view of a rectangular door stop. The top surface is labeled with a width of 21 and a length of 922. The height of the stop is 12.

DOOR STOP 12X21X1496
(A5558)x02




A 3D perspective view of a rectangular door stop. The top surface is labeled with a width of 21 and a length of 1496. The height of the stop is 12.

RUSTIC COVERSTRIP
12X48X685
(A5559)x04




A 2D top view of a rustic coverstrip. It features a central notch. The overall width is 663, and the length of the strip is 685.

DIAMOND
(A0019)x02




A 2D top view of a diamond-shaped fastener.

TEE HINGE
(A0049)x03





A 2D top view of a tee hinge. It consists of a horizontal base with three screws and a vertical stem with two screws.

HASP AND STAPLE
(A0123)x01



A 2D top view of a hasp and staple fastener. It has a rounded end with a slot and a rectangular end with a hole.






In more detail.....

Hardware Chart Scale 1:1


8mm Felt Nail
(A0266) x84




40mm Round head nail
(A0025) x69



25mm Posi-drive screw
(A0032) x26



60mm Posi-drive screw
(A0035) x29





Before you start...

Things to check before you start:

- ✓ Ensure your base is ready – See page 4.
- ✓ Check all parts as listed in the parts lists.
- ✓ Read the instructions fully before starting work.
- ✓ Follow all the health and safety guidelines.



When you see the drill icon
Only ever drill through the first piece of framework which will be a pilot hole for the screw to attach the second piece of framework
The required drill bit size is shown with the icon.



You will need:




- Hammer



- Spirit level




- Ladder




- 1mm 3mm 5mm 8mm drill bit



- Drill



- Tape measure & Ruler




- Sand paper



- Gloves




- Saw




- Pencil



- Goggles



- A helper for some tasks



- Screwdriver



- Sharp knife



- Masking tape

Assembly instructions:

These instructions are for your safety. Please read through them thoroughly before use.
Treat all the parts before assembly – see page 5!

GB-IE


The "Panel Layout" is showing you how the panels go together.

The Plain Panel 922 FITS INSIDE THE PLAIN PANELS 809!


01




Rustic Door
(A5555)x01



Tee Hinge
(A0049)x03




25mm Screws
(A0032)x12



DOOR CAN BE
LEFT OR
RIGHT HAND
HUNG

DOOR CAN BE
LEFT OR
RIGHT HAND
HUNG

HINGE OVER
DOOR
FRAMEWORK



INSIDE VIEW
GAP

GB-IE

Fix the **Tee Hinges (A0049)** as shown so the **25mm Screws (A0032)** go into the horizontal framework on the back of the **Rustic Door (A5555)**.

Ensure the hinge is over the framework gap on the back of the door.



12

Carefully put the **Floor Panel (A5547)** onto your chosen **base**.
Drill two **Plain Panels 809 (A5549)** and the **Plain Panel 922 (A5550)** as below, making sure the bottom hole in the 922 panel is inline with the floor bearers.


Place the two 809 panels into the corner of the floor so that the cladding overlaps, secure them together using 3x **60mm Screws (A0035)** using the pilot holes drilled.

Push the 922 panel up to the 809 panel and secure with 3x **60mm Screws (A0035)** as below.


02




NOTE
Some holes drilled for later use




Floor Panel (A5547)x01




Plain Panel 809 (A5549)x02



Plain Panel 922 (A5550)x01






60mm Screws (A0035)x06



Inline with floor bearer




DO NOT
FIX WALLS TO
FLOOR
UNTIL ASKED




Drill the last two **Plain Panels 809 (A5549)** as below.
Place onto your building and secure with 3x **60mm Screws (A0035)** using the pilot holes drilled.



03







Plain Panel 809
(A5549)x02



60mm Screws
(A0035)x06




NOTE
Some holes
drilled for
later use




**DO NOT
FIX WALLS TO
FLOOR
UNTIL ASKED**

Place the **Gables (A5551)** onto the building as below.
 Make sure the framework is flush with the wall panel framework.
 Secure the back gable with 4x **60mm Screws (A0035)**.
 Secure the front gable with 2x **60mm Screws (A0035)** as below.



04





**Gable
(A5551)x02**




**60mm Screws
(A0035)x06**



SECURE 2
SCREWS IN
EACH SIDE
FOR THE
BACK GABLE




SECURE 1
SCREW IN
EACH SIDE
FOR THE
FRONT GABLE




GB-IE Fix the Rustic **Coverstrips 12x48x1560 (A1378)** to the corners and panel joins of your building.
Secure each coverstrips with 4x **40mm Nails (A0025)**.


05



Coverstrip 12x48x1560 (A1378)x06




40mm Nails (A0025)x24




GB-IE Drill and screw the **34x34x922 (A5556)** piece underneath the front gable, making sure the cladding is facing forward and framework is flush the gable framework.
Use 2x **60mm Screws (A0035)**.


06



34x34x922 (A5556)x01




60mm Screws (A0035)x02




Fit the **Door Stop 12x21x922 (A5557)** and the **Door Stop 12x21x1496 (A5558)** with 3x **40mm Nails (A0025)** in each piece.
Make sure the Door Stops are flush with the edge of the framework, not the coverstrips.


07




Door Stop 12x21x922 (A5557)x01



Door Stop 12x21x1496 (A5558)x02



40mm Nails (A0025)x09




FLUSH WITH INSIDE FRAEWORK AND **NOT** COVERSTRIPS


BACKWALL REMOVED FOR CLARITY

GB-IE Use a helper to fit the **Rustic Door (Step 01)** within the building.
Secure the hinges to the coverstrips with 3x **25mm Screws (A0032)** in each.
Make sure the door can open and close properly.
Tip: Use coins or something similar as packing underneath the doors to help level them out.


08



Rustic Door
(Step 01)x01




25mm Screws
(A0032)x09




SECURE TO
COVERSTRIPS

GB-IE Fix the **Hasp and Staple (A0123)** as shown below, using **5x 25mm Screws (A0032)**.
Align them up and mark before fixing to make sure they meet together.


09



Hasp and Staple (A0123)x01




25mm Screws (A0032)x05





GB-IE Make sure everything is square and true.
Fix the walls to the floor using **60mm Screws (A0035)**.

10




60mm Screws (A0035)x05




To assemble the Roof Panels, place 2x **OSB 821x610 (A5553)** panels flat and fix the **34x34x1642 (A5631)**, which runs the full length of the Roof Panels along one side and nail with 4x **40mm Nails (A0025)**. Fix the **34x34x617 (A5632)**, which should sit **12mm** in from the edge on the other side. Repeat with the other panel, making sure you have two opposite panels.


11




OSB 821x610 (A5553)x04






34x34x1642 (A5631)x02



34x34x1617 (A5632)x02



40mm Nails (A0025)x16




OPPOSITES




GB-IE Place the first **Roof Panel (Step 11)** onto the building. Drill and fix with 1x **60mm Screw (A0035)** into the Gable at each end as below. Nail with 2x **40mm Nails (A0025)** along the sides of the building, making sure the nails go into the walls. Repeat with the second panel.


12





OSB 821x610 (Step 11)x04



60mm Screws (A0035)x04






40mm Nails (A0025)x04



2 Strips of **1.7M Felt (A0499)** have been supplied.
Fit the first strip of felt as below, so there is an even overhang front and back, pull tight and nail at approximately **100mm** apart. Repeat with the other strip.




13



Felt Strip 1.7M (A0499)x02




8mm Felt Nails (A0266)x84




Fix the **Rustic Coverstrip 12x48x685 (A5559)** with 3x **40mm Nails (A0025)** in each piece as below.

Then fix the **Diamonds (A0019)** in the centre with 2x **40mm Nails (A0025)** in each.


14



Rustic Coverstrip
12x48x685
(A5559)x04



Diamond
(A0019)x02



40mm Nails
(A0025)x16

