




12'x18' Metal Patio Gazebo

ASSEMBLY MANUAL



MODEL#: LGMF1672

Missing part? Damaged? Contact us via email at

service@domioutdoorliving.com

www.domioutdoorliving.com

Pre-assembly



1. Two or more people are required for assembly.



2. You will need one or more stepladders.



3. Wearing protective gloves is recommended.



4. You may need a safety hat.



5. Please use a Phillips screw driver.



6. For ease of construction, you may need a drill.



7. You may need a safety goggle.



8. Do not fully tighten screws prior to complete assembly.

Warning & Attention




-Try to assemble this product on the flat ground, otherwise it is difficult to carry out;

-It would be much easier to assemble the product with three or more people;



-After assembly, please check whether all screws are tightened, to prevent parts from falling apart.

▲ Use bolts to secure the frame to the ground to against the strong wind.

IMPORTANT: A gaze may entail to purchase a municipal permit or be subject to specific building codes. It is the consumer's responsibility to inform themselves of any restrictions.





1




x20

If the deck is hard wood and the depth of it is over 3 inch, you can use **5/16 in. x4 in. Structural Wood Screw** to mount the gazebo.




2




If the ground is concreted and the depth of it is over 3 inch, you can use 1/4 inch expansion bolts to mount the gazebo



















3







































Or you can make a concrete footing for gazebo, **15×15×15 inches** is recommended. use expansion bolts to mount the pergola like ② shows.


IMPORTANT:
Anchor is not recommended



 <p>Pole 2080MM A (x4)</p>	 <p>Track 814MM D2 (x2)</p>
 <p>Pole 2080MM B (x2)</p>	 <p>Track 814MM D3 (x2)</p>
 <p>Beam 1715MM C (x2)</p>	 <p>Outside Roof Cover E1 (x1)</p>
 <p>Beam 1715MM C1 (x2)</p>	 <p>Union Bar 600MM E (x6)</p>
 <p>Beam 1800MM C2 (x2)</p>	 <p>Corner Cover F (x4)</p>
 <p>Beam 1715MM C3 (x2)</p>	 <p>Joint Cover G (x6)</p>
 <p>Beam 1715MM C4 (x2)</p>	 <p>Silicone Sealant H (x1)</p>
 <p>Track 1583MM D (x4)</p>	 <p>Corner Solidifying Bar 578MM I1 (x4)</p>
 <p>Track 1583MM D1 (x4)</p>	 <p>Corner Solidifying Bar 578MM I2 (x4)</p>


 <p>Inside Roof Cover</p> <p>1989MM</p> <p>J (x1)</p>	 <p>Roof Tube</p> <p>1905MM</p> <p>N2 (x2)</p>
 <p>Base</p> <p>K (x4)</p>	 <p>Finishing Bar</p> <p>740MM</p> <p>P (x2)</p>
 <p>Base Cover</p> <p>K1 (x4)</p>	 <p>Finishing Bar</p> <p>1285MM</p> <p>L1 (x2)</p>
 <p>Bracket</p> <p>K2 (x8)</p>	 <p>Finishing Bar</p> <p>1285MM</p> <p>L2 (x2)</p>
 <p>Base</p> <p>K3 (x2)</p>	 <p>Finishing End</p> <p>Q (x8)</p>
 <p>Corner Roof Tube Connector</p> <p>690MM</p> <p>M (x4)</p>	 <p>Finishing End</p> <p>Q1 (x2)</p>
 <p>Corner Roof Tube</p> <p>2130MM</p> <p>M1 (x4)</p>	 <p>Black Rubber</p> <p>S (x148)</p>
 <p>Roof Tube</p> <p>1927MM</p> <p>N (x2)</p>	 <p>Finishing Bar</p> <p>1021MM</p> <p>T (x2)</p>
 <p>Roof Tube</p> <p>1927MM</p> <p>N1 (x4)</p>	 <p>Finishing Bar</p> <p>1424MM</p> <p>T1 (x2)</p>

 <p>Finishing Bar 1424MM</p> <p>T2 (x2)</p>	 <p>Hooks</p> <p>R1 (x3)</p>
 <p>Solidfying Bar 1085MM</p> <p>U1 (x4)</p>	 <p>x1</p>
 <p>Solidfying Bar 1085MM</p> <p>U2 (x4)</p>	 <p>x1</p>
 <p>Bracket</p> <p>U3 (x4)</p>	 <p>x1</p>
 <p>Bracket</p> <p>U4 (x6)</p>	 <p>Plastic Clips</p> <p>Z (x72)</p>
 <p>Solidfying Bar 1758MM</p> <p>U5 (x2)</p>	 <p>Plastic Clips</p> <p>Z1 (x4)</p>
 <p>Mesh</p> <p>O (x1)</p>	 <p>Plastic Clips</p> <p>Z2 (x4)</p>
 <p>Plastic Bar 1240MM</p> <p>O1 (x4)</p>	 <p>Plastic Clips</p> <p>Z3 (x4)</p>
 <p>Plastic Bar 620MM</p> <p>O2 (x2)</p>	 <p>Plastic Clips</p> <p>Z4 (x4)</p>




M6x16

1#
x259



M6x25

10#
x4



M6x20

2#
x36




M6x12

11#
x16




3#
x16




ST6.3*15

12#
x4




4#
x144




M6x28

5#
x92



M6x45

6#
x8



M6x50

7#
x44
































M5x16

8#
x6







ST4.8 x13

9#
x28





POST ASSEMBLY:






(1) Put on Base Cover
#K1 first;


(2) Attach Base #K to
Pole #A with 3 Bolts
#1.




(1)



(2)



X4




K3 (X2)



1#
x 8



B (X2)


(3) Attach the Base #K3 to Pole #B with 4 bolt 1#.



B

X2





D (x4)


D1 (x4)



4#
x112


(1) Slide the Plastic Hooks #4 to the double-rail track #D (each slot should slide 7 plastic hooks).


(2) Repeat the above procedures for the other 3 tracks D.



(1) Slide the Plastic Hooks #4 to the double-rail track #D1 (each slot should slide 7 plastic hooks).


(2) Repeat the above procedures for the other 3 tracks D1.






(1) Slide the Plastic Hooks #4 to the double-rail track #D2 (each slot should slide 4 plastic hooks).



(2) Repeat the above procedures for another track D2.




(1) Slide the Plastic Hooks #4 to the double-rail track #D3 (each slot should slide 4 plastic hooks).

(2) Repeat the above procedures for another track D3.






BEAM ASSEMBLY









- (1) Insert Part #E into Part #C4, and secure with 4 Bolts #1.
- (2) Insert the other side of Part #E into Part #C and secure with 4 Bolts #1.

Repeat the above procedures to assemble the other Part #C4 and #C.




TIPS: It's a normal situation that there's a gap between the 2 beams, please use silicone sealant (part #H) and Joint Cover #G to affix the gap.(see P14)







- (1) Insert Part #E into Part #C1, and secure with 4 Bolts #1.
- (2) Insert the other side of Part #E into Part #C2 and secure with 4 Bolts #1.

Repeat the above procedures to assemble the other Part #C1 and #C2.




- (3) Insert Part #E into Part #C3, and secure with 4 Bolts #1.
- (4) Insert the other side of Part #E into Part #C2 and secure with 4 Bolts #1.

Repeat the above procedures to assemble the other Part #C3 and #C2.



(1) Use 14 Bolts #1 to fix the track D ,D3,D2& D1 to the beam C1,C2 & C3.


Repeat the above procedures for another beam C1,C2 & C3.



X2





2#
x16




3#
x16

FRAME ASSEMBLY:



Inside View




Outside View


Please don't tighten
all bolts.




2#
x12



Please don't tighten
all bolts.





Inside View



Inside View

CORNER SOLIDIFYING
BAR ASSEMBLY:



Outside View







F x4






9#
x16





CORNER COVER & JOINT COVER ASSEMBLY:





Use 5mm silicone sealant(part #H) and Joint Cover #G to affix the gap.






INSIDE VIEW



M (x4)




M1 (x4)




2#
x8

CORNER ROOF TUBE ASSEMBLY:





(1) Connect Part #M1 and Part #M with 2 Bolts #2.
Repeat the above procedures to assemble the
other 3 Corner Roof Bars.




J (x1)

CORNER ROOF TUBE AND INSIDE ROOF CONNECTOR ASSEMBLY:






Place 4 Corner Roof Tubes on the 4 corners of Inside Roof Cover #D1,secure with 8 Bolts #1 (from bottom to top).




Lift 4 corner roof Tubes and inside roof connector to the top of the frame.(You may need 2 people and 2 ladder).




1#
×4





Secure with 4 Bolts #1.



1#
x24




BOTTOM VIEW




INSIDE VIEW


MIDDLE ROOF TUBE ASSEMBLY:




Check the the frame as pictures below shows.



Frames in Parallelogram shape



Frames in rectangular shape



O (x1)





O1 (x4)




O2 (x2)

PLASTIC BAR ASSEMBLY:



Align the holes






E (x1)






R1 (x3)

OUTSIDE ROOF COVER AND MESH ASSEMBLY :


- (1) Place the Outside Roof Cover on the inside Roof Cover.
- (2) Align the holes and use 3 Hooks #R1 to secure Mesh #O to the inside Roof Cover (From Bottom to Top).









Please do not pull plastic bar out when installing it with #P, L1 & L2 on the middle roof tube.











BOTTOM VIEW




1

2





Plastic Bar
on the mesh










Remove the protective film of the panels before installing the roofing panels,




Section View






Attach Part #Z,#Z1,#Z2,#Z3 & #Z4 by lightly tapping with screwdriver.



If you can't install #V, push the Outside Roof Cover up and try to insert them again.



FINISHING END ASSEMBLY:




U1 (x4)


U2 (x4)



U3 (x4)



U4 (x6)




1#
x32












U5 (x2)

SOLIDIFYING BAR ASSEMBLY:






INSIDE VIEW







Attach Part #Z by lightly tapping with screwdriver.




X5




X6




X7




X8




X1




X3




X4




X9



X10




X12



X11

Please install Clips #Z, Z3, Z4 in strict accordance with the instructions.


Install the Middle Panels (#X6, X7 or #W4,W5) first, then the small panels on the edge.




Remove the protective film of the panels before installing the roofing panels,
The Black Rubber #S should be assembled when installing the roof panels; please see the next page.




S x148




5#
x92








7#
x44



6#
x8









10#
x4



S x4


10#
x4






S x44

7#
x44



Solidifying Bar



S x92

5#
x92




4

Beam


5#


5#





MOSQUITO NETTING AND SOLID SIDEWALL ASSEMBLY:







Y1/Y


Ya/Y1a

Ya/Y1a



Y/Y1

Ya/Y1a



Yb

Please close your gazebo curtain when it is incoming over 30 mph wind, and tie with Strap #Yb.



Thanks for your purchase.

At domi outdoor living, we believe in our products.

That's why we provide a 12-month warranty and friendly, easy-to-reach after-sales service. So, if you have any questions about our product or assembly, please feel free to contact us. We are here for you.

Support:  

After-sales contact email:

service@domioutdoorliving.com

Business cooperation contact email:

marketing@domioutdoorliving.com

Please have your order ID available if you reach out for support.

If you have damaged parts or product, please send us photos for an immediate response.