Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Separate, identify and count all parts and hardware. Compare with the parts list to be sure all parts are present.

IMPORTANT: PLEASE READ INSTRUCTION BEFORE STARTING THE ASSEMBLY.

"DO NOT TIGHTEN SCREWS UNTIL COMPLETELY ASSEMBLED"

"DO NOT OVERTIGHT ANY HARDWARE"

WARNING: SMALL PARTS AND HARDWARE NOT FOR CHILDREN UNDER 3 YEARS. ADULT ASSEMBLY REQUIRED.

TABLE OF CONTENTS		
HARDWARES LIST	PAGE 2	
PARTS LIST	PAGE 2 - 3	
PARTS' LOCATION	PAGE 4	
ASSEMBLY STEPS	PAGE 5 - 14	
ASSEMBLY COMPLETED	PAGE 14	

<sup>\*\*</sup>COFFEE TABLE ASSEBLY STEP START FROM STEP 1 TO 8.

# ASSEMBLY TOOLS REQUIRED Skip the power drill this time.


<sup>\*\*</sup>END TABLE ASSEBLY STEP START FROM STEP 9 TO 16.

	ASSEMBLY INSTRUCTION			
	HARDWARES LIST			
ITEM	DESCRIPTION	DRAWING	QTY	
А	MINIFIX CAM LOCK		64 PCS	
В	MINIFIX CAM BOLT		64 PCS	
С	WOOD DOWEL (M8 x 25MM)		12 PCS	
D	PANHEAD SCREW (M4 x 35MM)		16 PCS	
COFFEE TABLE PARTS LIST				
ITEM	DESCRIPTION	DRAWING	QTY	
1	TOP PANEL	· · · · · · · · · · · · · · · · · · ·	1 PC	
2	BOTTOM PANEL		1 PC	
3	LONGER APRON	· • • • • · ·	4 PCS	
4	SHORTER APRON		4 PCS	


	ASSEMBLY INSTRUCTION			
	COFFEE TABLE PARTS LIST			
ITEM	DESCRIPTION	DRAWING	QTY	
5	SUPPORT LEG (i)		2 PCS	
6	SUPPORT LEG (ii)		2 PCS	
	END	TABLE PARTS LIST		
ITEM	DESCRIPTION	DRAWING	QTY	
7	TOP PANEL		2 PCS	
8	BOTTOM PANEL	0 0 0 0	2 PCS	
9	LONGER APRON		4 PCS	
10	SHORTER APRON		4 PCS	
11	SUPPORT LEG (i)		4 PCS	
12	SUPPORT LEG (ii)		4 PCS	

# PARTS ' LOCATION

## COFFEE TABLE x 1 PC




## END TABLE x 2 PCS



## **ASSEMBLY STEPS**


## STEP 1

Insert 6 pieces (B) to (1), 3 pieces (A) to (3). Combine them then tighten the 6 pieces (A) as shown.




#### STEP 2

Insert 4 pieces (A), 6 pieces (B) to (2), 3 pieces (A) to (3). Combine them then tighten the 6 pieces (A) as shown.



STEP 3


Insert 4 pieces (A) to (4) as shown.




#### STEP 4

Insert 5 pieces (B),1 piece (C) to (5) as shown. Insert 5 pieces (B),1 piece (C) to (6) as shown.








#### STEP 5

Combine 2 pieces (4) to (5) then tighten the 4 pieces (A)-(pre insert in step 3) as shown.


Combine 2 pieces (4) to (6) then tighten the 4 pieces (A)-(pre insert in step 3) as shown.

Attention the direction of (4).




## STEP 6

Combine (2) to (5),(6) then tighten the 2 pieces (A)-(pre insert in step 2) as shown.




## STEP 7

Combine the remaining 1 piece (5),(6) to (2),(4) tighten the 10 pieces (A)-(pre insert in step 2 and 3) as shown.




## STEP 8


Align position then put the frame to (1), insert 8 pieces (D) to combine (3),(5),(6) as shown.



#### STEP 9


Insert 4 pieces (B) to (7) as shown.






#### STEP 10


Insert 4 pieces (A) to (8) as shown.






#### STEP 11

Insert 6 pieces (A) to (10) as shown.




#### STEP 12

Insert 3 pieces (B),1 piece (C) to (11) as shown. Insert 3 pieces (B),1 piece (C) to (12) as shown.




#### STEP 13

Combine (10) to (12) then tighten the 2 pieces (A)-(pre insert in step 11) as shown. Combine (10) to (11) then tighten the 2 pieces (A)-(pre insert in step 11) as shown. Attention the direction of (10).




#### STEP 14

Combine (8) to (11),(12) then tighten the 2 pieces (A)-(pre insert in step 10) as shown.



#### STEP 15

Combine the remaining 1 piece (11),(12) to (8),(10) then tighten the 6 pieces (A)-(pre insert in step 10 and 11) as shown.



#### STEP 16

Combine (10) to (1) then tighten the 4 pieces (A)-(pre insert in step 11). Insert 4 pieces (D) to combine (9),(11),(12) as shown.

