# ASSEMBLY INSTRUCTIONS

### Customer Service : cs@nbrehome.com



THIS INSTRUCTIONS CONTAINS IMPORTANT SAFETY INFORMATION. PLEASE READ BEFORE ASSEMBLY AND KEEP FOR FUTURE REFERENCE.

Need Parts or Assistance? Email us : **cs@nbrehome.com** 

# **IMPORTANT NOTICE**

-This product contains small components, please ensure that they are kept away from small children.

-THIS INSTRUCTIONS CONTAINS IMPORTANT SAFETY INFORMATION. PLEASE READ BEFORE ASSEMBLY AND KEEP FOR FUTURE REFERENCE.

-Read each step carefully. It is very important that each step of instruction is performed in the correct order. If these steps are not followed in sequence, assembly difficulties will occur.

-Make sure all parts are included. Most parts are labelled or stampled on the raw edge.

-Work in spacious area, preferably on a carpet, near the place the unit will be used.

-Do not use power tools to assemble your furniture. Power tools may strip or damage the parts.

-Move your new furniture carefully, with two people lift and carry the unit to it's new location.

-Never push, drag or pull your furniture (especially on carpet)



### PLEASE DO NOT RETURN PRODUCT TO US IMMEDIATELY

If a part is missing or damaged, email our customer service. We will gladly ship your replacement parts FREE of charge.

Need Parts or Assistance? Email us : cs@nbrehome.com

For Prompt, reliable service, please have your assemble instruction ready


# WARNING


Children have died from furniture tipover. To reduce the risk of furniture tipover:


- -ALWAYS install Anti-tip device provided.
- -NEVER put a TV on this product.
- NEVER allow children to stand, climb or hang on any drawers, doors, or shelves.
- NEVER open more than one drawer at a time.

- Place heaviest items in the lowest drawers.

*This is a permanent label. Do not remove!* 







()


B x 2

Ø15x10mm

C x 2


Ø6x 30 mm


Insert screws (A) into the part<sup>(1)</sup>,<sup>(1)</sup>,<sup>(4)</sup>. As shown in the figure.



(10)


6-25






Insert the dowel (C) on part<sup>2</sup>,<sup>3</sup>.


Assemble part<sup>(2)</sup>, <sup>(3)</sup> and part<sup>(0)</sup> with screw (D). As shown in the figure.





### Step 12

Insert screws (A) into the part (1), (17, (4). As shown in the figure.











Insert the dowel (C) on part(4),(5). Assemble part(4),(5) and part(11) with screw (D). As shown in the figure.







Use screws (J) to lock the back panel buckle (I) to make the product more stable. As shown in the figure. Install anti-tipping devices (H) as shown. Н H L 20 (19) (18) 11  $\bigcirc$ Ix 12 J x 12 0811 H x 2 15*x 13 x 10 mm* Ø6.5x M3 x 16 mm


### Step 22


Use the screw (D) to assemble the side panels, 2 and the back panel. Insert the bottom panel according to the slot. Install the screw (A) on the drawer panel a shown.






Use the screw (G) to lock the handle (F) on the drawer panel<sup>(2)</sup>. As shown in the figure.







Use the screw (G) to lock the handle (F) on the drawer panel<sup>2</sup>. As shown in the figure.





# Step 28







Use the screw (G) to lock the handle (F) on the drawer panel<sup>(2)</sup>. As shown in the figure.






Use the screw (G) to lock the handle (F) on the drawer panel<sup>2</sup>. As shown in the figure.







Use the screw (G) to lock the handle (F) on the drawer panel<sup>25</sup>. As shown in the figure.



Pass the part<sup>(2)</sup> through the hole and install it into part<sup>(2)</sup>. As shown in the figure.





Install the layer support(K) to part<sup>(2)</sup>(3), as shown. Then place part<sup>(9)</sup> parallel on the left side of the cabinet. As shown in the figure.



### Step 40

**K x 4** Ø5*x 9 x 12 mm* 





# <text>

### Step 42

WARNING: Alway ensure the area to be drilled is free from hidden electrical wires, water and gas pipes.

