

JY9939BS01




As this item contains many parts, please read the installation instruction carefully before installation . Please use tools properly and carefully. If you have any questions about the product and installation, please contact us.

hosoteservice@gmail.com

Our professional after-sales team will serve you online all day.

Before You Start



- ✓ Read through each step carefully and follow the proper order
- ✓ Separate and count all your parts and hardware
- ✓ Give yourself enough room for the assembly process
- ✓ Have the following tools: Flat Head Screwdriver, #2 Phillips Head Screwdriver and Hammer
- ✓ Caution: If using a power drill or power screwdriver for screwing, please be aware of to slow down and stop when screw is tight. Failure to do so may result in stripping the screw. (Assembly speed can be increased by using electric screwdriver)

Helpful Hints


PEOPLE NEEDED FOR ASSEMBLY: 1-2

- Open your item in the area you plan to keep it to avoid excessive heavy lifting.
- Identify, sort and count the parts before attempting assembly.
- Compression dowels are lightly tapped in with a hammer.
- Slides are labeled with an **R** (right) and **L** (left) for proper placement.
- Make sure to always face the point on the top of the Cam Lock towards the outer edge.
- If there is a back panel in the package, please install it to make sure your unit is complete and sturdy.
- Please fix all the screws provided for the back panel which can enhance product stability. If it is difficult to fix it when tightening, it can be fixed with the help of a hammer and then tightened.
- Do NOT use harsh chemicals or abrasive cleaners on this item.
- Never push, pull, or drag your furniture.




Board Identification


Not actual size




(A)
DESK TOP




(B)
LOWER LEFT SIDE PANEL




(C)
LOWER LEFT PARTITION




(D)
LOWER RIGHT PARTITION




(E)
LOWER RIGHT SIDE PANEL




(F)
MIDDLE SHELF
Qty:2



(G)
RAIL
Qty:2




(H)
SHELF
Qty:2




(I)
FRONT SLAT
Qty:2

Board Identification


Not actual size




ⓐ
FRONT SLAT




ⓑ
REAR PANEL




ⓒ
BACK PANEL




ⓓ
BACK PANEL




ⓔ
PANEL




ⓕ
PANEL



ⓖ
UPPER LEFT BACK PANEL




ⓗ
UPPER RIGHT BACK PANEL



ⓘ
DRESSING MIRROR


Board Identification

Not actual size




Ⓡ

UPPER LEFT SIDE PANEL




Ⓢ

UPPER LEFT SIDE PARTITION




Ⓣ

UPPER RIGHT SIDE PARTITION



Ⓤ

UPPER RIGHT SIDE PANEL




Ⓥ

FIXED SHELF
Qty:4




Ⓦ

SMALL SEPTUM
Qty:2




Ⓧ

FRONT SEPTUM



Ⓨ

DRAWER LEFT SIDE PANEL
Qty:3




Ⓩ

DRAWER RIGHT SIDE PANEL
Qty:3


Board Identification

Not actual size




Ⓐ

DRAWER FRONT PANEL
Qty:2




Ⓑ

DRAWER FRONT PANEL




Ⓒ

DRAWER BACK PANEL
Qty:2




Ⓓ

DRAWER BACK PANEL




Ⓔ

DRAWER BOTTOM PANEL
Qty:2




Ⓕ

DRAWER BOTTOM PANEL




Ⓖ

SPONGE CUSHION



Ⓗ

STOOL SIDE PANEL
Qty:2




Ⓙ

STOOL UPPER CROSSBEAM
Qty:2

Board Identification

Not actual size




Ⓝ

















LOWER BEAM OF STOOL

Board Identification


Not actual size



Part List

 Ø15X9mm 1 X46 CAM LOCK spare: 3	 ø6.5X35mm 2 X46 CAM BOLT spare: 3	 ø6X30mm 3 X20 WOOD DOWEL spare: 2	 ø8X30mm 4 X26 WOOD DOWEL spare: 2
 ø4X35mm 5 X42 SCREW spare: 3	 Ø3.5X14mm 6 X70 SCREW spare: 3	 M6X50mm 7 X20 SCREW spare: 2	 M6X20mm 8 X6 SCREW spare: 1
 Ø3.5X12mm 9 X24 SCREW spare: 2	 10 X8 SHEIF SUPPORT	 12" 11CL X3 LEFT CABINET MEMBER	 12" 11CR X3 RIGHT CABINET MEMBER
 12" 11DL X3 LEFT DRAWER RUNNER	 12" 11DR X3 RIGHT DRAWER RUNNER	 Ø35mm 12 X4 HINGE	 13 X4 METAL PLATE


Part List



14

X2


HANDLE



15

X4


HANDLE



16


X1

HEX KEY



17

X1




Ø20mm

18

X26

SCAM LOCK COVER




109*99*38.5mm

19

X1

HAIR DRYER RACK




Ø4X14mm

20

X2


SCREW
spare: 1



21

X1

TIPPING RESTRAINT
HARDWARE KIT




22










X1

Cam Lock Fastening System












Insert the cam bolt into the hole first, then insert the cam lock and lock it.






STEP 1



STEP2











Edge Banding









Proper orientation of CAM LOCK

STEP 3







Proper orientation of CAM LOCK








STEP4











STEP 5










STEP 6



STEP 7











STEP8








Please make sure that the screw is VERTICAL so as not to affect the sliding of the drawer.

STEP9




Please make sure that the screw is VERTICAL so as not to affect the sliding of the drawer.

STEP10












Turn part D over






Please make sure that the screw is VERTICAL so as not to affect the sliding of the drawer.


STEP11








STEP 12



Edge Banding









STEP 13






Proper orientation of CAM LOCK

STEP 14







Proper orientation of CAM LOCK

STEP 15






Before attaching the back panel, be sure that the unit is at 90°
Avant d'attacher le panneau arrière, assurez-vous que l'unité est à 90°
Antes de fijar el panel posterior, asegúrese de que la unidad esté a 90°

STEP 16





STEP 17





To adjust the vertical height.

Loosen the four screws "A" on both hinges. Two of them are usually in slotted holes which allows you to adjust up or down by a few mm. Then tighten back up.



To adjust depth.





Loosen screw "B" and adjust door, if the door can not be adjusted, please loosen screw "C", then try again. Tighten screw "B" and "C".




To adjust side ways.

Turning the screw "C" on BOTH hinges on each door.


STEP 18



STEP 19








STEP 20






Proper orientation of CAM LOCK






STEP 21




STEP22
















STEP23






According to the needs of customers, install part 19 on the B or E board





STEP24








STEP25




STEP26



STEP27

PART LIST	FIGURE	QUANTITY	DESCRIPTION
21.1		1PC	LONG SCREW (Dia.4mmX38mmL)
21.2		1PC	SHORT SCREW (Dia.4mmX19mmL)
21.3		2PC	METAL "L"BRACKET
21.4		1PC	PLASTIC ANCHOR
21.5		1PC	CABLE



Follow the instructions printed on the plastic bag containing the tipping restraint hardware to attach the tip-over restraints to the unit and the wall.

NOTE: The tipping restraint hardware included is for drywall construction. It will be necessary to drill holes for the wall anchors. Depending upon your wall construction, different anchor hardware may be required. Please contact your local hardware store for assistance.

STEP28

Mirror lamp touch display settings

1 turn off the light state, show the blue light state, long press, digital flicker can adjust the time, click to increase the number.

2 Show the blue light status, long press, switch to the minute adjustment, click to increase the number, after the adjustment is not controlled, does not flash on behalf of the time has been adjusted.

3 white state is the state of the light, point switch color temperature, long press adjust the brightness of the light

