

























# Product structure decomposition




# Product structure decomposition




	1 x 2		2 x 2		3 x 4
	4 x 1		5 x 1		6 x 1
	7 x 1		8 x 2		9 x 1
	10 x 1		11 x 1		12 x 1
	13 x 1		14 x 1		15 x 1
	16 x 2		17 x 2		18 x 2
	19 x 3		20 x 3		21 x 1















22x 2



















23x 2




24x 1




# Accessories list

<b>A</b>	 6X28mm	Two In One Screw	81 pcs
<b>B</b>	 10x12mm	Two In One Nut	81 pcs
<b>C</b>		Male and female screws 5x17mm	4 pcs
<b>D</b>	 6x30mm	Wood Chipping	10 pcs
<b>E</b>		Foot rubber pad	4 pcs
<b>F</b>		Screw (6x20mm)	4 pcs
<b>G</b>		Handle & screw(3.5X12mm)	3 pcs /6 pcs
<b>H</b>		Iron sheet	2 pcs
<b>I</b>	 M4X10	Screw & Guide (12 inch)	2 pcs-10 pcs
<b>J</b>	 3.5x16mm	Fixing Clip & Screw	12 pcs
<b>K</b>	 3.5X14 M4X10	Hinge	12-6-24pcs
<b>L</b>		Dowel Pin	2 pcs
<b>M</b>		Shelf Bracket	8 pcs
<b>N</b>	 4x45mm 3.5x10mm	Anti Fall Hardware	2-2-2-2-4pcs
<b>P</b>		parent-child screw M6X10- 10X2 8x22mm	2pcs
<b>S</b>		Iron gasket	1pcs




1 pcs



Double-head screwdriver, use as required




# Use parts ① and ②




Use a screwdriver to lock in the direction of the "+" sign

Disassemble along the direction of "-" sign


## Step 1




Code	Diagram	count
C		1
C		1
H		1




## Step2


Code	Diagram	count
<b>A</b>		<b>3</b>



Repeat this installation three times

## Step3


Code	Diagram	count
<b>B</b>		<b>3</b>




Repeat this installation three times


**02**


# Step4



Code	Diagram	count
A		12


# Step5



Code	Diagram	count
A		12


03

# Step6




Code	Diagram	count
<b>B</b>		<b>6</b>

# Step7




Code	Diagram	count
<b>B</b>		<b>4</b>

# Step8




Code	Diagram	count
C		1
C	 5x17mm	1
C		1




# Step9

Code	Diagram	count
B		2




# Step10




Code	Diagram	count
<b>B</b>		<b>12</b>


# Step11



Code	Diagram	count
<b>A</b>		<b>4</b>


# Step12


Code	Diagram	count
<b>B</b>		<b>4</b>



After installtion of 12 and15,the hole of H, keep the same directiton


# Step13


Code	Diagram	count
<b>A</b>		<b>4</b>




Repeat this installation four times


# Step14

Code	Diagram	count
<b>B</b>		<b>4</b>




# Step15

Code	Diagram	count
<b>B</b>		<b>8</b>




# Step 16

Adjust height by rotation



Code	Diagram	count
<b>A</b>		<b>8</b>
<b>T</b>		<b>1</b>
<b>T</b>		<b>4</b>


# Step 17



Code	Diagram	count
<b>B</b>		<b>8</b>
<b>E</b>		<b>4</b>


# Step18

Repeat this installation twice




Code	Diagram	count
C		1
C		1

# Step19




Code	Diagram	count
F		2

Drawer rail breakdown diagram




① Dismantle the schematic diagram

Step 1 : Pull the rails apart






Step 2 : Press the nylon button and pull out ①.

Drawer rail decomposition completed schematic diagram






# Step20

Code	Diagram	count
I		1
	 M4X10mm	2




# Step21

Code	Diagram	count
P	 6x22mm	1
P		1






Repeat this installation twice




# Step22


Code	Diagram	count
I		1
		3




Repeat this installation twice



frontend



# Step23




frontend




align the screw on the elliptical hole

# Step24





Code	Diagram	count
A		6
S		1


# Step25





Code	Diagram	count
P	 6X10mm	1


# Step26





Code	Diagram	count
<b>C</b>		<b>1</b>

# Step27



Code	Diagram	count
<b>A</b>		<b>4</b>



# Step28



5


Code	Diagram	count
<b>A</b>		<b>4</b>


# Step29





Code	Diagram	count
<b>B</b>		<b>8</b>



# Step30

Code	Diagram	count
F	 M6X20	2




# Step31


Code	Diagram	count
I		1
	 M4X10mm	2




# Step32





# Step33




Code	Diagram	count
A		6


# Step34

Code	Diagram	count
D		6





# Step35

Code	Diagram	count
B		4




# Step36


Code	Diagram	count
<b>B</b>		<b>2</b>






# Step37




# Step38



Code	Diagram	count
D		4

Code	Diagram	count
B		1
P	 M6X10	1


# Step39





Step1



Step2



# Step40

Code	Diagram	count
C		1






# Step41

Code	Diagram	count
J		12
	 3x16mm	12




# Step42

Code	Diagram	count
M		8






22

# Step43







Repeat this installation twice




Code	Diagram	count
K		2
	 3.5X14mm	4


# Step44




Code	Diagram	count
K		2
	 3.5X14mm	4

# Step45

Code	Diagram	count
K	 M4X8mm	16




Adjust screw control the gap between the two doors




Adjust hole control the up and down height of the door

Adjust screw control the gap between the door and the board


# Step46

Code	Diagram	count
K	 M4X8mm	8




24


Turning this screw can effectively adjust the size of the door gap.





Turn this screw to adjust the door panel to be flat with the side panel.


# Step47

Code	Diagram	count
L		2





# Step48

Code	Diagram	count
G		3
	 3.5x12mm	6





# Step49






Code	Diagram	count
N		1
N		1
N		1



# Step50





Mark the angle bracket's center with a marker for drilling

# Step51

Code	Diagram	count
N		1
N		1
N	 3.5x10mm	1





# Step52



Mark the angle bracket's center with a marker for drilling


# Step53



Code	Diagram	count
N		2




First drilling holes in the wall with a hammer drill then Hammer in the expansion tube

# Step54

Code	Diagram	count
N	 4x45mm	1



# Step55

Code	Diagram	count
N	 4x45mm	1

