
ASSEMBLY INSTRUCTIONS END TABLE



PARTS IDENTIFICATION




PARTS IDENTIFICATION

ITEM	DESCRIPTION	QTY
#1	TOP PANEL	01
#2	RIGHT SIDE FRAME	01
#3	LEFT SIDE FRAME	01
#4	BACK PANEL	01
#5	BACK RAIL	01
#6	FRONT RAIL	01
#7	BOTTOM FRAME	01
#8	DRAWER SIDE	02
#9	DRAWER BACK	01
#10	DRAWER BOTTOM PANEL	01
#11	DRAWER FRONT PANEL	01

HARDWARE IDENTIFICATION


Please line up the hardware with the correct full size image to make sure you are installing the hardware correctly.


ITEM	PICTURE		DESCRIPTION	QTY
A		(Ø <mark>1</mark> "x1 ½") Full size	BOLT	04
В		(Ø8x30mm) Full size	WOOD DOWEL	12
С		(Ø ¹ / ₈ "x1") Full size	SCREW	08
D		(Ø6x30mm) Full size	SMALL WOOD DOWEL	02
E		(Ø ³ / ₁₆ "x ³ ") Full size	SMALL BOLT	02
F		Not to Scale	HANDLE	01
G	388	Not to Scale	CAM LOCK	04
Н		Not to Scale	CAM BOLT	04
I		Not to Scale	DRAWER STOP	01
J		(Ø̄8"x2̄") Full size	SMALL SCREW	01
K		Not to Scale	ALLEN WRENCH	01





IMPORTANT:

- 1. DO NOT TIGHTEN BOLTS COMPLETELY UNTIL ALL BOLTS ARE COMPLETELY LINED UP AND INSERTED INTO HOLES / NUTS.
- 2. DO NOT OVER TIGHTEN SCREWS AND BOLTS TO AVOID STRIPPING.









WARRANTY