
尺寸:14*21CM 单黑双面印刷 105g铜版纸

MULTIFUNCTIONAL LED FLOOR LAMP PRODUCT SPECIFICATION



		•		
PART	1)	23	4	567
Llustration			₽	
Description	Head of lamp	Tubes	Triadius	Sticks
QTY	1	2	1	3

PARTS LIST

Please check and make sure you have all the parts ready before beginning assembly.

ASSEMBLY INSTRUCTIONS

♦LED Floor Lamp

- 1. Screw assembly ① clockwise into Tube ② until secure.
- 2. Repeat Step 1 for Tubes ② and ③ .(If you want a shorter lamp, skip this step)Screw Tube ② or ③ clockwise into Base ④ until secure.
- 3. Screw support stick ⑤, ⑥and ⑦ clockwise into Base④ until secure.

♦ Desk Lamp

Screw assembly 1 clockwise into Base 4 without 2 and 3.

DESCRIPTION

◆Weight: 1.2 kg

♦Input current: 1A - 2A


◆Material: Head - Aluminium alloy, Shelf- Iron

◆ Voltage supply: DC5V

◆ Height: 70~183cm

♦ LED number:72PCS





OPREATION INSTRUCTIONS

Turn the lamp on / off

- 1. Press the A switch into position O to turn the light off.
- 2. Position II and position I of A switch, can adjust the color temperature (warmm light and cold light).
- 3.B switch can adjust the brightness.

CAUTION

- 1. Inspect the wire insulation for any cuts, abrasions or exposed copper that mayhave resulted during shipping. If there is a defect in the wire, DO NOT continue theassembly operation.
- 2. This lamp is designed for illumination in dry indoor rooms. It is not suitable for usein damp rooms, e.g. bathrooms.
- 3. Keep children away from packaging -risk of suffocation! Keep children away from the lamp, and do not leave them unsupervised with the lamp.4.Do not touch the lampshade during operation, as it becomes very hot. Do not lookdirectly into the light source! Your eyes could be damaged.

PRODUCT MAINTENANCE

- 1. To clean simply wipe with a soft dry cloth.
- 2. Always avoid the use of harsh chemicals or abrasive cleaners as they may cause damage to the fixtures finish.

ELECTRICITY - RISK OF ELECTRIC SHOCK

- 1. Keep the lamp away from humidity.
- 2. Connect the lamp only to outlets corresponding with the technical data of the lamp.
- 3. Before cleaning or if the lamp is not to be used for a long period, unplug the lamp from the mains power supply.
- 4. During storms unplug the lamp from the mains power supply. When removing the plug from the socket, always pull on the plug and not the cable.
- 5.A damaged cable must only be repaired at your local electrical store.
- 6.Do not use the lamp if it is damaged or if the connecting cable shows any kind of visible damage.

IMPORTANT

The input current(Adapter) CAN NOT be more than 2.0A(DC5V).

When you plug in the DC adapter, pay attention to the risk of short circuiting.

CONSULT A QUALIFIED ELECTRICIAN IF YOU HAVE ANY ELECTRICAL QUESTIONS.