







Assembly Instructions














Buffet




Hardware List

ITEM	DESCRIPTION	PART	QTY	ITEM	DESCRIPTION	PART	QTY
A	Cam Bolt	 6*35mm	10 pcs	I	Hinge	 45mm	4 pcs
B	Camlock	 15*9mm	10 pcs	J	Handle Bolt	 4*16mm	4 pcs
C	Screw	 4*40mm	9 pcs	K	Handle		2 pcs
D	Screw	 3*14mm	2 pcs	L	Supporter		4 pcs
E	Screw	 3*12mm	18 pcs	M	Wooden Dowel	 8*40mm	28 pcs
F	Allen Head Bolt	 6*70mm	8 pcs	N	Magnetic Catch		1 pc
G	Barrel Nut		8 pcs	O	Magnetic Bar	 35*12*1mm	2 pcs
H	Allen Wrench		1 pc				

Part List


ITEM	DESCRIPTION	PART	QTY	ITEM	DESCRIPTION	PART	QTY
1	Connect Rail for Bottom Panel		2 pcs	8	Left Side Panel		1pc
2	Bottom Panel		1 pc	9	Right Side Panel		1pc
3	Connect Rail for Shelf		1 pc	10	Left Door		1 pc
4	Shelf		1 pc	11	Right Door		1pc
5	Connect Rail for Top Panel		2 pcs	12	Down Back Panel		1pc
6	Top Panel		1 pc	13	Up Back Panel		1pc
7	Adjustable Shelf		1 pc				

STEP 1




1. Attach connect rail (1) to bottom panel (2) by using screw (C) and wooden dowel (M).

STEP 2



1. Attach connect rail (3) to shelf panel (4) by using screw (C) and wooden dowel (M).


STEP 3




1. Screw cam bolt (A) to left side panel (8) and attach part from step 1 and step 2 to left side panel (8) by using wooden dowel (M).
2. Insert cam lock (B) to the hole on shelf (4) then rotate clockwise to secure cam bolt in place.
3. Insert barrel nut (G) to the hole on connect rail (1) in right direction, then screw the allen head bolt (F).
4. Tighten the parts by using allen wrench (H).

STEP 4

1. Rotate the part from step 3. Insert down back panel (12) to part from step 3 as shown.
2. Attach connect rail (5) to left side panel (8) by using wooden dowel (M).




STEP 5




1. Screw cam bolt (A) to right side panel (9) and attach right side panel (9) to part from step 4 by using wooden dowel (M).
2. Insert cam lock (B) to the hole on shelf (4) then rotate clockwise to secure cam bolt in place.
3. Insert barrel nut (G) to the hole on connect rail (1) and (5) in right direction, then screw the allen head bolt (F).
4. Tighten the parts by using allen wrench (H).

STEP 6




1. Rotate the part from step 5. Insert up back panel (13) to part from step 5 as shown.
2. Insert barrel nut (G) to the hole on connect rail (5) in right direction, then screw the allen head bolt (F). Tighten the connect rail (5) by using allen wrench (H).

STEP 7




1. Screw cam bolt (A) to top panel (6) and attach top panel (6) to part from step 6 by using wooden dowel (M).
2. Insert cam lock (B) to the hole on connect rail (5) and side panel (8 & 9) then rotate clockwise to secure cam bolt in place.
3. Attach magnetic catch (N) to bottom panel (2) by using screw (D).

STEP 8



1. Assemble handle (K) to door by using handle bolt (J).
2. Assemble magnetic bar (O) to door by using screw (E).
3. Assemble hinge (I) to left door (10) and right door (11) to by using screw (E).

STEP 9



1. Attach left door (10) and right door (11) to part from step 8 by using screw (E).
2. Insert support (L) to side panel (8 & 9).
3. Insert adjustable shelf (7) as shown.