


















ASSEMBLY INSTRUCTIONS












TV Stand



Hardware List:

ITEM	DESCRIPTION	PART	QTY
A	Camlock bolt		12
B	Camlock		12
C	Wooden dowel	 F6*30mm	14
D	Magnet		2
E	Long wood screw	 F3*15mm	4
F	Bolt		8
G	Handle		4
H	Machine screw	 F5/32*1/2"	8
I	Phillips head screw	 F3*12mm	22
J	Shelf support		16
K	Door pin		8
L	Safety wall strap		1
M	Plastic anchor		1
N	Mounting screw	 F4*38mm	1
O	Washer		1
P	Allen Wrench		1

Parts List:

ITEM	DESCRIPTION	PART	QTY
1	Top		1
2	Base		1
3	Left panel		1
4	Right panel		1
5	Middle panel		1
6	back panel		1
7	Adjustable shelf		4
8	Left door		2
9	Right door		2
10	Feet		4
11	Center foot		1

ADDITIONAL TOOLS (Not Provided)

Note: It is not recommended to use power tools during assembly.




Phillips Head Screwdriver

Note: Wood dowels are intended for alignment. Additional clearance between wood dowel and pre-drilled hole is intentional for ease of assembly.

- * Required screwdriver & mallet, not included.
- * Before discarding packing materials, please check to make sure that all parts and hardware is present.
- * Two people needed for assembly.
- * Please follow the instructions closely; do not over tighten screws or bolts unless instructed.
- * After a few days from initial assembly, the product may have acclimated to the new environment. Please retighten the hardware.

Guideline For Assembling of Cam Lock(A & B)







Screw camlock bolt (A) to wood part.

Do not assemble camlock (B) unless instructed.


To assemble camlock (B), ensure long side of the + is facing the bolt (A) before inserting into hole.



Step 1. Attach feet (part #10) and center foot (part #11) to base (part #2) using wooden dowels (part C), bolts (part F) and allen wrench (part P).




- C  8 PCS
- F  4 PCS
- P  1 PC




Step 2. Attach magnets (part D) to top panel (part #1) using long wood screws (part E) and phillips head screwdriver.




- D  2 PCS
- E  4 PCS




Step 3. Attach side panels (part #3 & #4) and middle panel (part #5) to base (part #2) using camlock bolts (part A), camlock (part #B), wooden dowels (part C) and phillips head screwdriver.




- | | | |
|---|---|-------|
| A |  | 6 PCS |
| B |  | 6 PCS |
| C |  | 3 PCS |

Step 4. Attach top panels (part #1) to side panels (part #3 & #4) and middle panel (part #5) using camlock bolts (part A), camlock (part #B), wooden dowels (part C) and phillips head screwdriver.




- A:  6PCS
- B:  6PCS
- C:  3PCS




Step 5. Attach back panel (part #6) to assembled units (part #1, #2, #3 & #4) using safety wall strap (part L), phillips head screw (part I) and phillips head screwdriver.




- I  22 PCS
- L  1 PC

Step 6. Attach door pins (part K) to doors (parts #8 & #9). Attach handle (part G) to doors (parts #8 & #9) using machine screws (part H) and phillips head screwdriver.



- G  4 PCS
- H  8 PCS
- K  4 PCS


Step 7. Place shelf supports (part J) into desired position and slide adjustable shelves (part #8) into place.



J  16 PCS

Step 8. Attach doors (parts #8 & #9) by placing bottom pin hinge (pre-installed in door) in the pre-drilled hole of base (part #2), then depress the top spring-loaded pin hinge so it can be placed in the pre-drilled hole of top panel (part #1).

Note: Be sure top and bottom pin hinges are fully extended to secure doors in place.




Step 9. SAFETY WALL STRAP INSTALLATION.

Note: It is highly recommended to install this safety strap kit to prevent tipping, damage and/or injury.

1. Drill a hole where you want to secure the unit. The drilled hole will be at the same height as the hole in top panel (part #1) where safety wall strap (part L) is attached. Tap wall anchor (part M) into the hole.

2. Insert long screw (N) through washer (part O) and safety wall strap (part L) into wall anchor (part M) using phillips head screwdriver.

Note: This item is not intended for clothing storage use.



M		1 PC
N		1 PC
O		1 PC