


8x6 - Octagonal




1.a Lay the floor down in the desired position.

1.b Check that the floor is level using a spirit level before proceeding.

1.c Each floor joist should be as near as possible supported along its full length to prevent the floor from dipping in the middle.

1.d Ensure 65mm nails are driven through the side and gable panel base rails, through the floor boards in a position where they will finally penetrate the floor joist.



Important:

- The floor panel must be laid on a firm level base.
- The underside of this floor must be treated with a quality wood preservative.
- Before starting assembly you may have to remove transport blocks (marked X) from the bottom of some panels.


65mm Nails

1. Base

3. Roof

3.a Place the fibre glass roof down in to position on top of the walls.

3.b On the 6x6 model, screw one 80mm coachbolt through the centre top part of each panel.




65mm Coachbolt



2. Gables & Sides

4. Acorns 4.a Fit the roof finishing pieces by screwing upwards through the roof using the 80mm screws.



80mm Screws


5. Windows

5.a Glaze the windows by securing the glass/perspex with the panel pins supplied.

Panel Pins

Important:
All windows must be sealed inside and out with silicone putty or any other water-tight solution (not supplied).

Please do not confuse your corner strips as window beading. We do not provide window beading as standard with our buildings.



6. Corner Strips

6.a Secure the corner strips at each corner of the shed with the 38mm nails provided.



38mm Nails



Important:
Please do not confuse these corner strips as window beading. We do not provide window beading as standard with our buildings.

Also please be aware that these corner strips may need cutting to size.

Treat your building annually: Although it may come with a factory basecoat you should treat your new garden building inside and out shortly after installation with a good quality water resistant treatment. This process should then be repeated annually with care taken to brush the treatment into all wooden components involved within the construction of the building, inside and out.


Ensure nothing is in contact with your building: Any overhanging tree or hedge growth poses a threat to your garden building and should be cut back at regular intervals. If a tree branch makes contact with your building it may pierce the roofing felt and encourage water ingress. You should also take care not to allow plants to grow too close to the walls of your building to prevent leaks.

Check and replace any damaged felt: If you do find any damage sustained to your roofing felt over time it is essential that you act upon this without delay. Should you discover a rip or tear in the felt it is recommended that this area be stripped from the roof and a new covering of high grade, heavy duty, mineral felt (which can be purchased online and/or at most retail DIY stores) be fitted immediately.

You should also ensure that your new building is covered on your household insurance policy, as we cannot be held responsible for damage caused by storms or vandalism.

For more help and advice on installing and maintaining your garden building please visit our comprehensive help centre at: www.tigerheds.com/helpcentre.asp

6x6 Octagonal



These instructions use the 6x6 Octagonal as a model, but you will be able to use them to construct the 6x6 model. The 6x6 has a different shape to the 8x6, but the method of installation is the same.

Check List - 6x6

- x1 Floor
- x1 Door Panel
- x4 Window Panels
- x3 Blank Panels
- x1 Fibre Glass Roof
- Glass / Perspex
- x2 Acorns (Roof Decoration)
- x8 Corner Strips
- Fixing Pack (Found in Polytube)

Check List - 8x6

- x1 Floor
- x1 Door Panel
- x2 Window Panels
- x5 Blank Panels
- x1 Fibre Glass Roof
- Glass / Perspex
- x2 Acorns (Roof Decoration)
- x8 Corner Strips
- Fixing Pack (Found in Polytube)