


**IMPORTANT**  
**RETAIN FOR FUTURE REFERENCE**  
**READ CAREFULLY**

# **INSTRUCTION MANUAL**




**Note:**










1. Do not use electric screwdriver.
2. Two people are required to assemble this item. Assemble the item on a flat, solid and even surface.
3. Make sure that all the necessary parts are in the carton before starting the assembly.
4. Please secure all parts and bolts loosely, only when the frame is complete should you fully tighten the screws.
5. If any instability occurs, loosen the screws, re-align the components as necessary and re-tighten the screws evenly.
6. This item is not a climbing frame or toy.
7. Danger of suffocation. Keep out of reach of children.

## Warranty!











The product is guaranteed to be free from defects in workmanship and parts for a period of 12 months from the date of purchase. Defects that occur within this warranty period, under normal use and care, will be repaired, replaced or refunded at our discretion.



## Hardware List

1 M6 x 80mm BOLT  2PCS	2 M6 x 60mm BOLT  4PCS	3 M6 x 50mm BOLT  2PCS	4 M6 x 30mm BOLT  1PC	5 M6 x 40mm Screw  8PCS
6 M6 WASHER  8PCS	7 M6 NUT  8PCS	8 NO.10 SPANNER  1PC	9 ALLEN KEY  1PC	


## Parts List

A  1PC	B  1PC	C  1PC	D  1PC	E  1PC
F  1PC	G  1PC	H  1PC	I  2PCS	J  1PC


Note: The quantities above are for one single chair.

# Assembly


Step 1: Secure part H(front cross-piece) to B(right leg)&C(left leg) using Hardware5 (M6×40mm Screw).




Step 2: Attach part A(seat panel) to the finished part in step 1, using Hardware2 (M6×60mm Bolt), Hardware6 (Washer) and Hardware7 (M6 Nut).




Step 3: Secure part J(cup holder) to D(right armrest) using Hardware4 (M6×30mm Bolt).



Step 4: Secure part D(right armrest) to the right leg, and attach part E(left armrest) to the left leg, using Hardware2 (M6×60mm Bolt), Hardware6 (Washer) and Hardware7 (M6 Nut).



Step 5: Attach part F (back panel) to the armrests using Hardware1 (M6×80mm Bolt), Hardware6 (Washer) and Hardware7 (M6 Nut).



Step 6: Connect part G (back cross-piece) to the seat panel using Hardware5 (M6×40mm Screw). Secure the upper hole of part I to the back panel using Hardware5 (M6×40mm Screw). Secure the lower hole of part I to the seat panel using Hardware3 (M6×50mm Bolt), Hardware6 (Washer) and Hardware7 (M6 Nut). Repeat the part I assembly on the other side. Assembly is complete.

