



## Pivot Installation Guide

### What You Received:

- Worksurfaces
- 60" Outside Legs
- Power/Data Trough
- Acrylic Screens (optional)
- Screen Clamps (optional)
- Hat Channels
- Power (optional)
- Wood Screws

### Tools You'll Need:


- Drill with Phillips head bit
- Allen wrench set
- Tape measure




## Pivot Installation Guide

NOTE: 2-pack will be assembled upside down


1. Lay your worksurfaces out and place 60" leg on one end. The outside corners of the surface should be flush with the outside corner of the leg.



2. Mark center point of worksurface for trough placement later (step 8).




3. Attach hat channels 1/3rd of the way from the front of the worksurface.




## Pivot Installation Guide

4. Attach 60" leg to the other end of the worksurfaces. The outside corners of the surface should be flush with the outside corner of the leg.




5. Flip 2 pack right side up, and position according to floor plan.






7. Attach screen clamps to the trough. Discard small pin that comes with clamp. Make sure they are secured tightly and parallel to the edge of the trough.



## Pivot Installation Guide


8. Center troughs on surfaces from underneath (marked center on step 2) and attach with wood screws.





## Pivot Installation Guide

10. Remove face plates from screen clamps. Place acrylic screen notches on the clamps and secure face plates. Be sure to not over tighten screws.



11. Attach clamp on accessories (Monitor Arms/Power)

