














ASSEMBLY INSTRUCTION

- Please follow the instructions to assemble the items correctly.
- Please ensure the safety of the glass when assembling.
- Do not make the screws too loose or too tight.
- As shown in the figure, Insert the screw into the hole.
The arrow in the picture, Then rotate 90° or 180° clockwise.
- The accessory bag contains some small accessories, which should be kept away from children.
- The remaining parts are spare parts.
- Warm reminder white backboard please install the white side inward
- The operating instruction of RGB light is included in the package , please read it carefully when assembling







A1  72pcs	B1  72pcs	C  3.5*14 28pcs	C8  3.5*12 50pcs	C9  4*30 12pcs	F  6pcs	K  12pcs
X  2pcs	Y  16pcs	Z3  6*30 4pcs	AE1  6pcs			



Hardware installation demonstration


- Please make sure "A" hardware tightened and can't be pulled out





Hardware installation demonstration


- When inserting cam ensure arrowhead on cam points toward to the hole on the panel edge





Hardware installation demonstration

- Before installing the drawer rail, you need to separate the K1 and K2 first.




Warm Reminder: Press it and split




Hardware installation demonstration





The first screw hole should corresponded with the board location hole





The first screw hole should corresponded with the board location hole




STEP 1






STEP 2







STEP 3





	A1*4
	C8*12
	K1*6

STEP 4





	A1*4
	C8*12
	K1*6

STEP 5






B1*4

STEP 6




B1*2



STEP 7



STEP 8






STEP 9




 B1*8

STEP 10




 B1*8


STEP 11






STEP 12




STEP 13





STEP 14






STEP 15






STEP 16




	B1*24
	C*12
	F*6

STEP 17





STEP 18



Note: When assembling the inner slide rail, it is necessary to place the inner slide rail on the steel ball component first, and push the inner rail parallel to the outer rail together. Direct violence will lead to the falling off or deformation of the rail steel ball.





STEP 19





Use tools to install if necessary


	C*16
	Y*16

STEP 20



	C8*2
	X*2

STEP 21



STEP 22

