

10046 ASSEMBLY INSTRUCTION

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Separate, identify and count all parts and hardware. Compare with the parts list to be sure all parts are present.

IMPORTANT : PLEASE READ INSTRUCTION BEFORE STARTING THE ASSEMBLY.

"DO NOT TIGHTEN SCREWS UNTIL COMPLETELY ASSEMBLED"

"DO NOT OVERTIGHT ANY HARDWARE"

WARNING : SMALL PARTS AND HARDWARE NOT FOR CHILDREN UNDER 3 YEARS. ADULT ASSEMBLY REQUIRED.

TABLE OF CONTENTS

HARDWARES LIST

PAGE 2-3

PARTS LIST

PAGE 4

PARTS' LOCATION

PAGE 5

ASSEMBLY STORAGE CABINET BENCH


PAGE 6 - 12

COMPLETED ASSEMBLY


PAGE 13

ASSEMBLY TOOLS REQUIRED


1. Screwdriver (not provide)



2. Hammer (not provide)












Skip the power trip this time.





10046 ASSEMBLY INSTRUCTION

HARDWARES LIST

| ITEM | DESCRIPTION | DRAWING | QTY |
|------|---------------------------|--------------------------------------------------------------------------------------|--------|
| A | MINIFIX CAM LOCK |  | 20 PCS |
| B | MINIFIX CAM BOLT |  | 20 PCS |
| C | WOOD DOWEL (M8 x 25MM) |  | 4 PCS |
| D | SOFT CLOSE - HINGES |  | 3 PCS |
| E | CSK SCREW (4 x 16MM) |  | 28 PCS |
| F | FLAT WASHER (M6 x 19MM) |  | 4 PCS |
| G | SPRING WASHER (M6 x 13MM) |  | 4 PCS |
| H | JCBC SCREW (M6 x 55MM) |  | 4 PCS |
| I | M4 ALLEN KEY (65MM) |  | 1 PC |









10046 ASSEMBLY INSTRUCTION

HARDWARES LIST

| ITEM | DESCRIPTION | DRAWING | QTY |
|------|-------------------|------------------------------------------------------------------------------------|------|
| J | HINGES STAY LEFT |  | 1 PC |
| K | HINGES STAY RIGHT |  | 1 PC |

10046 ASSEMBLY INSTRUCTION


PARTS LIST

| ITEM | DESCRIPTION | DRAWING | QTY |
|------|----------------|---------------------------------------------------------------------------------------|-------|
| 1 | TOP DOOR PANEL |  | 1 PC |
| 2 | LEFT PANEL |  | 1 PC |
| 3 | RIGHT PANEL |  | 1 PC |
| 4 | CENTER PANEL |  | 1 PC |
| 5 | FRONT PANEL |  | 1 PC |
| 6 | BACK PANEL |  | 1 PC |
| 7 | BOTTOM PANEL |  | 1 PC |
| 22 | LEG |  | 4 PCS |

10046 ASSEMBLY INSTRUCTION

PARTS ' LOCATION


STORAGE CABINET BENCH x 1 PC





10046 ASSEMBLY INSTRUCTION

ASSEMBLY STEPS

STEP 1




STEP 2





10046 ASSEMBLY INSTRUCTION

STEP 3






STEP 4




10046 ASSEMBLY INSTRUCTION


STEP 5

| | |
|-------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|
|  |  |
| A x 4 | B x 6 |



STEP 6


| |
|---------------------------------------------------------------------------------------|
|  |
| B x 8 |



10046 ASSEMBLY INSTRUCTION


STEP 7

Combine (2),(3) &(4) into (6),then tighten 6pcs (A) as shown.



STEP 8


Combine (5) into (2),(3) & (4), then tighten 6pcs (A) as shown.



10046 ASSEMBLY INSTRUCTION




STEP 9

Combine (7) into (6) & (5), then tighten 8pcs (A) as shown.



STEP 10




Insert 4pcs(C) into (7) as shown. Then secure 4pcs (22) into(7) using 4pcs (F),(G) & (H) as shown.




10046 ASSEMBLY INSTRUCTION


STEP 11

Secure (J) & (K) to the (2) & (3) using 6pcs (E) as shown .


| | | |
|-------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|
|  |  |  |
| J x 1 | K x 1 | E x 6 |



STEP 11.1





STEP 11.2



STEP 12

Insert 3pcs (D) into the top panel and secure them using 6ps (E).



| | |
|---------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------|
|  |  |
| E x 6 | D x 3 |




10046 ASSEMBLY INSTRUCTION

STEP 13


Secure the (D) to the frame using 12pcs (E). Then screw on the hinges are used to adjust the position of the top panel.



STEP 13.1




STEP 13.2




Remark: The screws on the hinges are used to adjust the position of the top panel.

STEP 14


Align the hinges (J) & (K) with the pre-drilled holes on the top panel (1) then secure them using 4pcs screws (E) as shown



STEP 14.1




STEP 14.2



10046 ASSEMBLY INSTRUCTION

STEP 15



ASSEMBLY COMPLETED