








# Baby Balance Bike




  
Suitable for Children aged  
10-36 months

## Package List:



Insert the Handlebar into the Main Body, ensuring the correct orientation.



Attach the Fixed Cover to the Handlebar, ensuring the notched side of the cover is facing downwards (as shown in the diagram).

Next, insert the assembled handlebar and frame into the Front Wheel.



Connect the Rear Wheel to the assembled unit, ensuring the direction of the buckles is correct.

Finally, install the Seat to complete the assembly.

## Precautions:

1. Must carefully read the instruction manual and follow the steps for assembly.
2. Please keep the instruction manual properly for future reference.

## WARNING

1. Assembly must be done by an adult.
2. Since this product does not use any screws for fixation, ensure each buckle is oriented correctly and securely fastened. Before use, confirm that every part is securely and tightly connected. Loose parts can be dangerous and easily break.
3. Children must only use the bike under adult supervision.
4. The baby balance bike is suitable for children aged 10 months and older. We recommend that children wear protective gear, such as shoes and helmets.
5. Only one child is allowed to use this bike at a time.
6. Do not ride the balance bike near stairs, steps, heaters, or similar hazards.
7. This product is designed to help children learn balance and is recommended for indoor use. It should not be used as a means of transportation or in traffic.
8. Clean the bike with a moist cloth only. Do not use harsh chemicals or solvents.