






INSTALLATION & ASSEMBLY




EN_IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY.




EN_QUICKFIT: Tighten quickfit until shoulder is flush with panel. Do not overtighten or undertighten.













EN_CAM LOCK: When fitting cam lock, ensure starting position is correct before you insert connecting quickfit.














EN_Quickfit head should be in the centre of the cam lock when the two panels are joined.
Cam lock should be inserted before quickfit.




EN_Turn cam lock clockwise to tighten.

NO.	PARTS	QTY	SPARE
①		x1	
②		x1	
③		x1	
④		x1	
⑤		x4	
⑥		x1	
⑦		x2	
⑧		x1	
⑨		x2	
⑩		x3	


NO.		QTY	SPARE
⑪		x3	
⑫		x9	
⑬		x9	
⑭		x9	
⑮		x9	
⑯		x9	
⑰		x3	
	 Hardware Kit		























x3







x3




x3

 A x62 Ø6x35mm +3(spare)	 B x62 Ø15x10mm +3(spare)	 C x56 Ø6x30mm +4(spare)	 D x59 Ø4x35mm +4(spare)	 E x108 Ø3.5x12mm +10(spare)	 F x4
 G x4	 H-1	 H-2	 I-1	 I-2	 J-1
			 J-2	 K-1	 K-2
 L x10	 CL x9 L350mm	 CR x9 L350mm	 DL x9 L350mm	 DR x9 L350mm	

 A x45	 B x45	 C x36	 D x45
---------------------------------------------------------------------------------------------------	---------------------------------------------------------------------------------------------------	---------------------------------------------------------------------------------------------------	---------------------------------------------------------------------------------------------------

01






x9

02

E x54

DL x9

DR x9



x9


03

H x18



H-1

H-2











x9


E x54

CL x9

CR x9





x2



Second hole



A x6

L x4





D x8

L x4



C x4


D x4






The holes for the #7 plates are located below

B x6

C x6







C x10




11




A x11




12





G x4




J x14





J-1





J-2







The drawer is different,
please install it strictly
according to the number
shown.




First fix the anti-rewind screw in the reserved hole of the product.




then, use a ruler to measure the approximate height of the product on the wall, and then mark it with a pen.



Then use a tape drill to make holes in the wall that are suitable for the product screws.



Then, put the expansion bolt into the hole



Finally, pass the matching screws through the "anti-rewind" and tighten them to fix them on the wall.

