



© 5x2 Log store



Let's get started...



Important information...

Safety	02
Base and positioning	03
Warranty	03
Before you start	04
Care maintenance & Recycling	05



In more detail...

Hardware chart	06
Parts List	07
Detailed Technical Drawings	08
Assembly instructions	10-15

EN	For a copy of the instructions or a copy in another language please send an email or write to the address below.
F	Pour obtenir un exemplaire des instructions ou une copie dans une autre langue s'il vous plaît envoyez un e-mail ou écrivez à l'adresse ci-dessous.
PL	Na kopii instrukcji lub kopii w innym języku prosimy o wysłanie maila lub pisać na adres podany poniżej.
RUS	Для получения копии инструкции или копия на другом языке, пожалуйста, отправьте по электронной почте или написать по указанному ниже адресу.
TR	Başka bir dilde talimatları veya bir kopyasını bir kopyası için bir e-posta gönderebilir veya aşağıdaki adrese yazınız.

These instructions are for your safety. Please read through them thoroughly before use .
PLEASE KEEP THIS LEAFLET FOR FUTURE REFERENCE

Check that you have noted all the following instructions



- We advise the use of non slip protective gloves throughout the assembly process.
- We advise the use of steel capped protective footwear throughout the assembly process
- We advise that you use a helper to hold the glass in position whilst you nail the beading in place
- We advise the use of protective headwear and safety goggles throughout the assembly process
- Where a ladder is in use another person must hold the ladder.
- Do not attempt to work in windy conditions
- We advise the use of a scaffold tower when fitting the roof, for felting or if you cannot reach from the ground.
- Do not allow children near the tools and work area
- Follow any safety precautions quoted by the manufacturer for any equipment you use
- Check all parts before assembly
- Only use child and animal safe wood preservative
- Do not use creosote
- Allow the wood preservative to fully dry before use
- Regularly check the building for wear and tear

Important!



EVERY PRECAUTION IS TAKEN TO ENSURE THAT YOUR BUILDING HAS NO ELEMENT INCORRECTLY PLACED OR POSSIBLY HAZARDOUS, HOWEVER PRIOR TO USE PLEASE CHECK ALL SURFACES FOR THE FOLLOWING:

- (1) RAISED GRAIN, SPLINTERS: Sand down timber to smooth finish
- (2) NAIL/SCREW/PIN HEADS PROUD: Tap home to be flush with surface of timber
- (3) DAMAGED SCREW HEADS RESULTING IN SHARP SPLINTERS OF METAL: Replace
- (4) SHARP ENDS OF NAILS/ SCREWS/ PINS PROTRUDING THROUGH THE PANEL: Remove and reposition.
- (5) ENSURE ALL PARTS ARE SECURED AGAINST REASONABLE FORCE: Remove and refit
- (6) ENSURE THERE ARE NO LOOSE PARTS: Remove and refit/discard



IMPORTANT ! For your safety please read carefully the safety warnings

Preparation of base...

We recommend that the base onto which your building will stand should be at least 75mm larger in each direction than the total floor size of the building.

Actual floor area of the building: 1506mm x 569mm

Total height clearance: 1391mm

Roof size 1508mm wide x 627mm long

The chosen position in your garden for your building should be excavated to a depth of 75mm to allow a base of sand, on to which paving slabs can be evenly laid.

You may also use an adjustable timber base or a concrete base. Whatever base you decide upon IT MUST BE LEVEL AND FIRM.

Warranty...

10 Year anti rot warranty subject to the following -


- The building must be raised so it is not in contact with any water retaining base surface (for example grass).
- This can be achieved using a timber, concrete or slab base
- When using a concrete or slab base use damp proofing strips under the bearers
- The building must have been completely treated and sealed immediately prior to or after assembly
- The building must have been re-treated and re-sealed annually
- If your building has been pressure treated or has any pressure treated parts additional treatment need not be applied (except for aesthetic purposes)
- Wood is a natural product and therefore the following are excluded from the warranty
 - Colour changes
 - Warping
 - Splitting

The following are also excluded


- Damage resulting from poor assembly
- Poor treatment application
- Poor care and maintenance
- Changes to the design
- Misuse
- General wear and tear

Things to check before you start















- ✓ Ensure your base is ready– See page 3
- ✓ Check all parts as listed in the parts lists
- ✓ Read the instructions fully before starting work
- ✓ Follow all the health and safety guidelines



When you see the drill icon
Only ever drill through the first piece of framework which will be a pilot hole for the screw to attach the second piece of framework
The required drill bit size is shown with the icon.



You will need

 <ul style="list-style-type: none"> • Hammer 	 <ul style="list-style-type: none"> • Gloves
 <ul style="list-style-type: none"> • Spirit level 	 <ul style="list-style-type: none"> • Saw
 <ul style="list-style-type: none"> • Ladder 	 <ul style="list-style-type: none"> • Pencil
 <ul style="list-style-type: none"> • 1mm,3mm 5mm & 8mm drill bit 	 <ul style="list-style-type: none"> • Goggles
 <ul style="list-style-type: none"> • Drill 	 <ul style="list-style-type: none"> • A helper for some tasks
 <ul style="list-style-type: none"> • Tape measure & Ruler 	 <ul style="list-style-type: none"> • Screwdriver
 <ul style="list-style-type: none"> • Sand paper 	 <ul style="list-style-type: none"> • Safety knife

The 5 golden rules of care

- (1) Ensure your base is level and firm
- (2) Ensure the building is not sitting directly on the ground using damp proof membrane or the optional timber base.
- (3) Ensure every piece of timber and surface, especially that is hidden upon assembly is treated with a top quality wood preservative at least twice (see note on pressure treated buildings in warranty section). Turn the panels upside down whilst painting so the treatment runs into the seams.
- (4) Garden buildings are not waterproof, therefore we recommend you seal between all the panels with a silicone based sealant .
- (5) Regularly check your roofing felt for weather damage and leaks

The 7 golden rules of maintenance

- (1) Re apply the timber treatment annually. (see note on pressure treated buildings in warranty section)
- (2) Visually check for weather damage
- (3) Check and replace if necessary any Silicone sealant if used on your building.
- (4) Check the roofing material for wear
- (5) The doors and windows may require periodical adjustment
- (6) Ensure your building is well ventilated especially during hot weather
- (7) During extremely hot periods humidify your building to prevent the timber from drying out .

Recycling and disposal



packaging

1. Pallet and timber widely recycled
2. Cardboard widely recycled
3. Plastic strapping subject to local regulations
4. Plastic sheeting subject to local regulations



Building

1. Timber widely recycled
2. Metal fixings widely recycled
3. Glass widely recycled
4. Roofing felt not currently recycled


Nail bag contents

Description
(part No) qty



Stacked parts list

Hardware Chart Scale 1:1


60mm Posi-drive screw
(A0035) x25




80mm Posi-drive screw
(A0036) x04




Floor
(A0112) x01




Plain Panel
(A0113) x02




Side Panel LH
(A0114-LH) x01




Side Panel RH
(A0114-RH) x01



Roof Panel
(A0115) x01



Detailed Technical drawing




In more detail.....

In more detail.....


Assembly

GB-IE The floor panel **A0112** fits **inside the walls A0113 & A0114**.
 The **A0113** back panels . **FIT INSIDE THE A0114 SIDE PANELS**



01



Floor Panel (A0112) x01



Plain Panel (A0113) x02





GB-IE Position the floor panel **A0112** upside down and push the 2 "**A0113**" panels up to it .
 Mark the centre line of the floor bearers onto the bottom framework of the "**A0113**" panels.
 Drill 4x 5mm for fixing later with 80mm screws.


Turn the floor over from long edge to long edge.

GB-IE The panel "A0114-LH" for the side goes against the side and flush with the front corner of the floor .
 The side panels are longer and protrude past the back corner of the floor.,.
 The back panels "**A0113**" fit behind the floor panel between the sides.
 Ensure you have them the same way that you drilled the bottom in step 1.


02






Floor Panel (A0112) x01



side Panel LH (A0114-LH) x01





Plain Panel (A0113) x01




GB-IE Drill 5 places and fix with 60mm screws NOTE drill the two side panels through the framework between the upright pieces
Also fix the A0113 panel to the floor joists (step1) with 2 x 80mm screws.

GB-IE Drill 6 holes as in the back panel and fix it to the other back panel with 3 x 60mm screws
Fix the panel to the floor through the 2 holes drilled in step 1 with 2 x x60mm screws.

03




Floor Panel (A0112) x01




side Panel LH (A0114-LH) x01





Plain Panel (A0113) x01




60mm Screw




80mmScrew (A0036) x02




04





Plain Panel (A0113) x01



60mm Screw (A0035)x03




80mmScrew (A0036) x02




GB-IE Align the end panel "A0114-RH" flush with the front corner of the floor and level with the framework of the back panel.
Fix the side to the back panel using the holes from step 4 drill 2 holes through the framework between the uprights and attach with 60mm screws


05



side Panel RH
(A0114-RH) x01




60mm Screws
(A0035)x05




GB-IE Place the roof panel in position so its side framework sits inside and flush with the side panels. The framework at the back of the roof panel sits on top of the back panels and the cladding is flush at the back.



06



Roof panel
(A0115)x01



60mm Screws
(A0035)x12



GB-IE Drill through the roof panel framework and screw to the top of each side panel
Drill 3 holes through each back panel and screw to the roof framework so they are just nipped together.