


Sideboard



Please make sure to read the instruction manual carefully before installing the product.

Do Not Return This Product!

Contact our customer service team
for help first.

WARNING

- Unit can tip over causing severe injury or death.
- Anchor unit to stud in wall (if instructed to)
- Do Not allow children to climb on unit.
- put heavy items on lower shelves or drawers.

PEOPLE NEEDED
FOR ASSEMBLY : 2

CONTACT US!

Do NOT return this product!

Contact our friendly customer service team first for help.



- Open your item in the area you plan to keep it to avoid excessive heavy lifting.
- Identify, sort and count the parts before attempting assembly.
- Back panel must be used to make sure your unit is sturdy.
- Do NOT use harsh chemicals or abrasive cleaners on this item.
- Never push,pull,or drag your furniture.

















BEFORE YOU START

- ✓ Read through each step carefully and follow the proper order
- ✓ Separate and count all your parts and hardware
- ✓ Give yourself enough room for the assembly process
- ✓ Have the following tools:Flat Head Screwdriver,#2 Phillips Head Screwdriver and Hammer
- ✓ Caution: IF using a power drill or power screwdriver for screwing,please be aware to slow down and stop when screw is tight.Failure to do so may result in stripping the screw.


















BOARD IDENTIFICATION




BOARD IDENTIFICATION

<div>1</div>  <div>1PC</div>	<div>2</div>  <div>1PC</div>	<div>3</div>  <div>1PC</div>	<div>4</div>  <div>1PC</div>
<div>5</div>  <div>1PC</div>	<div>6</div>  <div>2PC</div>	<div>7</div>  <div>2PC</div>	<div>8</div>  <div>2PC</div>
<div>9</div>  <div>2PC</div>	<div>10</div>  <div>2PC</div>	<div>11</div>  <div>4PC</div>	<div>12</div>  <div>4PC</div>
<div>13</div>  <div>1PC</div>	<div>14</div>  <div>2PC</div>		

THE HARDWARE

A x30  Cam Bolt Ø6x35mm	B x30  Cam Lock Ø15x12mm	C x12  Wood Dowel Ø6x30mm	D x16  wedge	E x16  Screw Ø3x14mm
F x14  Screw Ø5x40mm	G x48  Screw Ø4x14mm	H x8  shelf Support	K x4  Hinge	J x4  Handle
R x2  Wall Anchor	L x4  Hinge	M x8  safety	N x8  Bolt Ø4x25mm	O x8  Pads
P x14  Cover	Q x2  safety bracket kit			

IMPORTANT :




Phillips Screwdriver Power Tool NOT Recommended

1. Do not tighten bolts / screws completely until all bolts / screws are lined up and inserted into holes.
2. Do not over tighten screws and bolts to avoid stripping.
3. Please use hand tools to assemble this product. Do not use power tools.


CAM LOCK FASTENING SYSTEM

This Cam Lock Fastening System will be used throughout the assembly process.




Press CAM BOLT into hole.

2




Press CAM LOCK into hole.

3




Press parts together so CAM BOLT inserts into edge hole.






4




Using a screwdriver, turn the CAM LOCK clockwise to lock the CAM LOCK and CAM BOLT into their holes and fastening parts together.




Notice: Proper orientation of CAM LOCK




It may be necessary to adjust the hinges so that the doors align. Use the instructions below as a guide.




To adjust the door vertically loosen the screw as shown and move up and down as needed.



To adjust the gap from the door to the main frame turn the screw clockwise or anticlockwise as needed.





To adjust the door laterally (such as changing the gap between the two doors), please adjust the screw as shown by turning clockwise or anticlockwise.





Please fix other screws.

INSTALLATION STEPS

STEP 1


	
B x16PCS	A x16PCS




INSTALLATION STEPS



STEP 2




F x8PCS




INSTALLATION STEPS

STEP 3




A x8PCS




INSTALLATION STEPS

STEP 4







B x 8 PCS



INSTALLATION STEPS



STEP 5

		
Ox8 PCS	Cx6 PCS	F x6 PCS



INSTALLATION STEPS






STEP 6




INSTALLATION STEPS





STEP 7


				
Q x2PCS		A x6PCS	B x6PCS	C x6PCS



INSTALLATION STEPS





STEP 8



	
H x8PCS	P x6PCS





INSTALLATION STEPS

STEP 9

			
L x4PCS	J x2PCS	G x8PCS	N x4PCS




10




9

INSTALLATION STEPS

STEP 10








G x 8PCS



INSTALLATION STEPS



STEP 11

			
K x4PCS	J x2PCS	G x8PCS	N x4PCS




INSTALLATION STEPS

STEP 12




G x 8 PCS



INSTALLATION STEPS



STEP 13


When the 12th step after the installation of the door plate up and down is not flush (height difference) can loosen the hinge on the G screws to adjust the distance between the door plate up and down until flush, and then lock the G screws.



INSTALLATION STEPS

STEP 14


	
G x16PCS	M x8PCS



INSTALLATION STEPS



STEP 15


When the door panel does not line up front to back and side to side after step 14 is installed, refer to the schematic diagram for adjustment.



INSTALLATION STEPS

STEP 16

	
E x16PCS	D x16PCS



INSTALLATION STEPS

STEP 17

Tips: This step is to install the anti-tipping device system, which requires drilling holes in the wall.

