


# **CROSLEY**










---

## FURNITURE












Medium Vinyl Record  
Storage Stand  
CF1216



# PARTS LIST


<p><b>A</b></p> 	<p><b>B</b></p> 	<p><b>C</b></p> 	<p><b>D</b></p> 	<p><b>E</b></p> 
<p>Left Panel 1 PC</p>	<p>Right Panel 1 PC</p>	<p>Bottom Panel 1 PC</p>	<p>Fixed Shelf Panel 2 PCS</p>	<p>Upper Back Panel 1 PC</p>
<p><b>F</b></p> 	<p><b>G</b></p> 	<p><b>H</b></p> 	<p><b>I</b></p> 	
<p>Middle Back Panel 1 PC</p>	<p>Lower Back Panel 1 PC</p>	<p>Rail 1 PC</p>	<p>Leg 4 PCS</p>	

## HARDWARE LIST

#1  8*30mm	#2  Cam Bolt 24 PCS (Extra 1)	#3  Cam Lock 24 PCS (Extra 1)	#4  Connecting Bar 4 PCS	#5  8*4*20mm Short Screw 8 PCS (Extra 1)
#6  8*4*25mm Long Screw 4 PCS (Extra 1)	#7  1/4"*20mm Long Bolt 4 PCS (Extra 1)	#8  1/4"*12mm Short Bolt 12 PCS (Extra 1)	#9  Cam Sticker 24 PCS (Extra 1)	#10  M4 Allen Wrench 1 PC
#11  Safety Strap Kit 1 SET				

## ADDITIONAL TOOLS (Not Provided)

Note: It is not recommended to use power tools during assembly.




Phillips Head Screwdriver


Note: Wood dowels are intended for alignment. Additional clearance between wood dowel and pre-drilled hole is intentional for ease of assembly.

Step 1. Insert cam bolts (part #2) into pre-drilled holes of panels (parts A, B, C, F & G) using phillips head screwdriver.

Note: Do not over tighten cam bolts. Stop tightening once threads on cam bolt are no longer visible.





Step 2. Attach connecting bars (part #4) to legs (part I) using short screws (part #5), long bolts (part #7), allen wrench (part #10) and phillips head screwdriver.



Step 3. Attach rail (part H) to bottom panel (part C) using wood dowels (part #1), cam locks (part #3) and phillips head screwdriver.



Note: Cam locks must rotate a full 180°. See pictured insert.





- |    |  |     |
|----|--|-----|
| #1 |   | x 2 |
| #3 |  | x 2 |

Step 4. Attach fixed shelf panels (part D) to middle back panel (part F) using wood dowels (part #1), cam locks (part #3), long screws (part #6) and phillips head screwdriver.



Note: Cam locks must rotate a full 180°. See pictured insert.






- |    |   |     |
|----|---|-----|
| #1 |  | x 4 |
| #3 |  | x 2 |
| #6 |  | x 2 |

Step 5. Attach panels (parts E & G) to fixed shelf panels (part D) using wood dowels (part #1), cam locks (part #3), long screws (part #6) and phillips head screwdriver.



Note: Cam locks must rotate a full 180°. See pictured insert.



- |    |   |     |
|----|---|-----|
| #1 |    | x 4 |
| #3 |  | x 2 |
| #6 |  | x 2 |



Step 6. Attach bottom panel (part C) to lower back panel (part G) using wood dowels (part #1), cam locks (part #3) and phillips head screwdriver.



Note: Cam locks must rotate a full 180°. See pictured insert.





- |    |   |     |
|----|---|-----|
| #1 |  | x 2 |
| #3 |  | x 2 |


Step 7. Attach left panel (part A) to assembled unit (parts C, D, E, F, G & H) using wood dowels (part #1), cam locks (part #3) and phillips head screwdriver.  
 Note: Cam locks must rotate a full 180°. See pictured insert.




- #1  x 5
- #3  x 8

Step 8. Attach right panel (part B) to assembled unit (parts C, D, E, F, G & H) using wood dowels (part #1), cam locks (part #3) and phillips head screwdriver.  
 Note: Cam locks must rotate a full 180°. See pictured insert.



- #1  x 5
- #3  x 8


Step 9. Attach legs (part I) to bottom panel (part C) using short bolts (part #8) and allen wrench (part #10).









Step 10. Carefully turn unit upright. Using cam stickers (part #9) cover all cam locks (part #3).

Important: Safety strap kit (part #11) must be installed to prevent tipping damage and/or injury.

NOTE: It is important to adjust levelers once fully assembled and upright. Extend adjustable leveler until it's firmly in contact with the floor. If relocating, adjust leveler as needed until it's firmly in contact with the floor in new location.




#11	A	B	C	D	E
			 8*3*15mm	 8*4*35mm	
Safety Strap Kit 1 SET	Wall Anchor 1 PC	Bracket 2 PCS	Short Screw 1 PC	Long Screw 1 PC	Safety Wall Strap 1 PC

## SAFETY WALL STRAP INSTALLATION

Note: It is highly recommended to install this safety strap kit to prevent tipping, damage and/or injury.

1. Insert short screw (C) and safety wall strap (E) through bracket (B) and attach to upper back panel (part E) using phillips head screwdriver.
2. Drill a 11/32" hole where you want to secure the unit. The drilled hole will be at the same height as the hole in upper back panel (part E) where bracket (B) is attached. Tap wall anchor (A) into the hole.
3. Insert long screw (D) and safety wall strap (E) through bracket (B) into wall anchor (A) using phillips head screwdriver.

Note: This item is not intended for clothing storage use.



⚠ WARNING	
	<p>Children have died from furniture tipover. To reduce the risk of furniture tipover:</p> <ul style="list-style-type: none"> <li>• ALWAYS install tipover restraint provided.</li> <li>• NEVER put a TV on this product.</li> <li>• NEVER allow children to stand, climb or hang on drawers, doors, or shelves.</li> <li>• NEVER open more than one drawer at a time.</li> <li>• Place heaviest items in the lowest drawers.</li> </ul>
	<p>This is a permanent label. Do not remove!</p>