



# Assemble Instruction

---



As this item contains many parts, please read the installation instruction carefully before installation and complete the installation with the cooperation of your partner. Please use tools properly and carefully. If you have any questions about the product and installation, please contact us.

# Before You Start








- ✓ Read through each step carefully and follow the proper order
- ✓ Separate and count all your parts and hardware
- ✓ Give yourself enough room for the assembly process
- ✓ Have the following tools: Flat Head Screwdriver, #2 Phillips Head Screwdriver and Hammer
- ✓ Caution: If using a power drill or power screwdriver for screwing, please be aware of to slow down and stop when screw is tight. Failure to do so may result in stripping the screw. (Assembly speed can be increased by using electric screwdriver)

# Helpful Hints


## PEOPLE NEEDED FOR ASSEMBLY: 1-2

- Open your item in the area you plan to keep it to avoid excessive heavy lifting.
- Identify, sort and count the parts before attempting assembly.
- Compression dowels are lightly tapped in with a hammer.
- Slides are labeled with an **R** (right) and **L** (left) for proper placement.
- Make sure to always face the point on the top of the Cam Lock towards the outer edge.
- If there is a back panel in the package, please install it to make sure your unit is complete and sturdy.
- Please fix all the screws provided for the back panel which can enhance product stability. If it is difficult to fix it when tightening, it can be fixed with the help of a hammer and then tightened.
- Do NOT use harsh chemicals or abrasive cleaners on this item.
- Never push, pull, or drag your furniture.




# Board Identification

Not actual size




**A**

Qty:1




**B**

Qty:1




**C**

Qty:1




**D**

Qty:1




**E**

Qty:4




**F**

Qty:4




**G**

Qty:1



**H**

Qty:1




**I**

Qty:2

---


# Board Identification

Not actual size




ⓐ

Qty:2




ⓑ

Qty:2




ⓒ

Qty:2




ⓓ

Qty:1



ⓔ


Qty:1




ⓕ

Qty:1


# Part List




CAM LOCK  
spare:2




CAM BOLT  
spare:2




WOOD DOWEL  
spare:2




CONFIRMAT SCREWS  
spare:1




CONFIRMAT SCREWS  
spare:2




CONFIRMAT SCREWS  
spare:1




GASKET




SCREW  
spare:2




LEFT CABINET MEMBER




RIGHT CABINET MEMBER




LEFT DRAWER RUNNER




RIGHT DRAWER RUNNER




USB SOCKET




H-STRIP



BACK PANEL BUCKLE  
spare:1



PERFECT STICKER  
spare:2




HEX KEY

# Part List


## Cam Lock Fastening System

Insert the cam bolt into the hole first, then insert the cam lock and lock it.


1



2




3





The opening must point toward the edge of the board

4






# Board Identification



Not actual size











# STEP 1









X4



# STEP 2







# STEP 3





Insert the cam bolt into the hole first, then insert the cam lock and lock it.






# STEP4




The first hole



# STEP 5




Install with groove facing down.




Install with groove facing down.

Insert the cam bolt into the hole first, then insert the cam lock and lock it.

# STEP 6









The upper and lower back plates are connected with H-shaped clamping strips.








Insert the cam bolt into the hole first, then insert the cam lock and lock it.

# STEP 7




Insert the cam bolt into the hole first, then insert the cam lock and lock it.







# STEP 8



Note that the high position of the gasket is inward, and the low position is outward.




# STEP 9



**Step 1** Pass the USB socket wire through the panel slot





**Step 2** The plug end is then passed through the back plate hole and pulled to the back of the cabinet.



**Step 3** Fix the USB socket to the panel




Insert the cam bolt into the hole first, then insert the cam lock and lock it.

# STEP10




Insert the plastic buckle into the back plate slot, screw through the hole in the plastic buckle and lock it in place.

# STEP11










X2










X2

# STEP 12








Insert the cam bolt into the hole first, then insert the cam lock and lock it.

# STEP13



Insert the cam bolt into the hole first, then insert the cam lock and lock it.

# STEP14



# STEP15

---

